



INSTRUCTIONS MANUAL



Keep for future use!

POLYUREA SPRAY SYSTEM

Serial Number:



VR COATINGS PVT.LTD.

OFFICE: J-138, MIDC PUNE – 411 026, INDIA.

TEL : + 91 - 20 - 69180136 / 27130331

E-MAIL: vrcoatings@eth.net


**Factory: Plot No.136, Sector No.7, PCNTDA,
Bhosari, Pune – 411 026, INDIA.**

TEL: + 91 – 20 - 69180106

E-MAIL: service@vrcoatings.com

Mr. Pascal D'souza (Technical Director)

+91- 9822655891






INSTRUCTIONS MANUAL



Keep for future use!



200 LTRS. BARREL TRANSFER PUMP

Serial Number:



VR COATINGS PVT.LTD.

OFFICE: J-138, MIDC PUNE – 411 026, INDIA.

TEL : + 91 - 20 - 69180136 / 27130331.

E-MAIL: vrcoatings@eth.net


**Factory: Plot No.136, Sector No.7, PCNTDA,
Bhosari, Pune – 411 026, INDIA.**

TEL: + 91 – 20 - 69180106

E-MAIL: service@vrcoatings.com

Mr. Pascal D'souza (Technical Director)

+91- 9822655891



CONTENT

DECLARATION OF CONFIRMITY

WARNING AND SAFETY INSTRUCTION

OPERATING INSTRUCTIONS, MAINTAINANCE,
TROUBLESHOOTING

TECHNICAL SPECIFICATIONS

DRAWINGS AND PARTLISTS

WARRANTY

NOTES



CONTENT

DECLARATION OF CONFIRMITY

WARNING AND SAFETY INSTRUCTION

OPERATING INSTRUCTIONS, MAINTAINANCE,
TROUBLESHOOTING

TECHNICAL SPECIFICATIONS

DRAWINGS AND PARTLISTS

WARRANTY

NOTES





TECHNICAL SPECIFICATION

POLYUREA SPRAY SYSTEM - 2K/270/110X2

Type	2K/270/110x2
Mixing Ratio	1 :1
Transfer Ratio	55:1
Output Per Cycle	220 cc
Air motor Piston Ø	270 mm
Spray Volume @ 40 cycles/min	8.8 ltr/min
Air In Max	6 bar
Max. Pressure	330 bar
Air consumption N ltr @ 40 cycles/min	3850
Inline Heaters	7kw x 2nos.
Temperature Range	Up to 100° C
Power Supply	415 VAC-3 phase 50 Hz 5 wire R-Y-B-N-E copper flexible 6sq.mm x 5 core cable for incoming feeder







	PART NAME	OLD PART NO.	NEW PART NO.
A	AIR SEAL	01 080 012 00	01 080 012 57


(DIRECTLY REPLACIBLE)

[NOTE : W& T ITEMS ARE SOLD WITH SERVICE KIT ONLY]

	01 080 700 00	SERVICE KIT	-	-	SET
	02 080 010 31	GASKET	-	-	2
14	01 080 003 19	STUD	3		-
13	20 011 037 19	WASHER M6	6		-
12	01 080 001 02	TOP CASTING	1		-
11	01 080 010 25	O-RING	2	Y	2
10	01 080 004 01	CYLINDER	1		-
9	01 080 006 19	NUT	1		-
8	01 080 008 01	PISTON DISC	1		-
7	01 080 007 25	O-RING	1	Y	1
6	01 080 009 19	PISTON	1		-
5	61 110 008 00	SENSING VALVE	2	Y	2
4	15 207 008 19	NUT (M6X1)	3		-
3	01 080 011 02	BOTTOM CASTING	1		-
2	01 080 012 57	AIR SEAL	1	Y	1
1	01 080 014 07	CIRCLIP	1		-
SR.NO.	PART NO.	PART NAME	QTY.	W&T	



Note: Gasket shown in assembly dwg of Control Block


RAW MATERIAL DESCRIPTION		NOTE:					
SIZE							
LENGTH							
MAT.							
		ALL DIMN. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01. REMOVE SHARP CORNERS. INCASE OF DOUBT ASK.					
 VR COATINGS PVT.LTD. J-138, MIDC, BHOSARI, PUNE-411 026 INDIA		DRN.	CKD.	APPD.	PART NAME	AIR MOTOR D 80 S 120	
		SIGN	ROHIT	Albert			NVD
		DATE				PART NO.	01 080 000 00
		SCALE		NOT TO SCALE			





NOTE : W & T ITEMS ARE SOLD WITH SERVICE KIT ONLY.



	02 081 700 01	SERVICE KIT	-	-	SET
23	15 330 008 19	ALLEN BOLT(M6X30)	2		-
22	15 340 008 19	ALLEN BOLT M6	4		-
21	02 081 021 57	MID BLOCK GASKET	2	Y	2
20	02 081 022 57	MID BLOCK GASKET	2	Y	2
19	02 081 001 00	SIDE BLOCK ASSEMBLY	1		-
18	15 345 008 19	ALLEN BOLT (M6X45)	4		-
17	02 081 023 57	MID BLOCK GASKET	2	Y	2
16	02 080 021 22	PIN Ø3 X 5	1	Y	1
15	02 081 042 57	BOTTOM GASKET	1	Y	1
14	02 081 003 00	SLIDER ASSEMBLY	1	Y	1
13	02 081 026 57	MID BLOCK GASKET	2	Y	-
12	02 081 029 02	BOTTOM BLOCK	1		-
11	02 081 025 57	MID BLOCK GASKET	2	Y	2
10	02 081 036 00	SILENCER ASSLY (TIGER)	1		-
9	15 370 008 19	ALLEN BOLT(M6x70L)	1		-
8	15 360 008 19	ALLEN BOLT (M6X60)	1		-
7	02 081 031 02	TIGER CB CAP	1		-
6	20 043 000 00	AIR SAFETY VALVE 1/4'	1		-
5	19 002 001 19	WASHER 1/4"	1		-
4	02 081 044 00	MIDDLE BLOCK ASM.	1		-
3	02 081 043 57	TOP GASKET	1	Y	1
2	02 081 027 02	TOP BLOCK	1		-
1	15 320 008 19	ALLEN BOLT M6X20	4		-
SR NOS.	PART NO.	PART NAME	QTY.	W & T	SERVICE KIT QTY.

RAW MATERIAL DESCRIPTION		NOTE: TIGER NEW CONTROL BLOCK					
SIZE		 ALL DIMN. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01. REMOVE SHARP CORNERS. IN CASE OF DOUBT ASK.					
LENGTH							
MAT.	ASSEMBLY						
 VR COATINGS PVT.LTD. J-138, MIDC, BHOSARI, PUNE-411 026 INDIA		DRN.	CKD.	APPD.	PART NAME	CONTROL BLOCK	
		SIGN	ROHIT	RAJIV			NVD
		DATE				PART NO.	02 081 000 01
		SCALE	NOT TO SCALE				





21	15 315 008 07	ALLEN BOLT M6X15	10	-
20	02 300 040 57	ROUND GASKET	4	Y
19	02 081 026 57	MID BLOCK GASKET	2	Y
18	02 300 042 57	GASKET	2	Y
17	02 300 045 00	MID BLOCK ASSEMBLY	1	-
16	02 300 009 02	SILENCER CAP	1	-
15	15 375 008 37	ALLEN BOLT	2	-
14	02 230 011 00	SILENCER ASSLY	1	-
13	15 335 008 07	ALLEN BOLT(M6X35)	8	-
12	15 360 008 07	ALLAN BOLT(M6X60)	4	-
11	02 300 036 02	BOTTOM BLOCK	1	-
10	02 300 024 00	SLIDER ASSEMBLY	1	Y
9	02 300 066 57	SQUARE GASKET	1	Y
8	15 322 008 07	ALLEN BOLT M6 x 22	4	-
7	02 300 004 02	INLET BLOCK	1	-
6	20 026 000 00	AIR SAFTEY VALVE 1/2"	2	-
5	02 300 064 57	ROUND LARGE GASKET	2	Y
4	02 300 043 57	GASKET	2	Y
3	02 300 065 57	ROUND SMALL GASKET	2	Y
2	02 081 001 00	SIDE BLOCK ASSEMBLY	1	-
1	02 300 035 02	TOP BLOCK	1	-
	02 300 700 04	SERVICE KIT	-	SET
SR NO.	PART NO.	PART NAME	QTY.	W&T

RAW MATERIAL DESCRIPTION		NOTE:					
SIZE		 ALL DIMN. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01. REMOVE SHARP CORNERS. INCASE OF DOUBT ASK.					
LENGTH							
MAT.	ASSEMBLY						
 VR COATINGS PVT.LTD. J-138, MIDC, BHOSARI, PUNE-411 026 INDIA		DRN.	CKD.	APPD.	PART NAME	RHINO CONTROL BLOCK ASSEMBLY	
		SIGN	NIKHL	RAJIV			WD
		DATE				PART NO.	02 300 000 04
		SCALE: NOT TO SCALE					



SECTION A-A
& B-B

13	WASHER 1/4"	19 001 002 19	11	
12	PRESSURE TRANSMITTER	98 014 400 10 WKA	2	
11	PRESSURE GAUGE	13 018 001 00	2	
10	PRESSURE GAUGE MOUNTING BLOCK	17 013 126 19	2	
9	CONNECTOR	14 001 001 19	2	
8	SWIVEL 1/4" BSP	51 101 000 02	2	
7	BALL 14	04 210 013 05	2	
6	PACKING RING	17 005 016 21	2	Y
5	SEAT ADAPTER	17 005 032 00	2	
4	CONNECTOR	17 013 040 07	2	
3	OUTLET MANIFOLD	17 013 042 08	1	
2	BALL GUIDE	04 210 017 17	3	
1	OUTLET MANIFOLD	17 013 313 08	1	
S.NO.	PART NAME	PART NUMBER	QTY.	W & T

RAW MATERIAL DESCRIPTION		NOTE:				
SIZE		<div>ALL DIMN. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01. REMOVE SHARP CORNERS. INCASE OF DOUBT ASK.</div>				
LENGTH						
MAT.	ASSEMBLY					
<div></div>						
<div></div>		SIGN	DRN.	APPD.	PART NAME	OUTLET MANIFOLD ASSEMBLY
VR COATINGS		DATE			PART NO.	17 013 312 00
J-138, MIDC, BHOSARI, PUNE-411 026		SCALE NOT TO SCALE				
INDIA						

PARTS LIST





TABLE B

14	LOWER PACKING SET (REG)	PTFE(6)	17 110 062 00
	LOWER PACKING SET (OPTIONAL)	GRAPHITE FILLED PTFE(6)	17 110 064 00
	LOWER PACKING SET (OPTIONAL)	BRONZE FILLED PTFE(6)	17 110 066 00
	LOWER PACKING SET (OPTIONAL)	UHMWPE (6)	17 110 070 00
	LOWER PACKING SET (OPTIONAL)	S.P.E(6)	17 110 071 00

TABLE C

PR. NO. FOR INDIVIDUAL PACKING RING			
S. NO.	PART NAME	PART NO.	
BA/14A	PACKING RING (PTFE)	04 110 089 21	
BB/14B	PACKING RING (GRAPHITE FILLED PTFE)	17 110 051 54	
BC/14C	PACKING RING (BRONZE FILLED PTFE)	04 110 052 48	ⓐ
BD/14D	PACKING RING (UHMWPE)	04 110 089 42	ⓑ
BE/14E	PACKING RING (S.E)	04 110 089 40	ⓒ

TABLE A			
3	UPPER PACKING SET (REG)	PTFE(7)	04 110 106 00
	UPPER PACKING SET (OPTIONAL)	GRAPHITE FILLED PTFE(7)	04 110 107 00
	UPPER PACKING SET (OPTIONAL)	BRONZE FILLED PTFE(7)	04 110 108 00
	UPPER PACKING SET (OPTIONAL)	UHMWPE (7)	04 110 112 00
	UPPER PACKING SET (OPTIONAL)	S.E (7)	04 110 114 00

S. NO.	PACKING SET KIT	SERVICE KIT NO	QTY	W&T	SERVICE KIT QTY
3E/14E	SERVICE KIT-4(OPTIONAL)(UPPER-S.E)	17 110 709 00	-	Y	SET
3D/14D	SERVICE KIT-3(OPTIONAL)(UPPER-UHMWPE)	17 110 708 00	-	Y	SET
3C/14C	SERVICE KIT-2(OPTIONAL)(UPPER-BRONZE FILLED PTFE/LOWER-BRONZE FILLED PTFE)	17 110 710 00	-	Y	SET
3B/14B	SERVICE KIT-1(OPTIONAL)(UPPER-GRAPHITE FILLED PTFE/LOWER-GRAPHITE FILLED PTFE)	17 110 704 00	-	Y	SET
BA/14A	SERVICE KIT(REG)(UPPER-PTFE/LOWER-PTFE)	17 110 700 00	-	Y	SET

20	WASHER	04 110 021 19	1	
19	NUT	15 210 014 07	4	
18	WASHER	19 002 014 07	4	
17	STUD	04 110 019 17	4	
16	CONNECTOR	SEE NOTE	1	
ⓐ15	WASHER	19 002 003 19	1	
ⓐ14	LOWER PACKING SET	REFER TABLE B	1	Y
ⓐ13	PISTON SEAT	04 110 069 00	1	
12	BALL GUIDE	04 110 012 19	1	
11	BALL	04 070 013 19	1	Y
10	SUCTION SEAT	04 110 011 00	1	
9	CYLINDER	04 110 010 19	1	
8	BALL 12	04 070 016 05	1	
7	PISTON ROD	17 110 008 19	1	
6	PACKING RING	04 110 007 21	2	Y
5	SPACER	04 110 006 19	1	
ⓐ4	MALE PACKING CAP	17 110 068 19	2	
ⓐ3	UPPER PACKING SET	REFER TABLE A	1	Y
ⓐ2	FEMALE PACKING CAP	17 110 067 19	2	
1	OIL CUP	17 110 001 17	1	
S.NO.	PART NAME	PART NUMBER	QTY.	W & T




PARTS LIST

D	UHMWPE, S.E.PACKING SET ADDED.	29/07/15	
C	PACKING SET NO. CHANGE, WASHER PART NO. CHANGE	10/06/15	
B	GRAPHITE FILLED PTFE AND BRONZE FILLED PTFE PACKING SET NEWLY ADDED	24/08/14	
B	MIDDLE PACKING CAP(04 110 014 19) REMOVED FROM LOWER PAKING SET.		
B	LOWER PACKING RING QTY 4, CHANGED TO 5	24/08/14	
A	PISTON SEAT PART NO. CHANGED AND PACKING MATERIAL CARBON FL PTFE CHANGED TO BR FL PTFE	12/06/06	



Rev.	AMENDMENT	Date	Appd.
------	-----------	------	-------


RAW MATERIAL DESCRIPTION	NOTE: CONNECTOR FOR BASE PUMP 14 003 002 19
SIZE	CONNECTOR FOR ACTIVATOR PUMP 17 013 058 19
LENGTH	ALL DIM. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01.
MAT.	REMOVE SHARP CORNERS. IN CASE OF DOUBT ASK.
ASSEMBLY	
SIGN	DRN. CKD. APD.
RENU	
DATE	

VR COATINGS	PART NAME	HYDRAULIC PART 110
J-138, MDC, BHOSAPUR, PUNE-411 026	PART NO.	17 110 000 00
INDIA		
SCALE NOT TO SCALE		



23	15 211 015 07	NUT M 12	4	
22	19 002 011 19	WASHER M14	3	
21	17 350 009 17	BOLT M14X2	3	
20	61 110 008 00	SENSING VALVE	2	Y
19	17 300 003 19	PISTON ROD	2	
18	17 271 003 07	PISTON DISC	1	
17	01 270 003 25	O RING	2	Y
16	15 360 021 07	ALLEN BOLT M20X60	2	
15	15 603 025 07	GRUB SCREW M3 X 0.5	1	
14	17 300 007 07	COVER	1	
13	01 230 013 07	INTERNAL CIRCLIP B55	1	
12	01 230 011 00	AIR SEAL	1	Y
11	17 300 005 16	BUSH	1	
10	01 230 002 00	STUD	4	
9	19 002 015 07	WASHER	8	
8	17 271 001 02	TOP CASTING	1	
7	01 270 002 19	CYLINDER	1	
6	17 300 006 19	TOP PISTON ROD	1	
5	15 360 017 07	BOLT M16X60	1	
4	01 270 005 25	O RING	2	Y
3	17 271 002 02	BOTTOM CASTING	1	
2	01 110 018 00	AIR SEAL	2	Y
1	01 110 022 07	CIRCLIP	2	
SR. NO.	PART NO.	PART NAME	QTY.	W & T



RAW MATERIAL DESCRIPTION		NOTE:	
SIZE		ALL DIMN. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01. REMOVE SHARP CORNERS. IN CASE OF DOUBT ASK.	
LENGTH			
MAT.	ASSEMBLY		
SIGN  DRN. CKD. APPD. DATE  ALBERT M.D. PART NAME AIR MOTOR		PART NO. 17 271 000 00	
VR COATINGS PVT.LTD. J-138, MIDC, BHOSARI, PUNE-411 026 INDIA		SCALE NOT TO SCALE	




32	29 003 019 21	PACKING RING	2	Y
31	29 003 036 19	BALL GUIDE 28	1	
30	33 275 031 19	BALL $\phi 19$ MM	1	
29	29 003 039 00	SEAT HOLDER	1	
28	15 110 014 07	NUT M10	1	
27	29 003 028 19	SEAL WASHAR	1	
26	29 003 029 19	LOCK NUT	1	
25	29 003 009 19	CYLINDER OUTER	1	
24	29 003 020 21	PACKING RING	1	Y
23	33 275 009 00	PACKING SET	1	Y
22	29 003 050 07	WASHAR M8	6	
21	15 320 008 07	ALLEN BOLT M6X20	4	
20	29 003 049 19	CONNECTING ROD	1	
19	29 003 069 19	TIE ROD	3	
18	01 080 000 00	AIR MOTOR 080 S120	1	
17	02 081 000 01	CONTROL BLOCK	1	
16	48 031 082 00	OIL CUP COVER	1	
15	09 001 000 00	COUPLING ASSEMBLY	1	
14	29 003 008 17	CUP NUT	1	
13	29 003 067 01	FLANGE	1	
12	15 210 009 07	NUT (M8)	6	
11	29 003 041 00	OUTLET HOUSING ASSEMBLY	1	
10	29 003 010 19	CYLINDER INNER	1	
9	29 003 045 00	SHAFT	1	
8	29 003 031 21	SEAL WASHER	1	Y
7	29 003 026 21	SEAL UPPER	1	Y
6	04 070 013 19	BALL $\phi 28$ MM	1	Y
5	29 003 021 19	PISTON HOLDER	1	
4	29 003 025 21	SEAL	1	Y
3	29 003 024 19	SEAT WASHAR	1	
2	29 003 047 19	INTRENAL CIRCLIP B45	1	
1	29 003 040 00	SUCTION SEAT	1	
SR. NO.	PART NUMBER	PART NAME	QTY.	W & T



RAW MATERIAL DESCRIPTION		NOTE:	
SIZE		ALL DIM. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01. REMOVE SHARP CORNERS. IN CASE OF DOUBT ASK.	
LENGTH			
MAT.			
VR COATINGS PVT.LTD. J-138, MIDC, BHOSARI, PUNE-411 026 INDIA		DRN CKD APPD SIGN ANIL ALBERT NYD DATE SCALE NOT TO SCALE	PART NAME BARREL PUMP 4.5:1 PART NO. 29 009 000 03

16	41 006 008 00	CABLE GLAND	1	
15	15 390 008 07	ALLEN BOLT	4	
14	41 011 021 01	CAP	1	
13	41 011 016 19	PLUG 1/2"	7	
12	41 011 018 04	PACKING RING	7	
11	41 011 017 04	PACKING RING	13	
10	41 011 015 19	PLUG M22 X 1.5	13	
9	41 005 124 00	HEATER ELEMENT	1	Y
8	41 011 010 01	SCREWED PLATE	1	
7	41 011 013 00	RTD SENSOR 3/8"	1	
6	41 011 012 04	RTD SENSOR BODY	1	
5	41 011 006 01	HEATER BODY	1	
4	41 011 005 19	CONNECTOR M26 X 1.5 X 3/4"	2	
3	41 011 014 19	DISTANCE PIECE	1	
2	15 315 008 19	ALLEN BOLT M6X15	8	
1	41 011 009 01	SCREWED PLATE	1	
SR.NOS.	PART NO.	PART NAME	Qty.	W&T

A		SR.NO. 14,15 & 16 ADDED	03/08/16		RAW MATERIAL DESCRIPTION		NOTE:	
REV		DESCRIPTION	DATE	APPD.	SIZE	 <p>ALL DIMN. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01. REMOVE SHARP CORNERS. INCASE OF DOUBT ASK.</p>		
AMMENDMENTS					 VR COATINGS PVT.LTD. J-138, MIDC, BHOSARI, PUNE-411 026 INDIA		DRN. CKD. APPD. SIGN OMKAR ALBERT NVD DATE SCALE NOT TO SCALE	PART NAME HEATER 7.6 KW WITHOUT CONTROL PANEL PART NO. 41 011 000 00





A	SR.NO. 14,15 & 16 ADDED	03/08/16	
REV	DESCRIPTION	DATE	APPD.
AMMENDMENTS			

RAW MATERIAL DESCRIPTION		NOTE:					
SIZE							
LENGTH							
MAT.							
		ALL DIMN. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01. REMOVE SHARP CORNERS. INCASE OF DOUBT ASK.					
 VR COATINGS PVT.LTD. J-138, MIDC, BHOSARI, PUNE-411 026 INDIA		DRN.	CKD.	APPD.	PART NAME	HEATER 7.6 KW WITHOUT CONTROL PANEL	
		SIGN	OMKAR	ALBERT			NVD
		DATE				PART NO.	41 011 000 00
		SCALE	NOT TO SCALE				

WEB SITE - <http://www.vrcoatings.com>
E-MAIL - vfdsouza@vsnl.com

PLC BASED
CONTROL PANEL



QUOTATION NUMBER

NOTE:



VR COATINGS
J-138, MIDC, BHOSARI
PUNE-411026 (INDIA)
TEL : (020) 7122331
FAX : (020) 7121891



ALL DIM. ARE IN MM UNLESS OTHERWISE STATED.

SIGN	DRN.	APPD.	PROJECT NAME	POLYUREA SPRAY SYSTEM
DATE			CUSTOMER NAME	TORNADO
SCALE	NOT TO SCALE			

WARRANTY

VR Coatings warrants all equipments manufactured by us, as long as it is bearing original identification plate, to be free from defects in material and workmanship for a period of twelve months from ex-works date. VR Coatings will repair or replace any part of the equipment proven defective. The warranty applies only when the equipment is installed, operated and maintained in accordance with VR Coatings written recommendations.

Warranty claims found to be defective shall be verified and confirmed by VR Coatings.

Our warranty does not cover and VR Coatings shall not be liable for any malfunction, damages, or fair wear and tear caused by faulty installation, misuse, abrasion, corrosion, inadequate or improper maintenance, negligence, tempering, accident or incorporation of non VR Coatings parts, non observance of VR Coatings recommendations.

This warranty only consists of replacing the parts returned to our plant prepaid transportation and proven defective by us. If inspection of the equipment /part does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which may include the cost of parts, labor and transportation. VR Coatings shall not be liable for any losses resulting from a production breakdown.

Any bought out material in the equipment, which is sold but not manufactured by VR Coatings, will be subject to the manufacturer's warranty. VR Coatings will provide purchaser with reasonable assistance in making any claim for breach of these warranties.






INSTRUCTIONS MANUAL



Keep for future use!



200 LTRS. BARREL TRANSFER PUMP

Serial Number:



VR COATINGS PVT.LTD.

OFFICE: J-138, MIDC PUNE – 411 026, INDIA.

TEL : + 91 - 20 - 30781022 / 27130331.

E-MAIL: vrcoatings@eth.net

Factory: Plot No.136, Sector No.7, PCNTDA,
Bhosari, Pune – 411 026, INDIA.

TEL: + 91 – 20 - 30781034

E-MAIL: service@vrcoatings.com

Mr. Pascal D'souza (Technical Director)

+91- 9822655891





INSTRUCTIONS MANUAL

Keep for future use!



POLYUREA SPRAY SYSTEM

Serial Number:



VR COATINGS PVT.LTD.

OFFICE: J-138, MIDC PUNE – 411 026, INDIA.

TEL : + 91 - 20 - 69180136 / 27130331

E-MAIL: vrcoatings@eth.net


Factory: Plot No.136, Sector No.7, PCNTDA,
Bhosari, Pune – 411 026, INDIA.


TEL: + 91 – 20 - 69180106

E-MAIL: service@vrcoatings.com


Mr. Pascal D'souza (Technical Director)

+91- 9822655891






L.H.S. VIEW



FRONT VIEW



R.H.S. VIEW

LEGENDS:

- 1: 'R' PHASE INDICATOR RED LED

2: 'Y' PHASE INDICATOR YELLOW LED

3: 'B' PHASE INDICATOR BLUE LED

4: BASE HEATER TIC

5: ACT HEATER TIC

6: MONITORING ON/OFF SW

7: SPRAY ON/OFF SW

8: FAULT ACK PB
- 9: MIMIC HOOTER

10: BASE HEATER ON/OFF SW

11: ACT. HEATER ON/OFF SW

12: SPARE


13: EMERGENCY PB


14: SOLENOID VALVE CONNECTOR


15: PRS. MONITOR CONNECTOR

16: MAIN SWITCH
- 17: FILTER

18: FAN + FILTER







DRAWN BY : SURESH

PRINT DATE: 07.06.2014

TITLE: WRING DIAGRAM FOR 230VAC CONTROL

PROJECT: 7.5 KW HEATER SYSTEM


V.R. COATINGS PVT LTD, PUNE

DWG. NO:

11

+

 $\frac{4}{5}$



ELECTRICAL SAFETY INSTRUCTIONS



- Avoid contact with ***energized electrical circuits***
- Disconnect the power source before servicing or repairing electrical equipment.
- Use only tools and equipment with non-conducting handles when working on electrical devices
- Never use metallic pencils or rulers, or wear rings or metal watchbands when working with electrical equipment. This rule is very easy to forget, especially when you are showing some electrical part pointing with metallic pencil.
- If water or a chemical is spilled onto equipment, shut off power at the main switch or circuit breaker and unplug the equipment.
- Do not store "***highly flammable liquids***" near electrical equipment.
- Do not wear loose clothing or ties near electrical equipment.
- In case of PLC used in panel, keep the power supply ON for at least two hours in a week.
- Make sure all electric cords are tucked away, neat and tidy.
- Always use caution when working near electricity.



VR COATINGS PVT.LTD.

J-138,MIDC PUNE-411 026
INDIA. TEL:(020)27130331,27130196
FAX:(020)30781051
E-MAIL:vrcoatings@eth.net

No Contractual Document. Specification and features subject to change without notice.


DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE STATED

HEATER 7.6 KW.

PAINT WITHOUT CONTROL PANEL

Maxi. Inbound Pressure - 400 bar

PAGE - 1



PART NO.

REF.

41 011 000 00

PAGE 00


41 011 700 00

PAGE 00



WEAR AND TEAR KIT

FOR COMPLETE HEATING UNIT



TECHNICAL SPECIFICATION

Maximum Inbound Pressure : 400 bar
Capacity : 7.6 KW
Power Supply : 415 VAC, 3 } , 50Hz
Inlet, Outlet Port : 3/4" BSP(M)
Temperature Range : 100°C
Wetted Parts : Aluminum, 304 Stainless Steel, PTFE.

DD-01/SD-30-1/0/010213

INPUT/OUTPUT LIST

INPUT

I1	Pressure Monitoring On/Off
I2	Fault Ack PB
I3	Supply On/Off sw
I4	Flush 1 sw
I5	Flush 2 sw
I6	Spare
I7	Base pressure input
I8	Act pressure input

OUTPUT

Q1	Supply Solenoid valve
Q2	Flush solenoid valve
Q3	Flt Lamp
Q4	Hooter

[illegible]

NOTES

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

OPERATION PROCESS

Power ON the Main switch. Check that all MCB's are switched ON.

Also check that all settings of temperature indicator controllers are as per requirement.

Select the "Base Heater" switch to ON position, tank heaters for base becomes ON.

Select the "Act. Heater" switch to ON position, tank heaters for activator becomes ON.

AUTO MODE:-

Select the Auto/Manual switch to Auto mode.

Spray Operation (Paint):-

- Select the "Spray" selector switch to ON position. Spray solenoid valve becomes ON and spray cycle starts.
- Do not select the flush switch during spray operation. Fault occurs but spray cycle do not get disturbed.

Flush Operation (Solvent):-

- Select the "Base Flush" selector switch to ON position. Base flush solenoid valve becomes ON and base flush cycle starts.
- Select the "Act Flush" selector switch to ON position. Activator flush solenoid valve becomes ON and activator flush cycle starts.
- Spray selector switch must be OFF if flush cycle is ON.

Pressure Monitoring:-



- Select the "Pressure Monitoring" selector switch to ON position. Whenever pressure rises or falls down beyond set limits, pressure fault occurs. Hooter sounds and fault lamp glows.
- Press Fault Ack pushbutton to silence the hooter and acknowledge the fault.



PRESSURE SETTING ON PLC:-



- 1) On PLC display, set the values for high pressure, low pressure for both Base (paint) and Solvent.
- 2) When actual pressure deviates from these set ranges of pressure values, pressure fault occurs. (Pressure monitoring switch should be ON).

When control panel is powered up. Following screen appears.





The screen shows the actual pressure for Base and Activator. This is only readable message screen and cannot be edited.

Press "Down arrow key" to display job counter screen. Following screen appears.



The screen shows job counter display. This is optional arrangement, if there is requirement to have record of jobs sprayed in auto cycle. The counter gets incremented by 1 for each auto cycle. To reset the counter, press "Right arrow key and ESC key" simultaneously.


Now press "Down arrow key", following screen appears.




The screen shows date and time in blinking mode. Both are settable parameter.




Press “ESC” key to enter setting screen which is shown as under.



Using “Down arrow key”, move the cursor to “set Param” function key. Following screen appears.




Press OK key of HMI to move to next screen shown as below.



Fault On delay timer can be set at this screen. The timer starts whenever a fault occurs. If the fault remains till the completion of this timer, fault lamp glows and hooter sounds.

Press Fault Ack pushbutton to silence the hooter and acknowledge the fault.


Press ‘up’ arrow key, following screen appears.



High limit for base pressure can be set at the parameter “On”.

For Ex:- Let the high limit for base pressure is set at “275” bar. When pressure goes beyond 275bar, fault occurs. Fault gets cleared only if pressure comes below “273”bar (Off parameter). The pressure limit can be changed using up/down arrow keys.


Press ‘up’ arrow key, following screen appears.



Low limit for base pressure can be set at the parameter “Off”.

For Ex:- Let the low limit for base pressure is set at “148” bar. When pressure falls below 148bar, fault occurs. Fault gets cleared only if pressure resumes above “150”bar (On parameter). The pressure limit can be changed using up/down arrow keys.

Press ‘up’ arrow key, following screen appears.



High limit for activator pressure can be set at the parameter “On”.

For Ex:- Let the high limit for act pressure is set at “275” bar. When pressure goes beyond 275bar, fault occurs. Fault gets cleared only if pressure comes below “273”bar (Off parameter). The pressure limit can be changed using up/down arrow keys.

Press ‘up’ arrow key, following screen appears.



- If activator pressure rises beyond the set pressure limit, activator pressure high message gets displayed as shown below.

			A	C	T				
		P	R	E	S	S	U	R	E
			H	I	G	H			


- If activator pressure falls below the set pressure limit, activator pressure low message gets displayed as shown below.

			A	C	T	.			
		P	R	E	S	S	U	R	E
			L	O	W				




TYPICAL INSTALLATION

Barrel Transfer Pump 4.5:1
(For Moisture Sensitive Material)



Barrel Length Pump 5.230
(For General Liquid)



INSTALLATION

1. Screw the bung adapter tightly into the bunghole of the drum.
 2. Install an air line filter on air line to remove harmful dirt and moisture from the compressed air supply.
 3. Connect air supply to the pump.
 4. Always connect a ground wire to the air motor.
- The pump installation is complete.

OPERATION

Daily startup procedures

1. Connect air supply to the Transfer pump.
 2. Turn on the main air supply.
 3. Slowly increase the air pressure by air regulator until the transfer pump run slowly.
- Use the Air regulator to control the pump speed.

Daily shutdown procedures

1. Slowly decrease the air pressure until zero.
2. Disconnect the air line.

For extended period shutdown

Flush, disassemble and thoroughly clean the Transfer pump before storing in a dry place.

MAINTANANCE

WARNING: TO AVOID PERSONAL INJURY, ALWAYS DISCONNECT THE AIR COUPLER AND RELIVE ALL THE AIR AND HYDRAULIC PRESSURES BEFORE SERVICING THE PUMP.

Disassembly

1. Place the transfer pump in a vice.
2. Remove the suction seat.


If the unit requires more than installation of a repair kit, it is usually quicker and least expensive to send the unit in for repair.

TROUBLE SHOOTING


MALFUNCTION	Pump does not start/stops during operation	Pump does not suck or only insufficiently	Spray pressure too low	Pump operates irregularly	Pump operates although spray gun is closed	Pump transports material into the rinsing agent	Regulator frozen
AIRMOTOR	Press sensing valve provided on control block Clean regulator, replace defective parts if necessary			Clean regulator, replace defective parts if necessary			Compressed air too moist, stroke frequency too high, ambient temperature too low.
HYDRAULIC PART		Not sufficiently ventilated, loose suction connection		Not sufficiently ventilated, loose suction connection	Not sufficiently ventilated, loose suction connection		
SUCTION AND TRANSFER VALVE		Worn or blocked, replace defective parts		Worn or blocked, replace defective parts	Replace worn or defective parts		
PACKINGS		Leaking piston and packing		Leaking piston and packing		Leaking packing	
FILTER	Filter mesh blocked, check where and clean out	Filter mesh blocked, check where and clean out	Filter mesh blocked, check where and clean out		Drain valve open.		
COMPRESSED AIR LINE	Volume flow too low, air pressure too low.		Volume flow too low, air pressure too low.				
MATERIAL HOSE	Blocked, check where and clean out	Blocked, check where and clean out	Blocked, check where and clean out				

TYPICAL INSTALLATION

**Barrel Transfer Pump 4.5:1
(For Moisture Sensitive Material)**



**Barrel Length Pump 5.230
(For General Liquid)**



INSTALLATION

1. Screw the bung adapter tightly into the bunghole of the drum.
 2. Install an air line filter on air line to remove harmful dirt and moisture from the compressed air supply.
 3. Connect air supply to the pump.
 4. Always connect a ground wire to the air motor.
- The pump installation is complete.

OPERATION

Daily startup procedures

1. Connect air supply to the Transfer pump.
 2. Turn on the main air supply.
 3. Slowly increase the air pressure by air regulator until the transfer pump run slowly.
- Use the Air regulator to control the pump speed.

Daily shutdown procedures

1. Slowly decrease the air pressure until zero.
2. Disconnect the air line.

For extended period shutdown

Flush, disassemble and thoroughly clean the Transfer pump before storing in a dry place.

MAINTANANCE

WARNING: TO AVOID PERSONAL INJURY, ALWAYS DISCONNECT THE AIR COUPLER AND RELIVE ALL THE AIR AND HYDRAULIC PRESSURES BEFORE SERVICING THE PUMP.

Disassembly

1. Place the transfer pump in a vice.
2. Remove the suction seat.

If the unit requires more than installation of a repair kit, it is usually quicker and least expensive to send the unit in for repair.

TROUBLE SHOOTING

MALFUNCTION	Pump does not start/stops during operation	Pump does not suck or only insufficiently	Spray pressure too low	Pump operates irregularly	Pump operates although spray gun is closed	Pump transports material into the rinsing agent	Regulator frozen
AIRMOTOR	Press sensing valve provided on control block Clean regulator, replace defective parts if necessary			Clean regulator, replace defective parts if necessary			Compressed air too moist, stroke frequency too high, ambient temperature too low.
HYDRAULIC PART		Not sufficiently ventilated, loose suction connection		Not sufficiently ventilated, loose suction connection	Not sufficiently ventilated, loose suction connection		
SUCTION AND TRANSFER VALVE		Worn or blocked, replace defective parts		Worn or blocked, replace defective parts	Replace worn or defective parts		
PACKINGS		Leaking piston and packing		Leaking piston and packing		Leaking packing	
FILTER	Filter mesh blocked, check where and clean out	Filter mesh blocked, check where and clean out	Filter mesh blocked, check where and clean out		Drain valve open.		
COMPRESSED AIR LINE	Volume flow too low, air pressure too low.		Volume flow too low, air pressure too low.				
MATERIAL HOSE	Blocked, check where and clean out	Blocked, check where and clean out	Blocked, check where and clean out				

OPERATION

- 1) I3 "ON" == Q1 ON
- 2) I4 "ON" == Q2A ON
- 3) I5 "ON" == Q2B ON
- 4) I1 "ON" == PRS MONITORING ON
FOR LP[OR HP " Q3 AND Q4"ON
FLT ACK === Q4 OFF
I1 "OFF" === Q3 ALSO OFF
- 5) I3 AND I4 "ON" == Q4 ON (HOOTER)
- 6) I3 AND I5 "ON" == Q4 ON

PREVENTIVE MAINTENANCE (ELECTRICAL)

- ❖ Keep the electrical control panel and junction boxes free from any debris and dust.
- ❖ Electrical connections should not be loosened. It may leads to spark.
- ❖ Identify components running hot or not according to specifications: Transformers, motors, bearings and wires almost always run hot before they fail. Predictive maintenance can avoid asset failure.
- ❖ Make sure that mounting fasteners and locking is secure.
- ❖ Check for wear of wiring insulation.
- ❖ Repair or replace the terminal blocks that are damaged or corroded.
- ❖ Make sure that all lamps are functioning well.
- ❖ Check the physical condition, operation and functionality of the Breakers, switches and component parts.
- ❖ Pitted contacts shall be replaced.
- ❖ Visually inspect for physical damage, moisture, overheating and cleanliness.
- ❖ Inspect and remove dust from busses, connectors, supports and Enclosure surfaces. A vacuum cleaner or dry compressed air may be used.
- ❖ Identify loose connections: Loose connections can cause power fluctuations to devices, devices to operate erratically and uneven load distribution between wires.



selecTC513A / TC513AX / TC221A /
TC203AX / TC303A / TC303AX
Operating Instructions**SPECIFICATIONS****Display**

3 digit, 7 segment digital display

LED Indications

R: Control output ON

Keys

3 keys for digital setting

INPUT SPECIFICATIONS**Input Signal**

Thermocouple (J,K,T,R,S) / RTD (Pt100)

Sampling time

250 ms

Input Filter (FTC)

0.2 to 10.0 sec

Resolution

Fixed 1° resolution

Temperature Unit

°C / °F selectable

Indication Accuracy

For TC inputs: 0.25% of FS ±1°

For R & S inputs: 0.5% of F.S ± 2°

(20 min of warm up time for TC input)

For RTD inputs: 0.1% of FS ±1°

FUNCTIONAL SPECIFICATIONS**Control Method**

- 1) PID control with auto tuning
- 2) ON-OFF control

Proportional Band (P)

1 to 400°

Integral Time (I)

0.0 to 99.9 min

Derivative Time (D)

0 to 999 sec

Cycle Time

0.1 to 99.9 sec

Hysteresis Width

0.1 to 99.9°

Manual Reset Value

-19.9 to 19.9°

CONTROL OUTPUT (Relay or SSR user selectable)***Relay contact (SPST)** (For TC513A, TC221A, TC303A)

10 A @ 250V AC / 30V DC, resistive

Relay contact (SPDT) (For TC513AX, TC203AX, TC303AX)

10 A @ 250V AC / 30V DC, resistive

SSR Drive Output (Voltage Pulse)

12V DC, 50 mA

* Not applicable for TC513A, TC221A, TC303A

POWER SUPPLY**Supply Voltage**

85 to 270V AC/DC (AC: 50 or 60 Hz)

OPTIONAL - 24V AC/DC

Power Consumption

5 VA max @ 230V AC

Temperature

Operating: 0 to 50°C ; Storage: -20 to 75°C

Humidity (non-condensing)

95% RH

Weight

TC513A/TC513AX : 129 gms

TC221A/TC203AX : 180 gms

TC303A/TC303AX : 240 gms

SAFETY PRECAUTIONS

All safety related codifications, symbols and instructions that appear in this operating manual or on the equipment must be strictly followed to ensure the safety of the operating personnel as well as the instrument.

If the equipment is not handled in a manner specified by the manufacturer it might impair the protection provided by the equipment.

Read complete instructions prior to installation and operation of the unit.

WARNING: Risk of electric shock.

WIRING GUIDELINES

WARNING:

1. To prevent the risk of electric shock power supply to the equipment must be kept OFF while doing the wiring arrangement. Do not touch the terminals while power is being supplied.
2. To eliminate electromagnetic interference use short wire with adequate ratings; twists of the same in equal size shall be made. For the input and output signal lines, be sure to use shielded wires and keep them away from each other.
3. Cable used for connection to power source, must have a cross section of 1mm² or greater. These wires shall have insulation capacity made of at least 1.5kV.
4. When extending the thermocouple lead wires, always use thermocouple compensation wires for wiring. For the RTD type, use a wiring material with a small lead resistance (5Ω max per line) and no resistance differentials among three wires.
5. A better anti-noise effect can be expected by using standard power supply cable for the instrument.

MAINTENANCE

- 1 The equipment should be cleaned regularly to avoid blockage of ventilating parts.
2. Clean the equipment with a clean soft cloth . Do not use Isopropyl alcohol or any other cleaning agent.


INSTALLATION GUIDELINES

1. This equipment, being built-in-type, normally becomes a part of main control panel and in such case the terminals do not remain accessible to the end user after installation and internal wiring.
- 2 Do not allow pieces of metal, wire clippings, or fine metallic fillings from installation to enter the product or else it may lead to a safety hazard that may in turn endanger life or cause electrical shock to the operator.

3. Circuit breaker or mains switch must be installed between power source and supply terminals to facilitate power 'ON' or 'OFF' function. However this switch or breaker must be installed in a convenient position normally accessible to the operator.
4. Use and store the temperature controller within the specified ambient temperature and humidity ranges as mentioned in this manual.

CAUTION

1. When powering up for the first time, disconnect the output connections.
2. Fuse Protection: The unit is normally supplied without a power switch and fuses. Make wiring so that the fuse is placed between the mains power supply switch and the controller. (2 pole breaker fuse- rating: 275V AC, 1A for electrical circuitry is highly recommended)
3. Since this is a built-in-type equipment (finds place in main control panel), its output terminals get connected to host equipment. Such equipment shall also comply with basic EMI/EMC and other safety requirements like BSEN61326-1 and BSEN61010 respectively.
4. Thermal dissipation of equipment is met through ventilation holes provided on chassis of equipment. Such ventilation holes shall not be obstructed else it can lead to a safety hazard.
5. The output terminals shall be strictly loaded to the manufacturer specified values/range.

MECHANICAL INSTALLATION

MODELS	DIM	A	B	C	D	E	F	G
TC513A/TC513AX		52	52	94	45	4	46	46
TC221A/TC203AX		72	72	83.7	67	4.5	69	69
TC303A/TC303AX		96	96	73	90.5	5	92	92


1. Prepare the panel cutout with proper dimensions as shown above.
2. Remove the clamp from the controller and push the controller into the panel cutout. Insert the clamp from the rear side until the main unit is securely fit into the panel.
3. The equipment in its installed state must not come in close proximity to any heating sources, caustic vapors, oils, steam, or other unwanted process by-products.
4. Use the specified size of crimp terminals (M3.5 screws) to wire the terminal block. Tighten the screws on the terminal block using the tightening torque within the range of 1.2 N.m.
5. Do not connect anything to unused terminals.

EMC Guidelines:

1. Use proper input power cables with shortest connections and twisted type.
2. Layout of connecting cables shall be away from any internal EMI source.

LOAD CONNECTIONS


1. The service life of the output relays depends on the switching capacity and switching conditions. Consider the actual application conditions and use the product within the rated load and electrical service life.
2. Although the relay output is rated at 10 amps it is always necessary to use an interposing relay or contactor that will switch the load. This avoids damage to the controller in the event of a fault short developing on the power output circuit.
3. Always use a separate fused supply for the "power load circuit" and do not take this from the live and neutral terminals supplying power to the controller.

**ELECTRICAL PRECAUTIONS DURING USE**

Electrical noise generated by switching of inductive loads can create momentary disruption, erratic display, latch up, data loss or permanent damage to the instrument.


To reduce noise:

- a) Use of snubber circuits across loads as shown above, is recommended.
- b) Use separate shielded wires for inputs.

TERMINAL CONNECTIONS

Operating /1103/ TC513A / TC513AX / TC221A / TC203AX / TC303A
/ TC303AX / OP292-V04


TERMINAL CONNECTIONS




*NC contact valid only for TC203AX

Control Output

Relay Output




SSR Drive Output




Measured Value Input

Thermocouple (J, K, T, R, S)




Connect thermocouple sensor according to polarity shown.

RTD (Pt100)




For 2-wire RTD input short terminals 9 and 10.




*NC contact valid only for TC303AX

Control Output

Relay Output




SSR Drive Output




Measured Value Input

Thermocouple (J, K, T, R, S)



Connect thermocouple sensor according to polarity shown.

RTD (Pt100)




For 2-wire RTD input short terminals 11 and 12

WARNING: Please check the power supply voltage and controllers output type ordered (with reference to the order code) before installation.

Use only the correct thermocouple wire or compensating cable from the probe to instrument terminals avoiding joints in the cable if possible.
Failure to use the correct wire type will lead to inaccurate readings.
Ensure that the input sensor connected at the terminals and the input type set in the temperature controller configuration are the same.

FRONT PANEL DESCRIPTION



1	Process-value (PV) / Parameter name display	1) Displays a process value (PV). 2) Displays the parameter symbols at parameter setting mode for 1 sec and then parameter values. 3) Displays PV error conditions. (refer Table 2)
	Set-value (SV)	4) Displays a set value (SV) when key pressed.
2	Control output indication	The LED is lite when the control output is ON
3	Tune	Auto tune: Decimal point blinks with faster speed.

FRONT KEYS DESCRIPTION

Functions	Key press
Online	
To view Level 1	Press key for 3 seconds.
To view Level 2	Press key for 3 seconds.
To view Protection Level	Press + keys for 3 seconds.
To view and change setpoint value	Press to view the setpoint. Press + / key to change the setpoint.
Programming Mode	
To view parameters on the same level.	Or key once to view the next or previous function in operational menu.
To increase or decrease the value of a particular parameter.	+ to increase and + to decrease the function value. Note: Parameter value will not alter when respective level is locked.

NOTE: The unit will auto exit programming mode after 30 seconds of inactivity.

OR

By pressing the or or + keys for 3 sec.

USER GUIDE

1. Display Bias:

This function is used to adjust the PV value in cases where it is necessary for PV value to agree with another recorder or indicator, or when the sensor cannot be mounted in correct location.


2. Filter Time Constant

The input filter is used to filter out quick changes that occur to the process variable in a dynamic or quick responding application which causes erratic control. The digital filter also aids in controlling processes where the electrical noise affects the input signal. Larger the value of FTC entered, greater the filter added and the slower the controller reacts to the process and vice versa.

3. Auto tuning:

The Auto-tuning function automatically computes and sets the proportional band (P), integral time (I), Derivative time (D), ARW% and cycle time (CY.T) as per process characteristics.

- Decimal point of LSD flashes at faster speed while auto-tuning is being performed.
- At the completion of Auto-tuning, the decimal point stops blinking.




- If the power goes OFF before auto-tuning is completed, auto-tuning will be restarted at next power ON.
- If auto-tuning is not completed after 3-4 cycles, the auto-tuning is suspected to fail. In this case, check the wiring & parameters such as the control action, input type, etc.
- Carry out the auto-tuning again, if there is a change in set point or process parameters.

4. ON/OFF control action (For Reverse Mode):

The relay is 'ON' up to the set temperature and cuts 'OFF' above the set temperature. As the temperature of the system drops, the relay is switched 'ON' at a temperature slightly lower than the set point.


HYSTERESIS:

The difference between the temperature at which relay switches 'ON' and at which the relay switches 'OFF' is the hysteresis or dead band.



5. Manual Reset (for PID control & I=0):

After some time the process temperature settles at some point and there is a difference between the set temperature & the controlled temperature. This difference can be removed by setting the manual reset value equal & opposite to the offset.



CALIBRATION ACCURACY DECLARATION


Product is tested & calibrated by automatic technique. The calibration of this instrument is done as per following accuracy :

For TC inputs: 0.25% of FS $\pm 1^\circ$
For R & S inputs: 0.5% of F.S $\pm 2^\circ$
(20 min of warm up time for TC input)
For RTD inputs: 0.1% of FS $\pm 1^\circ$

Sources calibrated against:
Kusam-meco, model 405, Sr.No.:104446


Initial calibration is valid for 18 months after the Month/Year of manufacturing which is mentioned on order code label.

CONFIGURATION INSTRUCTIONS



OPERATIONAL MENU

POWER ON



REQUIRED PARAMETER SETTING IS SHOWN IN LEVEL 1
DISPLAY CONDITION COLUMN

Press key for 3 sec.

Press key for 3 sec.

Press + keys for 3 sec.

Level 1				
Display (For 1sec)	Description	Default Value	Range	Display Condition
Input	Input type (Refer Table 1)	J	J/K/T/R/S/RTD	RTD —
Unit	Temperature unit	°C	°C/°F	C —
SP.L	Set point low limit	-199	Min range of sensor selected to SP.H	00 —
SP.H	Set point high limit	150	SP.L to Max range of sensor selected	100 —
F.T.C	Filter time constant (Refer user guide)	1.0	0.2 to 10.0 sec	1.0 —
Control	Control action	RE	RE/FD	RE —
Logic	Control logic	PID	PID/ONF	ONF —
Anti reset	Anti reset windup%	25	1 to 100 %	For CNT=PID
Factory default	Factory default (Reset all)	NO	NO/YES	NO —

Level 2				
Display (For 1sec)	Description	Default Value	Range	Display Condition
Tune	Tune (Refer user guide)	OFF	OFF/ON	For CNT=PID
P	Proportional band	1.0	1 to 400°	For CNT=PID
I	Integral time	2.0	0.0 to 99.9 min	For CNT=PID
d	Derivative time	3.0	0 to 999 sec	For CNT=PID
Cycle time mode	Cycle time mode	AUT	AUT/US.F	For CNT=PID
Cycle time	Cycle time	15.0	0.1 to 99.9 sec	For CNT=PID
Hysteresis	Hysteresis	1.0	0.1 to 99.9°	For CNT=ONF
Manual reset	Manual reset (Refer user guide)	0.0	-19.9 to 19.9°	For CNT=PID & I=0
Display bias	Display bias (Refer user guide)	0.0	-19.9 to 19.9°	—

Protection Level				
Display (For 1sec)	Description	Default Value	Range	Display Condition
SP	Lock setpoint	UNL	UNK/LCK	—
LV1	Lock Level 1	UNL	UNK/LCK	—
LV2	Lock Level 2	UNL	UNK/LCK	—

Note

1. Locking parameters (LV1 or LV2 or SP) will not permit change in the value of respective level parameters.
2. Continuous operation of + keys for SP or other parameters makes Update speed faster in 3 stages after 3 seconds.

Programming Setpoint (Online):

Default: 50

To view setpoint: Press the key.

To increase/decrease setpoint: Press + keys.

INPUT RANGES (Table 1)

FOR RTD		
Input	°C	°F
Pt100	-150 to 850	-199 to 999

FOR THERMOCOUPLE

Input	°C	°F
J	-199 to 750	-199 to 999
K	-199 to 999	-199 to 999
T	-199 to 400	-199 to 750
R & S	0 to 999	32 to 999

ERROR DISPLAY (Table 2)

When an error has occurred, the display indicates error codes as given below.		
Error	Meaning	Control Output Status
5.b 7	Sensor break / Over range condition	OFF
5.7 E	Sensor reverse / Under range condition	OFF

Selec Controls Pvt. Ltd.

(Specifications are subject to change, since development is a continuous process)

Telephone: +91-22-40394200 / 40394202

Fax: +91-22-28471733

Toll free: 1800 227 353

Website: www.selec.com

Email: sales@selec.com

TECHNICAL SPECIFICATIONS**Barrel Transfer Pump**

Part No.	29 009 000 03
Output (Continuous duty)	21 Ltrs/Min
Output (Intermediate duty)	42 Ltrs/Min
Cycles per ltrs.	5
Cycle per Gal.	19
Pressure ratio	4.5:1
Stroke Length	120 mm
Air motor Piston ϕ	80mm
Air inlet pressure max	6 Bar



TECHNICAL SPECIFICATIONS**Barrel Transfer Pump**

Part No.	29 009 000 03
Output (Continuous duty)	21 Ltrs/Min
Output (Intermediate duty)	42 Ltrs/Min
Cycles per ltrs.	5
Cycle per Gal.	19
Pressure ratio	4.5:1
Stroke Length	120 mm
Air motor Piston ϕ	80mm
Air inlet pressure max	6 Bar



TECHNICAL SPECIFICATION

POLYUREA SPRAY SYSTEM - 2K/270/110X2

Type	2K/270/110x2
Mixing Ratio	1 :1
Transfer Ratio	55:1
Output Per Cycle	220 cc
Air motor Piston Ø	270 mm
Spray Volume @ 40 cycles/min	8.8 ltr/min
Air In Max	6 bar
Max. Pressure	330 bar
Air consumption N ltr @ 40 cycles/min	3850
Inline Heaters	7kw x 2nos.
Temperature Range	Up to 100° C
Power Supply	415 VAC-3 phase 50 Hz 5 wire R-Y-B-N-E copper flexible 6sq.mm x 5 core cable for incoming feeder



WARNING AND SAFETY INSTRUCTIONS

EQUIPMENT IS FOR PROFESSIONAL USE ONLY

⚠ WARNING



HIGH PRESSURE DEVICE FOR PROFESSIONAL USE ONLY

Read and understand instruction manual before use and maintenance. Observe on warnings.



Do not use spray materials containing reactive solvents with equipment containing aluminum, galvanized or zinc coated wetted parts. e.g. Dichloromethane and ethylene chloride can chemically react with aluminum and galvanized or zinc coated parts and cause explosion hazard.

⚠ WARNING



Do not process flammable, explosive, toxic or otherwise hazardous materials without first performing an appropriate hazard analysis.

VR Coatings cannot be an expert in the chemical and biological properties of the infinite number of materials that could be processed in this machine. As sold by VR Coatings, this machine is not designed to safely process hazardous materials unless additional precautions are not taken.

Before processing any material that are (or can react to become) flammable, explosive, toxic or otherwise hazardous, the user must perform a thorough hazard analysis and risk assessment of the entire process and determine the best way to deal with the hazard(s) identified, including contingency plans for dealing with processing errors and object conditions.



It is compulsory to

- know the product and possible hazards.
- store the product to be used in the appropriate areas.
- keep the product used during dispensing in a suitable container.
- Dispose the product according to the regulation of hazardous products in force in the country where the product is used.
- Wear protective equipment designed for that use.
- wear glasses, gloves, shoes clothes and mask for breath.

⚠ WARNING



SKIN INJECTION HAZARD. Protect hands and body from high-pressure fluids. Relieve pressure before disconnecting hydraulic or other lines and tighten all connections before applying pressure. In case of accidental skin injection, seek immediate "Surgical Treatment". Failure to follow this warning can result in amputation or serious injury.



- NEVER attempt to force the flow of fluid backward through the gun with your finger, hand or hand-held object against the gun nozzle.



- Before flushing system, always remove spray tip and adjust fluid pressure to lowest possible setting.



WARNING: The paint hose can develop leaks from wear, kinking, abuse etc. A leak is capable of injecting fluid into the skin; therefore the paint hose should be inspected before use. NEVER attempt to plug a hose with any part of your body, adhesive tape or any other makeshift device. Do not attempt to repair a spray hose. Instead, replace it with a new-grounded hose. You must see to it that the following points are followed for hoses, accessories or any other hardware:

- ☐ Comply with manufacturer's recommendations.
- ☐ Withstand the pressure ranges with correct safety factor.
- ☐ must not show any leaks, kinks, and sign of wear and should be factory fitted and pressure tested.

An air pressure safety valve forms an integral part of the air motor or air regulator and must not be altered or tampered with.

▲ WARNING



COMPONENT RUPTURE The system is capable of producing high pressure all components in the system must have a maximum working pressure capacity, not less than the pressure rating of the pump.

SERVICING Before servicing, cleaning or removing any part, always shut off power source, carefully release pressure in fluid portions of the system and set safety locks on guns and equipment

▲ WARNING



High velocity flow of material through equipment may create static electricity. All equipment being sprayed must be properly grounded to prevent sparking, which may cause fire or explosion.



Due to static electricity potential generated by the high velocity of fluid through the pump, hose and tip, sparking may occur and the system may be hazardous. This can result in an explosion and/or fire, if every part of the spray equipment is not properly grounded. Be sure that both the object being sprayed and the airless equipment are grounded.

This can be done by attaching a static wire to water piping or building structural members known to be earthen. If the hose does not contain a static electricity conductor, a static wire must be attached from the spray gun to the earth.

⚠ CAUTION



Before any adjustment, inspection, maintenance, cleaning, removing work always shut off the power source, carefully release pressure in fluid of the system and set safety locks on guns.

⚠ CAUTION



FLUSHING/CLEANING

Always flush the unit into a separate metal container with the spray tip removed and the gun held firmly against the side of container to assure proper grounding and prevent static discharge, which could cause serious bodily injury.

⚠ CAUTION



FINGURE OR HANDS PINCH HAZARD. KEEP HANDS CLEAR OF MOVING PARTS COUPLING AND PISTONS

Before servicing/removing any part always shut off power source and release pressure in fluid portions of the system.

WARNING AND SAFETY INSTRUCTIONS

EQUIPMENT IS FOR PROFESSIONAL USE ONLY

⚠ WARNING



HIGH PRESSURE DEVICE FOR PROFESSIONAL USE ONLY

Read and understand instruction manual before use and maintenance. Observe on warnings.



Do not use spray materials containing reactive solvents with equipment containing aluminum, galvanized or zinc coated wetted parts. e.g. Dichloromethane and ethylene chloride can chemically react with aluminum and galvanized or zinc coated parts and cause explosion hazard.

⚠ WARNING



Do not process flammable, explosive, toxic or otherwise hazardous materials without first performing an appropriate hazard analysis.

VR Coatings cannot be an expert in the chemical and biological properties of the infinite number of materials that could be processed in this machine. As sold by VR Coatings, this machine is not designed to safely process hazardous materials unless additional precautions are not taken.

Before processing any material that are (or can react to become) flammable, explosive, toxic or otherwise hazardous, the user must perform a thorough hazard analysis and risk assessment of the entire process and determine the best way to deal with the hazard(s) identified, including contingency plans for dealing with processing errors and object conditions.



It is compulsory to

- know the product and possible hazards.
- store the product to be used in the appropriate areas.
- keep the product used during dispensing in a suitable container.
- Dispose the product according to the regulation of hazardous products in force in the country where the product is used.
- Wear protective equipment designed for that use.
- wear glasses, gloves, shoes clothes and mask for breath.

⚠ WARNING



SKIN INJECTION HAZARD. Protect hands and body from high-pressure fluids. Relieve pressure before disconnecting hydraulic or other lines and tighten all connections before applying pressure. In case of accidental skin injection, seek immediate" Surgical Treatment". Failure to follow this warning can result in amputation or serious injury.



- NEVER attempt to force the flow of fluid backward through the gun with your finger, hand or hand-held object against the gun nozzle.



- Before flushing system, always remove spray tip and adjust fluid pressure to lowest possible setting.



WARNING: The paint hose can develop leaks from wear, kinking, abuse etc. A leak is capable of injecting fluid into the skin; therefore the paint hose should be inspected before use. NEVER attempt to plug a hose with any part of your body, adhesive tape or any other makeshift device. Do not attempt to repair a spray hose. Instead, replace it with a new-grounded hose. You must see to it that the following points are followed for hoses, accessories or any other hardware:

- ☐ Comply with manufacturer's recommendations.
- ☐ Withstand the pressure ranges with correct safety factor.
- ☐ must not show any leaks, kinks, and sign of wear and should be factory fitted and pressure tested.

An air pressure safety valve forms an integral part of the air motor or air regulator and must not be altered or tampered with.

▲ WARNING



COMPONENT RUPTURE The system is capable of producing high pressure all components in the system must have a maximum working pressure capacity, not less than the pressure rating of the pump.

SERVICING Before servicing, cleaning or removing any part, always shut off power source, carefully release pressure in fluid portions of the system and set safety locks on guns and equipment

▲ WARNING



High velocity flow of material through equipment may create static electricity. All equipment being sprayed must be properly grounded to prevent sparking, which may cause fire or explosion.



Due to static electricity potential generated by the high velocity of fluid through the pump, hose and tip, sparking may occur and the system may be hazardous. This can result in an explosion and/or fire, if every part of the spray equipment is not properly grounded. Be sure that both the object being sprayed and the airless equipment are grounded.

This can be done by attaching a static wire to water piping or building structural members known to be earthen. If the hose does not contain a static electricity conductor, a static wire must be attached from the spray gun to the earth.

⚠ CAUTION



Before any adjustment, inspection, maintenance, cleaning, removing work always shut off the power source, carefully release pressure in fluid of the system and set safety locks on guns.

⚠ CAUTION



FLUSHING/CLEANING

Always flush the unit into a separate metal container with the spray tip removed and the gun held firmly against the side of container to assure proper grounding and prevent static discharge, which could cause serious bodily injury.

⚠ CAUTION



FINGURE OR HANDS PINCH HAZARD. KEEP HANDS CLEAR OF MOVING PARTS COUPLING AND PISTONS

Before servicing/removing any part always shut off power source and release pressure in fluid portions of the system.

WARNING AND SAFETY INSTRUCTIONS

EQUIPMENT IS FOR PROFESSIONAL USE ONLY

⚠ WARNING



HIGH PRESSURE DEVICE FOR PROFESSIONAL USE ONLY

Read and understand instruction manual before use and maintenance. Observe on warnings.



Do not use spray materials containing reactive solvents with equipment containing aluminum, galvanized or zinc coated wetted parts. e.g. Dichloromethane and ethylene chloride can chemically react with aluminum and galvanized or zinc coated parts and cause explosion hazard.

⚠ WARNING



Do not process flammable, explosive, toxic or otherwise hazardous materials without first performing an appropriate hazard analysis.

VR Coatings cannot be an expert in the chemical and biological properties of the infinite number of materials that could be processed in this machine. As sold by VR Coatings, this machine is not designed to safely process hazardous materials unless additional precautions are not taken.

Before processing any material that are(or can react to become) flammable, explosive, toxic or otherwise hazardous, the user must perform a thorough hazard analysis and risk assessment of the entire process and determine the best way to deal with the hazard(s) identified, including contingency plans for dealing with processing errors and object conditions.



It is compulsory to

- know the product and possible hazards.
- store the product to be used in the appropriate areas.
- keep the product used during dispensing in a suitable container.
- Dispose the product according to the regulation of hazardous products in force in the country where the product is used.
- Wore protective equipment designed for that use.
- wore glasses, gloves, shoes clothes and mask for breath.

⚠ WARNING



SKIN INJECTION HAZARD. Protect hands and body from high pressure fluids. Relieve pressure before disconnecting hydraulic or other lines and tighten all connections before applying pressure. In case of accidental skin injection, seek immediate” Surgical Treatment”. Failure to follow this warning can result in amputation or serious injury.




An airless spray gun requires that fluid be introduced to it at very high pressure. Fluids under high pressure, from spray or leaks, can penetrate the skin and inject substantial quantities of toxic fluid into the body. If not promptly and properly treated, the injury can cause tissue death or gangrene and may result in serious, permanent disability or amputation of the wounded part. Therefore extreme caution must be exercised when using any airless spray equipment.

IF YOU ARE INJECTED, SEE A PHYSICIAN IMMEDIATELY. DO NOT TREAT AS A SIMPLE CUT!

NOTE TO PHYSICIAN:

Injection into the skin is a serious, traumatic injury. It is important to treat the injury surgically as soon as possible. Do not delay treatment to research toxicity. Toxicity is concerned with some exotic coatings injected directly in to the bloodstream. Consultation with a plastic surgeon or a reconstructive hand surgeon may be advised





- NEVER attempt to force the flow of fluid backward through the gun with your finger, hand or hand-held object against the gun nozzle.



- Before flushing system, always remove spray tip and adjust fluid pressure to lowest possible setting.



WARNING: The paint hose can develop leaks from wear, kinking, abuse etc. A leak is capable of injecting fluid into the skin; therefore the paint hose should be inspected before use. NEVER attempt to plug a hose with any part of your body, adhesive tape or any other makeshift device. Do not attempt to repair a spray hose. Instead, replace it with a new grounded hose. You must see to it that the following points are followed for hoses, accessories or any other hardware :

- ☐ Comply with manufacturer's recommendations.
 - ☐ Withstand the pressure ranges with correct safety factor.
 - ☐ Must not show any leaks, kinks, sign of wear and should be factory fitted and pressure tested.
- An air pressure safety valve forms an integral part of the air motor or air regulator and must not be altered or tampered with.



⚠ WARNING

COMPONENT RUPTURE The system is capable of producing high pressure all components in the system must have a maximum working pressure capacity, not less than the pressure rating of the pump.

SERVICING Before servicing, cleaning or removing any part, always shut off power source, carefully release pressure in fluid portions of the system and set safety locks on guns and equipment

**PRESSURE RELEASE PROCEDURE**

A Set trigger safely in a locked position.

B Shut off pump(Close main air supply valve and back-off air regulator).

C Release fluid pressure from entire system (Open drain valve) and trigger gun.

D Reset trigger safely in a locked position.

⚠ WARNING

High velocity flow of material through equipment may create static electricity. All equipment being sprayed must be properly grounded to prevent sparking, which may cause fire or explosion.



Due to static electricity potential generated by the high velocity of fluid through the pump, hose and tip, sparking may occur and the system may be hazardous. This can result in an explosion and/or fire, if every part of the spray equipment is not properly grounded. Be sure that both the object being sprayed and the airless equipment are grounded.

This can be done by attaching a static wire to water piping or building structural members known to be earthen. If the hose does not contain a static electricity conductor, a static wire must be attached from the spray gun to the earth.

⚠ CAUTION

Before any adjustment, inspection, maintenance, cleaning, removing work always shut off the power source, carefully release pressure in fluid of the system and set safety locks on guns.



ALWAYS follow the coating or solvent manufacturer's safety precautions and warnings. Never spray flammable material near open flames, pilot lights or any other source of ignition.



If you experience any static sparking or slight shock while using the equipment, stop spraying immediately. Check the entire system for proper grounding. Do not use the system again until the problem has been corrected.

Follow material supplier's instructions carefully and ensure adequate ventilation of working area to prevent health hazards.

⚠ CAUTION**FLUSHING/CLEANING**

Always flush the unit into a separate metal container with the spray tip removed and the gun held firmly against the side of container to assure proper grounding and prevent static discharge, which could cause serious bodily injury.

⚠ CAUTION

FINGURE OR HANDS PINCH HAZARD. KEEP HANDS CLEAR OF MOVING PARTS COUPLING AND PISTONS

Before servicing/removing any part always shut off power source and release pressure in fluid portions of the system.

⚠ CAUTION

DO NOT START PUMP IF GUARD IS NOT AT “UP” POSITION.


TO SET “UP” POSITION-hold by hands push upward till it locks in ball catch.

TO SET “DOWN” POSITION-Push downward.

FINGURE OR HANDS PINCH HAZARD.KEEP HANDS CLEAR. Before servicing/removing any part always shut off power source and release pressure in fluid portions of the system.

OPERATING INSTRUCTIONS

GENERAL DESCRIPTION:



Pneumatic piston Pumps are made for spraying, Dispensing, and transferring of various types of liquid/semi solid. These pumps are mainly used for airless/air assisted spraying of coating materials and dispensing /transferring of paints, oil, ink, sealants adhesives, wax, grease, solvents etc. and incorporate the following essential parts:

Airless Pump : Pneumatic motor with Control Unit, Hydraulic parts, Suction device, mounting plate ,etc.

Accessories: HP (High Pressure) hose, HP Filter, Trolley, Spray gun, Spray nozzle, etc.

Optional : Circulating unit, special accessories depending on applications.

The various pump versions are identified as follows:

e.g.: TIGER 30.150

Double stroke Volume in CC (150)

The above is intended to obtain the following data: s

Material Pressure : Pressure Input x Transmission Ratio

Displaced Volume : Double Stroke Volume x No. Of double stroke/ min. E.g. 50 double strokes/min.)

The pump works double acting and self-priming and serves to transfer the spray material to the spray gun by making it pass through a filter and a high pressure hose. Its differential piston, which is located in the hydraulic portion of the pump, moves upwards and downwards in the working cylinder (1 cycle = 1 double stroke = 1 upward and 1 downward stroke). The displacement piston features a layer of hard chrome of about 200 microns to protect against wear. The suction and delivery ball valve feature tungsten carbide seat.

The pump is equipped with an oil cup containing a solvent, which is intended to lubricate the piston and to prevent paint residues from incrustation. The packing need to be readjusted manually by tightening the upper packing take up nut which is designed as oil cup.

The actual spray performance depends on both spray nozzle size and selected spray pressure; increased material flow results in both spray nozzle size and air consumption.



Make sure that pump does not work too fast and / or too long when idling in order to prevent damage to sealing and valves.

All airless spraying units are equipped with capacity sieving filters. There are different mesh sizes to match according to the airless nozzle. Please see **Nozzle Chart** for appropriate type of nozzle.

In case of high delivery transfer pumps separate filters cartridge type or bag type can be used. Filter size depends upon the fluid, which is handled, and application requirements.

TWO COMPONENT HOT AIRLESS SPRAY EQUIPMENT -

Two Component Spray Equipment are used where curing time is very fast ranging from few seconds to several minutes and spraying through standard airless pump is not possible.

For High Performance Protective Coatings which are solvent free and fast curing Two Components Epoxy or PU Coating tar modified or tar free, Two Component Hot Airless Spraying Equipment is a must.

TWO COMPONENT HOT AIRLESS EQUIPMENT CONSIST OF -

1. Plural Component High Pressure Pump
2. Mixing Block
3. Mixers – Static / Dynamic
4. Flush Pump
5. Heating System
6. Feed pump and supply system
7. Monitoring and control system
8. Spray Guns

1. PLURAL COMPONENT HIGH PRESSURE PUMP

This is the core part of Two Component System. It is like a standard Airless Spray Equipment except two or three hydraulic cylinders driven by single common Air Motor.

2. MIXING BLOCK / MANIFOLD

Both the components that are individually metered and delivered by Two Component Pump are mixed in this Mixing Block incorporated with numbers of Non Return Valves. Return Line from the Mixing Block goes back to the tank in case of circulated system.

3. MIXERS

When fluids are pumped through mixer they are progressively divided and recombined to get mixed. Diameter and length of the mixer depends upon material specifications.

4. FLUSH PUMP

This is the standard Airless High Pressure Pump with pressure ratio ranging from 40:1 to 60:1 and output per cycle from 70 to 110cc used in Two Component Systems to rinse the whole system. Selection of flush pump depends on material to be flushed and hose lengths.

5. HEATED SYSTEM

This may consist of inline fluid heaters, heated supply containers, heated hoses. VR Coatings offers high pressure inline fluid heaters to heat each individual component to the required temperature. Oil heated Jacketed Containers up to 200 ltr. capacity is also offered by VR Coatings to preheat the component individually as per material specification. It has power up to 12KW and temperature range up to 100°C. This is controlled and monitored by PID based Control Panel.

For long hose lengths materials which have to be sprayed at high temperature, the spray hoses must be heated / insulated. VR Coatings offers hot water system to heat the hose and also provide electrical heated hose. In some cases insulated hose can

be used instead of heated hose again depending on application, material specification and ambient temperature.

6. FEED PUMP AND SUPPLY SYSTEM

Feeding pumps are used to feed the component from supply tank to Two Component pump. VR Coatings offers various feed pumps from its standard transfer pump range depending on the material specifications.

Separate feed pumps can be used to transfer material from supplier's drum to supply containers of Two Component System. Drumpress with Hoisting Unit can be used for transferring high viscous materials.

Agitators may also be used depending upon the application and type of the material. VR Coatings offers electrical driven high torque agitator for viscous material. Pneumatic agitators are also available where torque requirement is less.

7. MONITORING AND CONTROL SYSTEM

The monitoring system is required for safeguarding against incorrect mixing ratio for Two Component System. When pressure exceeds or drops surpassing the tolerance setting that are set by operator, while spraying the system automatically shut downs. When there is malfunctioning in the system and is manifested by surpassing set limits the system automatically switches off. These malfunctions may be because of internal / external leakage's, material deficiency, damaged seal etc. Automatic 'switching off' of the system prevents incorrect mixing ratio and reworks.

8. SPRAY GUNS

Trigger operated and insulated handle spray guns are used to apply coatings manually. For automatic spraying pneumatically operated automatic guns are used.

OTHER ACCESSORIES

A flexible HP hose serves as connection between pump and spray gun. Its inside wall consists of either Nylon or Teflon; it also contains an electrical conductor in order to permit electrostatic charges to discharge through the grounded pump.

WARNING



COMPONENT RUPTURE The system is capable of producing high pressure, all components in the system must have a maximum working pressure capacity not less than the pressure rating of the pump.

A large number of different nozzles are available. See **Nozzle Chart**.

MOUNTING OF ANY AIRLESS PUMP

Any pumping unit should be installed in a way to make it easily accessible for cleaning and maintenance purposes.



In the case of wall mounting, assure that pump is vertically installed and fastened by using the holes on the mounting plate.

All pumps are equipped with a grounding point. It is compulsory that the ground lead be connected to this point.

WARNING



High velocity flow of material through equipment may create static electricity. All equipment being sprayed must be properly grounded to prevent sparking, which may cause a fire or explosion.

Make sure that sufficient compressed air is available when connecting the pump to the air supply net.

Insure inside diameter of the connection tube between compressed air delivery point and airless unit is sufficient for required capacity.

COMMISSIONING AND OPERATING

1. General Information

Present pump is suitable for any kind of coatings/ material such as primers, basic coats, lacquers, dispersion paints, caustics, bituminous mastics etc.,

Depending on their physical and chemical characteristics, other types of spray media can be used e.g. cements, fillers, deadening agents and so forth.

Two component paints, PU material, PES material, acid hardening material or other media containing filler such as asbestos, ground cork and silicates require special attention prior to use.

We do not recommend the application of coarse bodied or abrasive fluids using the airless method. These would include sand filled wall coatings, coatings with coarse fibrous, various types of adhesives.

WARNING



Do not process flammable, explosive, toxic or otherwise hazardous materials without first performing an appropriate hazard analysis.

It is compulsory to


- know the product and possible hazards.**
- store the product to be used in the appropriate areas.**
- keep the product used during dispensing in a suitable container.**
- Dispose the product according to the regulation of hazardous products in force in the country where the product is used.**
- Wear protective equipment designed for that use.**
- wear glasses, gloves, shoes clothes and mask for breath.**

2. In case of doubt, please contact for correct equipment recommendations.

Setting up

- Hold oil cup/coupling guard by hand and push downwards in versions provided with this type of guard.
- Check for top lubricant to maximum level in pump lubrication chamber or oil-cup or packing take-up nut.
- Lift oilcup guard in upward direction till it locks in ball catch.

⚠ CAUTION



FINGURE OR HANDS PINCH HAZARD. KEEP HANDS CLEAR. Before servicing/removing any part always shut off power source and release pressure in fluid portions of the system.
Ensure coupling guard is always at UP position while pump is working.

- Check high-pressure filter screen element. Mesh opening should be smaller than bore tip size used.
- The Table below should be used as a guideline only. We suggest that you do not use any filter element when spraying materials containing fibrous.

Mesh size an element marking (opening)	Tip size	Coating material to be sprayed
M 200 (0.084 mm/ 0.0033")	< 0.3 mm 0.011"	Clear lacquer, varnishes, and hammer tone.
M 150 (0.6 mm/0.0039")	>0.3 mm 0.011"	Primer, filler, red oxide.
M 100 (0.25 mm/0.0057)	>0.3 mm 0.011"	Primer, filler, red oxide.
M 70 (0.250 mm/0.0098")	>0.5 mm 0.016"	Iron mica, red oxide.
M 50 (0.320 mm/0.0125")	>0.6 mm 0.023"	Latex paint, bodied coatings.

- Connect high-pressure fluid hose and gun and connect air supply to air regulator.

⚠ CAUTION



Have Trigger Lock engaged at all times when not spraying/in use.

Grounding

Connect the other end of the grounding wire provided on machine to the earth ground. Always use electrically conductive hoses.

Flushing Of Complete Two Component System.

The unit has been factory tested using an oil emulsion. To avoid contamination of the coating material to be sprayed, be sure the emulsion is flushed from the system before spray operation begins by using a compatible solvent.

Do as follows:

- Close main air supply valve and back-off all air regulators.
- Close drain valve located at high-pressure filter at outlet manifold..
- Insert suction hose and tube or fluid end into compatible solvent.
- Place drain hoses from drain valves into container, open both drain Valves, if system having return lines open return line valves instead of drain valves and put line ends in container

Note: If system is already loaded with both components then take two separate containers to collect drain.

- Open main air supply valve and slowly open-air regulators to max. 2 bar (30 psi) of feed pumps. open air regulator of main plural component pump to max 2 bar.

Note: Pump cycles slowly and circulates fluid via drain hose or return line back into the container.

- Close Drain valves/return line valves. Point gun into container ensuring contact between gun and metal container-then trigger the gun.

Note: The pump will cycle slowly and circulate fluid via gun back into the container.

- Close gun and increase air regulator setting of two component pump to maximum pressure allowed. Check all connections for leaks.

Note: Maximum fluid pressure will vary according to the model of pump selected.

- Close main air supply valve and back-off air regulator.



- Open drain valves / return line valves relieve system pressure completely. Finally trigger the gun again shortly to ensure that there is no pressure retained in the fluid hose

⚠ CAUTION



CAUTION : drain valves, return valves, supply valves shall be always closed or opened simultaneously of both components: otherwise system will unbalance and raise high pressure In one line.

- Remove suction hose and tube or fluid end from solvent container, wipe clean . Point gun into the container, ensuring good contact with the container Trigger the Gun .Slowly open air regulators to max. 2 bar (30 psi) of feed pumps. open air regulator of main plural component pump to max 2 bar .Remove complete solvent via gun and return lines

⚠ CAUTION



FLUSHING/CLEANING

Always flush the unit into a separate metal container with the spray tip removed and the gun held firmly against the side of container to assure proper grounding and prevent static discharge which could cause serious bodily injury.

MATERIAL LOADING AND OPERATING.

- Take individual components to be mixed and sprayed in respective feed containers, manually or by separate transfer pumps or (if material is highly viscous) may be by drum press unit.
- Close Drain valves on filters at outlet manifold.
- Open return line valves. Increase feed pumps air pressure gradually till material flows properly. Collect return material in separate containers instead of main feed tank till its solvent free.
- Start flushing pump loaded with compatible solvent and keeps pressurized for immediate flushing of mixed material whenever required.
- Before opening supply valves, open flush valve and flush for few seconds. Close flushing Valve. Close return line valves and

- open supply line valves and Trigger the spray gun. Take mixed material in a separate container and increase pressure till you get proper mixing and atomization. Insure the pressures on the pressure gauges are stable before applying on substrate.

NOTE :

- There is pressure difference in upward and downward stroke due to use of feed pumps. As well as difference in both component pressures because of typical and efficient mixing block design.
- Set upper and lower pressure limits on either the gauges or pressure controllers provided for monitoring.
- Upper pressure limit shall be about 20 bar more than the stall pressure and lower limit shall be below about 20 bar than lowest working/spraying pressure. These parameters can be varied depending upon material specifications and application.



NOTE: Do not stop while spraying when pot life is very short. If you Stop, immediately close supply lines open return lines and flush the mixed material.

- Start monitoring system by switching on the monitoring switch on the control panel.
- Automatic switching off closes supply valves, opens return lines and flush valve and fault indication lamp will glow. Operator has to immediately flush the mixed material. Switch off monitoring. Identify and rectify the problem and start the system again as mentioned above.

OPERATING REMOTE PNEUMATIC CONTROLS.


- Refer circuit diagram of pneumatic control panel.
- To switch on supply valves and to switch off return line valves or vice versa. Operated hand lever of 3/2 way DC valve as shown in figure on Pneumatic Panel.
- To switch on flushing operate hand lever of 3/2 way DC valve as shown in figure. Flushing valve will only operate when supply line valves are closed and return line valves are open.



NOTE : Immediately flush the mixed material when you STOP Spraying

TROUBLE SHOOTING CHART RELATED TO MIXING.

PROBLEM	CAUSE	SOLUTION
Mixing ratio incorrect	Return line valve leaking	Check and clean valve seats, if worn out replace.
		Insure sufficient air pressure to valves.
		Check pneumatic circuit.
	External leakages through joints	Tighten the joints. Replace worn out sealings
	Hydraulic Part valve seat leakages	Remove and clean valve seats.
	Feeding Container empty	Refill the container
Solvent is mixing in sprayed material.	Flushing valve leaking	Check and clean valve seats. Replace if there are worn out parts. Check & clean non return valves in mixing block.
Spray pressure is low at high air inlet pressure	Choking in fluid line filters	Check filters. Clean the filter and replace element if necessary.
	Choking in hoses	Replace choked hoses.
	Choking in mixing block	Clean the mixing block and service it.
	Choking in Static Mixer	Clean or replace.
	Required material temperature not achieved	Circulate the heated material till required temperature reaches .
		Check whether any heating element is failed. Correct it or replace.
Mixed Material is not flushing out	Hardened material in the mixing block or in the static mixer or in the hose and gun	Clean the mixing block with compatible solvent; service it as necessary. Clean static mixer, gun and hose. Replace hose if cleaning not possible.
	Solvent pump pressure is low	Increase pump air pressure
	Flushing valve not opening fully	Insure sufficient air pressure to valve.
	Solvent container empty	Refill the solvent supply.
	The solvent is not compatible with the material	Change to a compatible solvent



PRESSURE RELEASE PROCEDURE

- A Set trigger safely in a locked position.
- B Shut off pump(Close main air supply valve and back-off air regulator).
- C Release fluid pressure from entire system
Open drain valve and trigger gun.
- D Reset trigger safely in a locked position.

Spray Pattern Control

CAUTION



Have Gun **Trigger Lock** engaged at all times when not actually spraying.

When installing **spray tip** be sure that **Gasket** is correctly used between gun tip and spray tip. With Gun in the “**Open**”(triggered) position, increase the air regulator setting until the correct spray pattern is achieved.



Note: Use the lowest air pressure possible that will give proper fluid atomization and spray pattern. Excessive or higher pressures show no improved result, but will cause reduced system component life, and will waste material.

POST-OPERATIONAL HANDLING:

Actuate gun in order to evacuate pressure from pump. Remove nozzle and clean it.

Lacquer may remain in the pump up to 48 hours. This should however be avoided when using two component materials or any other material liable to self-cure quickly.

Incase of protracted downtimes, evacuate pump, refill with solvent and leave as such. Clean HP filter if necessary.

- **Shut Down Procedure**

Flush the mixed material, shut-off flush valve. Actuate gun in order to evacuate pressure from pump. Follow Procedure as listed under “**Flushing**”, however use regular **Recommended lubricating oil** without additives instead of solvent, if the pump is to be put into storage.

Back-off (relief) air regulator completely.

Close main airs supply valve.

MAINTENANCE:

- Daily - if compressed air is wet - drain oil and water separator with pressure on and blow out water at least twice daily.
- Check fog oiler for correct adjustment (droplet metering) and oil s level. Refill if required.

Note: Severe operating conditions may cause frosting of Air motor. To prevent, fill fog oiler with mixture of 50:50 regular Recommended lubricating oil and Glycol.

- Check or top-up level of lubricant in pump packing take-up nut.
Note: Change lubricant every 50 hours of operation, earlier in oil cup pumps. Discoloration of lubricant indicates packing wear or failure. This will affect pump performance. If necessary, renew upper packing set.
- Clean and inspect filter elements in filter screen housing and high-pressure filter at least daily, based on quality of product to be sprayed.
- Do not kink or bend high-pressure fluid hose to less than four-inch radius.
- Loosen threaded connections or hose couplings of the unit or system only when essential. This will help prevent hardened materials getting into the system, which could malfunction.



- Displacement piston in lowest (DOWN) position at all times to prevent material from hardening on the fluid piston or rod.

TECHNICAL SPECIFICATIONS

Name	Type	Ratio	Output/cycle(cc)	Air motor piston ϕ mm	Stroke length mm	Approximate Weight (kg)	Recommended spray volume/minute (lt.)	Air inlet pressure Max (bar)	Output Pressure Max. (bar)	Air consumption N lt./ min. Max.
<u>TIGER</u>	30.70	30:1	70	110	120	19	3.5	8	240	900
	40.110	40:1	110	160	120	24	5.5	8	320	1900
	12.150	12:1	150	110	120	22	7.5	6	72	900
	28.20	28:1	20	80	70	15	2	6	168	450
	30.150	30:1	150	160	120	23	6	8	240	1900
	28.40	28:1	40	80/110	120/70	17	2	6	168	450
	60.70	60:1	70	160	120	21	3.5	6	360	1400
	16.70	16:1	70	80	120	17	3.5	8	128	450
	12.150	12:1	150	110	120	24	7.5	6	720	900
<u>RHINO</u>	45.210	45:1	210	230	120	62	5.5	6	270	3000
	60.150	60:1	150	230	120		6	6	360	3000
	30.275	30:1	275	230	120	62	10	6	280	3000
	45.275	45:1	275	270	120	70	7.5	6	270	4000
	60.210	60:1	210	210	120	70	5.5	6	360	3000
	55.275	55:1	275	300	120	67	7.5	6	330	5000
	75.210	75:1	210	300	120	67	5.5	6	450	5000
<u>HIPPO</u>	4.90	4:1	90	60	70	8	1.8	6	24	100
	2.900	2:1	900	110	120	28	30	6	12	480
	5.900	5:1	900	160	120	30	30	6	30	4000
	3.400	3:1	400	080	120	22	15	6	18	300
<u>ELEPHANT</u>	04.2000	4:1	2000	230	120	78	40	6	24	1200
	04.3400	4:1	3400	230	200		70	6	24	2000
	02.4000	2:1	4000	230	120	105	80	6	12	1200
	02.6500	2:1	6500	230	200	110	130	6	12	2000

CHEETAH

Type	2k -350 / 79X79X150	2k -350 / 110x110x110	2k -350 / 110x110x79	2k -350 / 110x110x58	2k -350 / 150x150x32
Mixing Ratio *	1:1	2:1	3:1	4:1	10:1
Transfer Ratio *	70:1	65:1	70:1	75:1	60:1
Output per Cycle	300 cc	340 cc	300 cc	280 cc	332 cc
Air Motor Piston	350 mm	350 mm	350 mm	350 mm	350 mm
Stroke Length	120 mm	120 mm	120 mm	120 mm	120 mm
Recommended Spray Vol/Min	7.5 ltr.	8.5 ltr.	7.5 ltr.	7 ltr.	8 ltr.
Air Inlet Pressure Max.	6 bar	6 bar	6 bar	6 bar	6 bar
Output Pressure Max.	420 bar	390 bar	420 bar	450 bar	360 bar
Air Consumption N ltr./min Max.	6800	6800	6800	6800	6800

*Other ratios on request



TROUBLE SHOOTING

MALFUNCTION	Pump does not start/stops during operation	Pump does not suck or only insufficiently	Spray pressure too low	Pump operates irregularly	Pump operates although spray gun is closed	Pump transports material into the rinsing agent	Regulator frozen
AIMOTOR	Press sensing valve provided on control block Clean regulator, replace defective parts if necessary			Clean regulator, replace defective parts if necessary			Compressed air too moist, stroke frequency too high, ambient temperature too low.
HYDRAULIC PART		Not sufficiently ventilated, loose suction connection		Not sufficiently ventilated, loose suction connection	Not sufficiently ventilated, loose suction connection		
SUCTION AND TRANSFER VALVE		Worn or blocked, replace defective parts		Worn or blocked, replace defective parts	Replace worn or defective parts		
PACKINGS		Leaking piston and packing		Leaking piston and packing		Leaking packing	
FILTER	Filter mesh blocked, check where and clean out	Filter mesh blocked, check where and clean out	Filter mesh blocked, check where and clean out		Drain valve open.		
COMPRESSED AIR LINE	Volume flow too low, air pressure too low.		Volume flow too low, air pressure too low.				
PRESSURE REGULATOR VALVE (AIR)	Air pressure too low		Air pressure too low				
SUCTION SET		Filter mesh blocked		Filter mesh blocked	Filter mesh blocked		
MATERIAL HOSE	Blocked, check where and clean out	Blocked, check where and clean out	Blocked, check where and clean out				
ATOMIZER	Orifice of spray cap blocked		Orifice spray too large				
MATERIAL BEING USED	Viscosity too high						

INDEX

DECLARATION OF CONFIRMITY	1
SAFETY LABELS	2
WARNING AND SAFETY INSTRUCTIONS	3
OPERATING INSTRUCTIONS	9
TROUBLESHOOTING	22
TECHNICAL SPECIFICATIONS	21
DRAWINGS AND PARTLISTS	
NOTES	24
WARRANTY	25



WARRANTY

VR Coatings warrants all equipments manufactured by us, as long as it is bearing original identification plate, to be free from defects in material and workmanship for a period of one year from ex-works date. VR Coatings will repair or replace any part of the equipment proven defective. The warranty applies only when the equipment is installed, operated and maintained in accordance with VR Coatings written recommendations.

Warranty claims found to be defective shall be verified and confirmed by VR Coatings.

Our warranty does not cover and VR Coatings shall not be liable for any malfunction, damages, or fair wear and tear caused by faulty installation, misuse, abrasion, corrosion, inadequate or improper maintenance, negligence, tempering, accident or incorporation of non VR Coatings parts, non observance of VR Coatings recommendations.

This warranty only consists of replacing the parts returned to our plant prepaid transportation and proven defective by us. If inspection of the equipment /part does not discloses any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may includes the cost of parts, labor and transportation. VR Coatings shall not be liable for any losses resulting from a production breakdown.

Material bought in equipment, which is sold but not manufactured by VR Coatings, will be subject to the manufacturer's warranty. VR Coatings will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

Date of sales

[illegible]

SAFETY LABELS AND NAMEPLATE



Label on pump

label no.W.01




Label on pump provided with coupling guard Label no.W.02



Label on pump provided without coupling guard Label no.W.03

Safety labels free of charge on request



Name Plate



WARNING AND SAFETY INSTRUCTIONS

EQUIPMENT IS FOR PROFESSIONAL USE ONLY

⚠ WARNING**HIGH PRESSURE DEVICE FOR PROFESSIONAL USE ONLY**

Read and understand instruction manual before use and maintenance. Observe on warnings.



Do not use spray materials containing reactive solvents with equipment containing aluminum, galvanized or zinc coated wetted parts. e.g. Dichloromethane and ethylene chloride can chemically react with aluminum and galvanized or zinc coated parts and cause explosion hazard.

⚠ WARNING**Do not process flammable, explosive, toxic or otherwise hazardous materials without first performing an appropriate hazard analysis.**

VR Coatings cannot be an expert in the chemical and biological properties of the infinite number of materials that could be processed in this machine. As sold by VR Coatings, this machine is not designed to safely process hazardous materials unless additional precautions are not taken.

Before processing any material that are(or can react to become) flammable, explosive, toxic or otherwise hazardous, the user must perform a thorough hazard analysis and risk assessment of the entire process and determine the best way to deal with the hazard(s) identified, including contingency plans for dealing with processing errors and object conditions.



It is compulsory to

- Know the product and possible hazards.**
- Store the product to be used in the appropriate areas.**
- Keep the product used during dispensing in a suitable container.**
- Dispose the product according to the regulation of hazardous products in force in the country where the product is used.**
- Wore protective equipment designed for that use.**
- Wore glasses, gloves, shoes clothes and mask for breath.**

⚠ WARNING



SKIN INJECTION HAZARD. Protect hands and body from high pressure fluids. Relieve pressure before disconnecting hydraulic or other lines and tighten all connections before applying pressure. In case of accidental skin injection, seek immediate” Surgical Treatment”. Failure to follow this warning can result in amputation or serious injury.




An airless spray gun requires that fluid be introduced to it at very high pressure. Fluids under high pressure, from spray or leaks, can penetrate the skin and inject substantial quantities of toxic fluid into the body. If not promptly and properly treated, the injury can cause tissue death or gangrene and may result in serious, permanent disability or amputation of the wounded part. Therefore extreme caution must be exercised when using any airless spray equipment.

IF YOU ARE INJECTED, SEE A PHYSICIAN IMMEDIATELY. DO NOT TREAT AS A SIMPLE CUT!

NOTE TO PHYSICIAN:

Injection into the skin is a serious, traumatic injury. It is important to treat the injury surgically as soon as possible. Do not delay treatment to research toxicity. Toxicity is concerned with some exotic coatings injected directly in to the bloodstream. Consultation with a plastic surgeon or a reconstructive hand surgeon may be advised





- NEVER attempt to force the flow of fluid backward through the gun with your finger, hand or hand-held object against the gun nozzle.



- Before flushing system, always remove spray tip and adjust fluid pressure to lowest possible setting.



WARNING: The paint hose can develop leaks from wear, kinking, abuse etc. A leak is capable of injecting fluid into the skin; therefore the paint hose should be inspected before use. NEVER attempt to plug a hose with any part of your body, adhesive tape or any other makeshift device. Do not attempt to repair a spray hose. Instead, replace it with a new grounded hose. You must see to it that the following points are followed for hoses, accessories or any other hardware:

- ☐ Comply with manufacturer's recommendations.
 - ☐ Withstand the pressure ranges with correct safety factor.
 - ☐ Must not show any leaks, kinks, sign of wear and should be factory fitted and pressure tested.
- An air pressure safety valve forms an integral part of the air motor or air regulator and must not be altered or tampered with.



⚠ WARNING



COMPONENT RUPTURE The system is capable of producing high pressure all components in the system must have a maximum working pressure capacity, not less than the pressure rating of the pump.

SERVICING Before servicing, cleaning or removing any part, always shut off power source, carefully release pressure in fluid portions of the system and set safety locks on guns and equipment



PRESSURE RELEASE PROCEDURE

A Set trigger safely in a locked position.

B Shut off pump (Close main air supply valve and back-off air regulator).

C Release fluid pressure from entire system (Open drain valve) and trigger gun.

D Reset trigger safely in a locked position.

⚠ WARNING



High velocity flow of material through equipment may create static electricity. All equipment being sprayed must be properly grounded to prevent sparking, which may cause fire or explosion.



Due to static electricity potential generated by the high velocity of fluid through the pump, hose and tip, sparking may occur and the system may be hazardous. This can result in an explosion and/or fire, if every part of the spray equipment is not properly grounded. Be sure that both the object being sprayed and the airless equipment are grounded. This can be done by attaching a static wire to water piping or building structural members known to be earthen. If the hose does not contain a static electricity conductor, a static wire must be attached from the spray gun to the earth.

⚠ CAUTION

Before any adjustment, inspection, maintenance, cleaning, removing work always shut off the power source, carefully release pressure in fluid of the system and set safety locks on guns.



ALWAYS follow the coating or solvent manufacturer's safety precautions and warnings. Never spray flammable material near open flames, pilot lights or any other source of ignition.



If you experience any static sparking or slight shock while using the equipment, stop spraying immediately. Check the entire system for proper grounding. Do not use the system again until the problem has been corrected.

Follow material supplier's instructions carefully and ensure adequate ventilation of working area to prevent health hazards.

⚠ CAUTION**FLUSHING/CLEANING**

Always flush the unit into a separate metal container with the spray tip removed and the gun held firmly against the side of container to assure proper grounding and prevent static discharge, which could cause serious bodily injury.

⚠ CAUTION

FINGER OR HANDS PINCH HAZARD. KEEP HANDS CLEAR OF MOVING PARTS COUPLING AND PISTONS

Before servicing/removing any part always shut off power source and release pressure in fluid portions of the system.

⚠ CAUTION

DO NOT START PUMP IF GUARD IS NOT AT “UP” POSITION.

TO SET “UP” POSITION-hold by hands push upward till it locks in ball catch.

TO SET “DOWN” POSITION-Push downward.

FINGER OR HANDS PINCH HAZARD. KEEP HANDS CLEAR. Before servicing/removing any part always shut off power source and release pressure in fluid portions of the system.

⚠ CAUTION


Ensure that temperature of hot fluid used in the equipment shall not exceed 80% of the self-ignition temperature of the gases/solvent vapour in explosive atmosphere, in which equipment is used.

⚠ CAUTION

Check the compatibility of the solvent used in the equipment with the materials of wetted parts.

OPERATING INSTRUCTIONS

GENERAL DESCRIPTION:



Pneumatic piston Pumps are made for spraying, Dispensing, and transferring of various types of liquid/semi solid. These pumps are mainly used for airless/air assisted spraying of coating materials and dispensing /transferring of paints, oil, ink, sealants adhesives, wax, grease, solvents etc. and incorporate the following essential parts:

Airless Pump : Pneumatic motor with Control Unit, Hydraulic parts, Suction device, mounting plate ,etc.

Accessories: HP (High Pressure) hose, HP Filter, Trolley, Spray gun, Spray nozzle, etc.

Optional : Circulating unit, special accessories depending on applications.

The various pump versions are identified as follows:

e.g.: TIGER 30.150

Double stroke Volume in CC (150)

The above is intended to obtain the following data: s

Material Pressure : Pressure Input x Transmission Ratio

Displaced Volume : Double Stroke Volume x No. Of double stroke/ min. E.g. 50 double strokes/min.)

The pump works double acting and self-priming and serves to transfer the spray material to the spray gun by making it pass through a filter and a high pressure hose. Its differential piston, which is located in the hydraulic portion of the pump, moves upwards and downwards in the working cylinder (1 cycle = 1 double stroke = 1 upward and 1 downward stroke). The displacement piston features a layer of hard chrome of about 200 microns to protect against wear. The suction and delivery ball valve feature tungsten carbide seat.

The pump is equipped with an oil cup containing a solvent, which is intended to lubricate the piston and to prevent paint residues from incrustation. The packing need to be readjusted manually by tightening the upper packing take up nut which is designed as oil cup.

The actual spray performance depends on both spray nozzle size and selected spray pressure; increased material flow results in both spray nozzle size and air consumption.



Make sure that pump does not work too fast and / or too long when idling in order to prevent damage to sealing and valves.

All airless spraying units are equipped with capacity sieving filters. There are different mesh sizes to match according to the airless nozzle. Please see **Nozzle Chart** for appropriate type of nozzle.

In case of high delivery transfer pumps separate filters cartridge type or bag type can be used. Filter size depends upon the fluid, which is handled, and application requirements.

TWO COMPONENT HOT AIRLESS SPRAY EQUIPMENT-

Two Component Spray Equipment are used where curing time is very fast ranging from few seconds to several minutes and spraying through standard airless pump is not possible.

For high performance protective coatings which are solvent free and fast curing two components Epoxy or PU coating tar modified or tar free, two component hot airless spraying equipment is a must.

TWO COMPONENT HOT AIRLESS EQUIPMENT CONSIST OF-

1. Plural component high pressure pump
2. Mixing block
3. Mixers-Static/Dynamic
4. Flush pump
5. Heating system
6. Feed pump and supply system
7. Monitoring and control system
8. Spray guns

1. PLURAL COMPONENT HIGH PRESSURE PUMP

This is the core part of two component system. It is like standard airless spray equipment except two or three hydraulic cylinders driven by single common air motor.

2. MIXING BLOCK / MANIFOLD

Both the components that are individually metered and delivered by two component pump are mixed in this mixing block incorporated with numbers of non return valves. Return line from the mixing block goes back to the tank in case of circulated system.

3. MIXERS

When fluids are pumped through mixer they are progressively divided and recombined to get mixed. Diameter and length of the mixer depends upon material specifications.

4. FLUSH PUMP

This is the standard airless high pressure pump with pressure ratio ranging from 40:1 to 60:1 and output per cycle from 70 to 110cc used in two component system to rinse the whole system. Selection of flush pump depends on material to be flushed and hose lengths.

5. HEATED SYSTEM

This may consist of inline fluid heaters, heated supply containers, heated hoses. VR Coatings offers high pressure Inline fluid heaters to heat each individual component to the required temperature. Oil heated jacketed containers up to 200 ltr. capacity is also offered by VR Coatings to preheat the component individually as per material specification. It has power up to 12KW and temperature range up to 100°C. This is controlled and monitored by PID based control panel.

For long hose lengths materials which have to be sprayed at high temperature, the spray hoses must be heated/ insulated. VR Coatings offers hot water system to heated/ insulated. VR Coatings offers hot water system to

heat the hose and also provide electrical heated hose. In some cases insulated hose can be used instead of heated hose again depending on application, material specification and ambient temperature.

6. FEED PUMP AND SUPPLY SYSTEM

Feeding pump are used to feed the component from supply tank to two component pump. VR Coatings offers various feed pumps from its standard transfer pump range depending on the material specifications.

Separate feed pumps can be used to transfer material from Suppliers drum to supply containers of Two Component System. Drumpress with Hoisting unit can be used for transferring high viscous materials.

Agitators may also be used depending upon the application and type of the material. VR Coatings offers electrical driven high torque agitator for viscous material. Pneumatic agitators are also available where torque requirement is less.

7. MONITORING AND CONTROL SYSTEM

The monitoring system is required for safeguarding against incorrect mixing ratio for Two Component System. When pressure exceeds or drops surpassing the tolerance setting that are set by operator, while spraying the system automatically shut downs. When there is malfunctioning in the system and is manifested by surpassing set limits the system automatically switches off. These malfunctions may be because of internal/ external leakages, material deficiency, damaged seal etc. Automatic 'switching off' of the system prevents incorrect mixing ratio and reworks.

8. SPRAY GUNS

Trigger operated and insulated handle spray guns are used to apply coatings manually. For automatic spraying pneumatically operated automatic guns are used.

OTHER ACCESSORIES

A flexible HP hose serves as connection between pump and spray gun. Its inside wall consists of either Nylon or Teflon; it also contains an electrical conductor in order to permit electrostatic charges to discharge through the grounded pump.

WARNING



COMPONENT RUPTURE The system is capable of producing high pressure; all components in the system must have a maximum working pressure capacity not less than the pressure rating of the pump.

A large number of different nozzles are available. See **Nozzle Chart**.

MOUNTING OF ANY AIRLESS PUMP

Any pumping unit should be installed in a way to make it easily accessible for cleaning and maintenance purposes.



In the case of wall mounting, assure that pump is vertically installed and fastened by using the holes on the mounting plate.

All pumps are equipped with a grounding point. It is compulsory that the ground lead be connected to this point.

WARNING



High velocity flow of material through equipment may create static electricity. All equipment being sprayed must be properly grounded to prevent sparking, which may cause a fire or explosion.

Make sure that sufficient compressed air is available when connecting the pump to the air supply net.

Insure inside diameter of connection tube between compressed air delivery point and airless unit is sufficient for required capacity.

COMMISSIONING AND OPERATING

1. General Information

Present pump is suitable for any kind of coatings/ material such as primers, basic coats, lacquers, dispersion paints, caustics, bituminous mastics etc.,

Depending on their physical and chemical characteristics, other types of spray media can be used e.g. cements, fillers, deadening agents and so forth.

Two component paints, PU material, PES material, acid hardening material or other media containing filler such as asbestos, ground cork and silicates require special attention prior to use.

We do not recommend the application of coarse bodied or aggressive fluids using the airless method. These would include sand filled wall coatings, coatings with coarse fibrous, various types of adhesives.



⚠ WARNING



Do not process flammable, explosive, toxic or otherwise hazardous materials without first performing an appropriate hazard analysis.

It is compulsory to

- know the product and possible hazards.**
- store the product to be used in the appropriate areas.**
- keep the product used during dispensing in a suitable container.**
- Dispose the product according to the regulation of hazardous products in force in the country where the product is used.**
- Wear protective equipment designed for that use.**
- wear glasses, gloves, shoes clothes and mask for breath.**

2. In case of doubt, please contact for correct equipment recommendations.

Setting up

- Hold oil cup/coupling guard by hand and push downwards in versions provided with this type of guard.
- Check for top lubricant to maximum level in pump lubrication chamber or oil-cup or packing take-up nut.
- Lift oil cup guard in upward direction till it locks in ball catch.

⚠ CAUTION




FINGURE OR HANDS PINCH HAZARD. KEEP HANDS CLEAR. Before servicing/removing any part always shut off power source and release pressure in fluid portions of the system.

Ensure coupling guard is always at UP position while pump is working.

- Check high-pressure filter screen element. Mesh opening should be smaller than bore tip size used.
- The Table below should be used as a guideline only. We suggest that you do not use any filter element when spraying materials containing fibrous.

Mesh size an element marking (opening)	Tip size	Coating material to be sprayed
M 200 (0.084 mm/ 0.0033’')	< 0.3 mm 0.011’"	Clear lacquers, varnishes, and hammer tone.
M 150 (0.099mm/0.0039’')	>0.3 mm 0.011’"	Primer, filler, red oxide.
M 100 (0.145mm/0.0057)	>0.3 mm 0.011’"	Primer, filler, red oxide.
M 70 (0.250 mm/0.0098’')	>0.5 mm 0.016’"	Iron mica, red oxide.
M 50 (0.320 mm/0.0125’')	>0.6 mm 0.023’"	Latex paint, bodied coatings.

- Connect high-pressure fluid hose and gun and connect air supply to air regulator.

⚠ CAUTION	
	Have Trigger Lock engaged at all times when not spraying/in use.

Grounding

Connect the other end of the grounding wire provided on machine to the earth ground. Always use electrically conductive hoses.

Flushing of Complete Two Component System



The unit has been factory tested using an oil emulsion. To avoid contamination of the coating material to be sprayed, be sure the emulsion is flushed from the system before spray operation begins by using a compatible solvent.

Do as follows:

- Close main air supply valve and back-off air regulator.
- Close drain valve located at high-pressure filter manifold.
- Insert suction hose and tube or fluid end into compatible solvent.



- Place drain hoses from drain valves into container, open both drain Valves, if system having return lines open return line valves instead of drain valves and put line ends in container
Note: If system is already loaded with both components then take two separate containers to collect drain.
- Open main air supply valve and slowly open-air regulators to max. 2 bar (30 psi) of feed pumps. Open air regulator of main plural component pump to max 2 bar.
Note: Pump cycles slowly and circulates fluid via drain hose or return line back into the container.
- Close Drain valves/ return line valve. Point gun into container ensuring contact between gun and metal container then trigger the gun.
Note: The pump will cycle slowly and circulate fluid via gun back into the container.
- Close gun and increase air regulator setting of two component pump to maximum pressure allowed. Check all connections for leaks.
Note: Maximum fluid pressure will vary according to the model of pump selected.
- Close main air supply valve and back-off air regulator.
- Open drain valves/ return line valve relieve system pressure completely. Finally trigger the gun again shortly to ensure that there is no pressure retained in the fluid hose.

 CAUTION	
	<p>CAUTION : drain valves, return valves, supply valves shall be always closed or opened simultaneously of both components: otherwise system will unbalance and raise high pressure In one line.</p>

- Remove suction hose and tube or fluid end from solvent container, wipe clean. Point gun into the container, ensuring good contact with the container Trigger the gun. Slowly open air regulators to max. 2 bar (30 psi) of feed pumps. Open air regulators to main plural component pump to max 2 bar. Remove complete solvent via gun and return lines+

CAUTION



FLUSHING/CLEANING

Always flush the unit into a separate metal container with the spray tip removed and the gun held firmly against the side of container to assure proper grounding and prevent static discharge which could cause serious bodily injury.

MATERIAL LOADING AND OPERATING

- Take individual components to be mixed and sprayed in respective feed containers, manually or separate transfer pump or (if material is highly viscous) may be by drumpress unit.
- Close drain valves on filters at outlet manifold.
- Open the return valves. Increase feed pumps air pressure gradually till material flows properly. Collect return material in separate containers instead of main feed tank till its solvent free.
- Start flushing pump loaded with compatible solvent and keeps pressurized for immediate flushing of mixed material whenever required.
- Before opening supply valves, open flush valve and flush for few seconds. Close flushing valve. Close return line valves and open supply line valves and Trigger the spray gun. Take mixed material in a separate container and increase till you get proper mixing and atomization. Insure the pressures on the pressure gauges are stable before applying on substrate.

NOTE:

- There is pressure difference in upward and downward stroke due to use of feed pumps. As well as difference in both component pressures because of typical and efficient mixing block design.
- Set upper and lower pressure limits on the gauges or pressure controllers provided for monitoring.
- Upper pressure limit shall be about 20 bar more than the stall pressure and lower limit shall be below about 20 bar than lowest working/spraying pressure. These parameters can be varied depending upon material specifications and application.





Note: Do not stop while spraying when pot life is very short. If you stop, immediately close supply lines open return lines and flush the mixed material.

Note: Do not stop while spraying when pot life is very short. If you stop, immediately close supply lines open return lines and flush the mixed material.

- Start monitoring system by switching on the monitoring switch on the control panel.
- Automatic switching off closes supply valves, open return lines and flush valve and indication lamp will glow. Operator has to immediately flush the mixed material. Switch off monitoring. Identify and rectify the problem and start the system again as mentioned above.

OPERATING REMOTE PNEUMATIC CONTROLS

- Refer circuit diagram of pneumatic control panel.
- To switch on supply valves and to switch off return line valves or vice versa. Operated hand lever of 3/2 way DC valve as shown in figure on pneumatic panel.
- To switch on flushing operate hand lever of 3/2 way DC valve as shown in figure. Flushing valve will only operate when supply line valves are closed and return line valves are open.




Note: Immediately flush the mixed material when you STOP spraying

TROUBLE SHOOTING CHART RELATED TO MIXING

PROBLEM	CAUSE	SOLUTION
Mixing ratio incorrect	Return line valve leaking	Check and clean valve seats, if worn out replace.
		Insure sufficient air pressure to valves.
		Check pneumatic circuit.
	External leakages through joints	Tighten the joints. Replace worn out sealing's
	Hydraulic part valve seat leakages	Remove and clean valve seats
	Feeding container empty	Refill the container
Solvent is mixing in sprayed material	Flushing valve leaking	Check and clean valve seats. Replace if there are worn out parts. Check & clean non return valves in mixing block.
Spray pressure is low at high air inlet pressure	Choking in fluid line filters	Check filters. Clean the filter and replace element if necessary.
	Choking in hoses	Replace choked hoses.
	Choking in static mixer	Clean or replace
	Required material temperature not achieved	Circulate the heated material till required temperature reaches
		Check whether any heating element is failed. Correct it or replace.
Mixed material is not flushing out	Hardened material in the mixing block or in the static mixer or in the hose and gun	Clean the mixing block with compatible solvent, Service it as necessary. Clean static mixer, gun and hose. Replace hose if cleaning not possible.
	Solvent pump pressure is low	Increase pump air pressure
	Flushing valve not opening fully	Insure sufficient air pressure to valve
	Solvent container empty	Refill the solvent supply
	The solvent is compatible with the material	Change to a compatible solvent





PRESSURE RELEASE PROCEDURE

- A Set trigger safely in a locked position.
- B Shut off pump(Close main air supply valve and back-off air regulator).
- C Release fluid pressure from entire system
Open drain valve and trigger gun.
- D Reset trigger safely in a locked position.

Spray Pattern Control

CAUTION



Have Gun **Trigger Lock** engaged at all times when not actually spraying.

When installing **spray tip** be sure that **Gasket** is correctly used between gun tip and spray tip. With Gun in the “**Open**” (triggered) position, increase the air regulator setting until the correct spray pattern is achieved.



Note: Use the lowest air pressure possible that will give proper fluid atomization and spray pattern. Excessive or higher pressures show no improved result, but will cause reduced system component life, and will waste material.

POST-OPERATIONAL HANDLING:

Actuate gun in order to evacuate pressure from pump. Remove nozzle and clean it.

Lacquer may remain in the pump unto 48 hours. This should however be avoided when using two component materials or any other material liable to self-cure quickly.

Incase of protracted downtimes, evacuate pump, refill with solvent and leave as such. Clean HP filter if necessary.



• SHUT DOWN PROCEDURE

Flush the mixed material, shut-off flush valve. Actuate gun in order to evacuate pressure from pump. Follow procedure as listed under “Flushing”, however use regular Recommended lubricating oil without additives instead of solvent, if the pump is to be put into storage.

Back-off (relief) air regulator completely.

Close main air supply valve.

MAINTENANCE:

- Daily - if compressed air is wet - drain oil and water separator with pressure on and blow out water at least twice daily.
- Check fog oiler for correct adjustment (droplet metering) and oil level. Refill if required.

Note: Severe operating conditions may cause frosting of Air motor. To prevent, fill fog oiler with mixture of 50:50 regular recommended lubricating oil and Glycol.

Check or top-up level of lubricant in pump packing take-up nut & tighten oil cup if required.

Note: Change lubricant every 50 hours of operation, earlier in oil cup pumps. Discoloration of lubricant indicates packing wear or failure. This will affect pump performance. If necessary, renew upper packing set.

- Clean and inspect filter elements in filter screen housing and high-pressure filter at least daily, based on quality of product to be sprayed.
- Do not kink or bend high-pressure fluid hose to less than four-inch radius.
- Loosen threaded connections or hose couplings of the unit or system only when essential. This will help prevent hardened materials getting into the system, which could malfunction.



- Displacement piston in lowest (DOWN) position at all times to prevent material from hardening on the fluid piston or rod.

TECHNICAL SPECIFICATIONS

Name	Type	Ratio	Output/cycle(cc)	Air motor piston ϕ mm	Stroke length mm	Approximate Weight (kg)	Recommended spray volume/minute (lt.)	Air inlet pressure Max. (bar)	Output Pressure Max. (bar)	Air consumption N lt./ min. Max.
<u>TIGER</u>	30.70	30:1	70	110	120	19	3.5	8	240	900
	40.110	40:1	110	160	120	24	5.5	8	320	1900
	12.150	12:1	150	110	120	22	7.5	6	72	900
	28.20	28:1	20	80	70	15	2	6	168	450
	30.150	30:1	150	160	120	23	6	8	240	1900
	28.40	28:1	40	80/110	120/70	17	2	6	168	450
	60.70	60:1	70	160	120	21	3.5	6	360	1400
	16.70	16:1	70	80	120	17	3.5	8	128	450
	12.150	12:1	150	110	120	24	7.5	6	720	900
	14.20	14:1	20	60	70	13	1.2	6	84	250
	14.40	14:1	40	60	120	15	1.2	6	84	250
<u>RHINO</u>	45.210	45:1	210	230	120	62	5.5	6	270	3000
	60.150	60:1	150	230	120	60	6	6	360	3000
	30.275	30:1	275	230	120	62	10	6	280	3000
	45.275	45:1	275	270	120	70	7.5	6	270	4000
	60.210	60:1	210	210	120	70	5.5	6	360	3000
	55.275	55:1	275	300	120	67	7.5	6	330	5000
	75.210	75:1	210	300	120	67	5.5	6	450	5000
	75.275	75:1	275	350	120	67	7.5	6	450	5000
<u>HIPPO</u>	4.90	4:1	90	60	70	8	1.8	6	24	100
	2.900	2:1	900	110	120	28	30	6	12	480
	5.900	5:1	900	160	120	30	30	6	30	4000
	3.400	3:1	400	080	120	22	15	6	18	300
<u>ELEPHANT</u>	4.2000	4:1	2000	230	120	78	40	6	24	1200
	4.3400	4:1	3400	230	200		70	6	24	2000
	2.4000	2:1	4000	230	120	105	80	6	12	1200
	2.6500	2:1	6500	230	200	110	130	6	12	2000

CHEETAH

Type	2k-350/79x79x150	2k-350/110x110x110	2k-350 / 110x110x79	2k-350/110x110x58	2k-350/150x150x32
Mixing Ratio*	1:1	2:1	3:1	4:1	10:1
Transfer Ratio*	70:1	65:1	70:1	75:1	60:1
Output per cycle	300 cc	340 cc	300 cc	280 cc	332 cc
Air Motor Piston	350 mm	350 mm	350 mm	350 mm	350 mm
Stroke Length	120 mm	120 mm	120 mm	120 mm	120 mm
Recommended spray Vol/min	7.5ltr.	8.5ltr.	7.5 ltr.	7 ltr.	8 ltr.
Air Inlet Pressure Max.	6 bar	6 bar	6 bar	6 bar	6 bar
Output Pressure Max.	420 bar	390 bar	420 bar	450 bar	360 bar
Air consumption N ltr./min Max.	6800	6800	6800	6800	6800



TROUBLE SHOOTING

MALFUNCTION	Pump does not start/stops during operation	Pump does not suck or only insufficiently	Spray pressure too low	Pump operates irregularly	Pump operates although spray gun is closed	Pump transports material into the rinsing agent	Regulator frozen
AIMOTOR	Clean regulator, replace defective parts if necessary			Clean regulator, replace defective parts if necessary			Compressed air too moist, stroke frequency too high, ambient temperature too low.
HYDRAULIC PART		Not sufficiently ventilated, loose suction connection		Not sufficiently ventilated, loose suction connection	Not sufficiently ventilated, loose suction connection		
SUCTION AND TRANSFER VALVE		Worn or blocked, replace defective parts		Worn or blocked, replace defective parts	Replace worn or defective parts		
PACKINGS		Leaking piston and packing		Leaking piston and packing		Leaking packing	
FILTER	Filter mesh blocked, check where and clean out	Filter mesh blocked, check where and clean out	Filter mesh blocked, check where and clean out		Drain valve open.		
COMPRESSED AIR LINE	Volume flow too low, air pressure too low.		Volume flow too low, air pressure too low.				
PRESSURE REGULATOR VALVE (AIR)	Air pressure too low		Air pressure too low				
SUCTION SET		Filter mesh blocked		Filter mesh blocked	Filter mesh blocked		
MATERIAL HOSE	Blocked, check where and clean out	Blocked, check where and clean out	Blocked, check where and clean out				
ATOMIZER	Orifice of spray cap blocked		Orifice spray too large				
MATERIAL BEING USED	Viscosity too high						

WARRANTY

VR Coatings warrants all equipments manufactured by us, as long as it is bearing original identification plate, to be free from defects in material and workmanship for a period of one year from ex-works date. VR Coatings will repair or replace any part of the equipment proven defective. The warranty applies only when the equipment is installed, operated and maintained in accordance with VR Coatings written recommendations.

Warranty claims found to be defective shall be verified and confirmed by VR Coatings.

Our warranty does not cover and VR Coatings shall not be liable for any malfunction, damages, or fair wear and tear caused by faulty installation, misuse, abrasion, corrosion, inadequate or improper maintenance, negligence, tempering, accident or incorporation of non VR Coatings parts, non observance of VR Coatings recommendations.

This warranty only consists of replacing the parts returned to our plant prepaid transportation and proven defective by us. If inspection of the equipment /part does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the cost of parts, labor and transportation. VR Coatings shall not be liable for any losses resulting from a production breakdown.

Material bought in equipment, which is sold but not manufactured by VR Coatings, will be subject to the manufacturer's warranty. VR Coatings will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

NOTES

[illegible]

INDEX

DECLARATION OF CONFIRMITY	1
SAFETY LABELS	2
WARNING AND SAFETY INSTRUCTIONS	3
OPERATING INSTRUCTIONS	9
TROUBLESHOOTING	17
TECHNICAL SPECIFICATIONS	18
WARRANTY	19
NOTES	20



SAFETY LABELS AND NAMEPLATE



Label on pump

label no.W.01




Label on pump provided without coupling guard Label no.W.02



Label on pump provided with coupling guard Label no.W.03

Safety labels free of charge on request





INSTRUCTIONS MANUAL

Keep for future use!



POLYUREA SPRAY SYSTEM

Serial Number:



VR COATINGS PVT.LTD.

OFFICE: J-138, MIDC PUNE – 411 026, INDIA.

TEL : + 91 - 20 - 69180136 / 27130331

E-MAIL: vrcoatings@eth.net


**Factory: Plot No.136, Sector No.7, PCNTDA,
Bhosari, Pune – 411 026, INDIA.**

TEL: + 91 – 20 - 69180106

E-MAIL: service@vrcoatings.com

Mr. Pascal D'souza (Technical Director)

+91- 9822655891






INSTRUCTIONS MANUAL



Keep for future use!



200 LTRS. BARREL TRANSFER PUMP

Serial Number:



VR COATINGS PVT.LTD.

OFFICE: J-138, MIDC PUNE – 411 026, INDIA.

TEL : + 91 - 20 - 69180136 / 27130331.

E-MAIL: vrcoatings@eth.net

**Factory: Plot No.136, Sector No.7, PCNTDA,
Bhosari, Pune – 411 026, INDIA.**

TEL: + 91 – 20 - 69180106

E-MAIL: service@vrcoatings.com

Mr. Pascal D'souza (Technical Director)

+91- 9822655891



CONTENT

DECLARATION OF CONFIRMITY

WARNING AND SAFETY INSTRUCTION

OPERATING INSTRUCTIONS, MAINTAINANCE,
TROUBLESHOOTING

TECHNICAL SPECIFICATIONS

DRAWINGS AND PARTLISTS

WARRANTY

NOTES



CONTENT

DECLARATION OF CONFIRMITY

WARNING AND SAFETY INSTRUCTION

OPERATING INSTRUCTIONS, MAINTAINANCE,
TROUBLESHOOTING

TECHNICAL SPECIFICATIONS

DRAWINGS AND PARTLISTS

WARRANTY

NOTES





TECHNICAL SPECIFICATION

POLYUREA SPRAY SYSTEM - 2K/270/110X2

Type	2K/270/110x2
Mixing Ratio	1 :1
Transfer Ratio	55:1
Output Per Cycle	220 cc
Air motor Piston Ø	270 mm
Spray Volume @ 40 cycles/min	8.8 ltr/min
Air In Max	6 bar
Max. Pressure	330 bar
Air consumption N ltr @ 40 cycles/min	3850
Inline Heaters	7kw x 2nos.
Temperature Range	Up to 100° C
Power Supply	415 VAC-3 phase 50 Hz 5 wire R-Y-B-N-E copper flexible 6sq.mm x 5 core cable for incoming feeder







	PART NAME	OLD PART NO.	NEW PART NO.
A	AIR SEAL	01 080 012 00	01 080 012 57


(DIRECTLY REPLACIBLE)

[NOTE : W& T ITEMS ARE SOLD WITH SERVICE KIT ONLY]

	01 080 700 00	SERVICE KIT	-	-	SET
	02 080 010 31	GASKET	-	-	2
14	01 080 003 19	STUD	3		-
13	20 011 037 19	WASHER M6	6		-
12	01 080 001 02	TOP CASTING	1		-
11	01 080 010 25	O-RING	2	Y	2
10	01 080 004 01	CYLINDER	1		-
9	01 080 006 19	NUT	1		-
8	01 080 008 01	PISTON DISC	1		-
7	01 080 007 25	O-RING	1	Y	1
6	01 080 009 19	PISTON	1		-
5	61 110 008 00	SENSING VALVE	2	Y	2
4	15 207 008 19	NUT (M6X1)	3		-
3	01 080 011 02	BOTTOM CASTING	1		-
2	01 080 012 57	AIR SEAL	1	Y	1
1	01 080 014 07	CIRCLIP	1		-
SR.NO.	PART NO.	PART NAME	QTY.	W&T	



Note: Gasket shown in assembly dwg of Control Block


RAW MATERIAL DESCRIPTION		NOTE:					
SIZE							
LENGTH							
MAT.							
		ALL DIMN. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01. REMOVE SHARP CORNERS. INCASE OF DOUBT ASK.					
 VR COATINGS PVT.LTD. J-138, MIDC, BHOSARI, PUNE-411 026 INDIA			DRN.	CKD.	APPD.	PART NAME	AIR MOTOR D 80 S 120
		SIGN	ROHIT	Albert	NVD		
		DATE					
		SCALE	NOT TO SCALE	PART NO.		01 080 000 00	





NOTE : W & T ITEMS ARE SOLD WITH SERVICE KIT ONLY.



	02 081 700 01	SERVICE KIT	-	-	SET
23	15 330 008 19	ALLEN BOLT(M6X30)	2		-
22	15 340 008 19	ALLEN BOLT M6	4		-
21	02 081 021 57	MID BLOCK GASKET	2	Y	2
20	02 081 022 57	MID BLOCK GASKET	2	Y	2
19	02 081 001 00	SIDE BLOCK ASSEMBLY	1		-
18	15 345 008 19	ALLEN BOLT (M6X45)	4		-
17	02 081 023 57	MID BLOCK GASKET	2	Y	2
16	02 080 021 22	PIN Ø3 X 5	1	Y	1
15	02 081 042 57	BOTTOM GASKET	1	Y	1
14	02 081 003 00	SLIDER ASSEMBLY	1	Y	1
13	02 081 026 57	MID BLOCK GASKET	2	Y	-
12	02 081 029 02	BOTTOM BLOCK	1		-
11	02 081 025 57	MID BLOCK GASKET	2	Y	2
10	02 081 036 00	SILENCER ASSLY (TIGER)	1		-
9	15 370 008 19	ALLEN BOLT(M6x70L)	1		-
8	15 360 008 19	ALLEN BOLT (M6X60)	1		-
7	02 081 031 02	TIGER CB CAP	1		-
6	20 043 000 00	AIR SAFETY VALVE 1/4'	1		-
5	19 002 001 19	WASHER 1/4"	1		-
4	02 081 044 00	MIDDLE BLOCK ASM.	1		-
3	02 081 043 57	TOP GASKET	1	Y	1
2	02 081 027 02	TOP BLOCK	1		-
1	15 320 008 19	ALLEN BOLT M6X20	4		-
SR NOS.	PART NO.	PART NAME	QTY.	W & T	SERVICE KIT QTY.

RAW MATERIAL DESCRIPTION		NOTE: TIGER NEW CONTROL BLOCK				
SIZE		 ALL DIMN. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01. REMOVE SHARP CORNERS. IN CASE OF DOUBT ASK.				
LENGTH						
MAT.	ASSEMBLY					
 VR COATINGS PVT.LTD. J-138, MIDC, BHOSARI, PUNE-411 026 INDIA		DRN.	CKD.	APPD.	PART NAME	
		SIGN	ROHIT	RAJIV	NVD	
		DATE				PART NO.
		SCALE	NOT TO SCALE			02 081 000 01



21	15 315 008 07	ALLEN BOLT M6X15	10	-
20	02 300 040 57	ROUND GASKET	4	Y
19	02 081 026 57	MID BLOCK GASKET	2	Y
18	02 300 042 57	GASKET	2	Y
17	02 300 045 00	MID BLOCK ASSEMBLY	1	-
16	02 300 009 02	SILENCER CAP	1	-
15	15 375 008 37	ALLEN BOLT	2	-
14	02 230 011 00	SILENCER ASSLY	1	-
13	15 335 008 07	ALLEN BOLT(M6X35)	8	-
12	15 360 008 07	ALLAN BOLT(M6X60)	4	-
11	02 300 036 02	BOTTOM BLOCK	1	-
10	02 300 024 00	SLIDER ASSEMBLY	1	Y
9	02 300 066 57	SQUARE GASKET	1	Y
8	15 322 008 07	ALLEN BOLT M6 x 22	4	-
7	02 300 004 02	INLET BLOCK	1	-
6	20 026 000 00	AIR SAFTEY VALVE 1/2"	2	-
5	02 300 064 57	ROUND LARGE GASKET	2	Y
4	02 300 043 57	GASKET	2	Y
3	02 300 065 57	ROUND SMALL GASKET	2	Y
2	02 081 001 00	SIDE BLOCK ASSEMBLY	1	-
1	02 300 035 02	TOP BLOCK	1	-
	02 300 700 04	SERVICE KIT	-	SET
SR NO.	PART NO.	PART NAME	QTY.	W&T

RAW MATERIAL DESCRIPTION		NOTE:	
SIZE		<div></div> <div>ALL DIMN. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01. REMOVE SHARP CORNERS. INCASE OF DOUBT ASK.</div>	
LENGTH			
MAT.	ASSEMBLY		
<div><div>VR COATINGS PVT.LTD. J-138, MIDC, BHOSARI, PUNE-411 026 INDIA</div></div>		<div><div>DRN. CKD. APPD.</div><div>SIGN. NIKHIL. RAJIV. NID.</div><div>DATE</div><div>SCALE NOT TO SCALE</div></div>	<div>PART NAME RHINO CONTROL BLOCK ASSEMBLY</div> <div>PART NO. 02 300 000 04</div>



SECTION A-A
& B-B

13	WASHER 1/4"	19 001 002 19	11	
12	PRESSURE TRANSMITTER	98 014 400 10 WKA	2	
11	PRESSURE GAUGE	13 018 001 00	2	
10	PRESSURE GAUGE MOUNTING BLOCK	17 013 126 19	2	
9	CONNECTOR	14 001 001 19	2	
8	SWIVEL 1/4" BSP	51 101 000 02	2	
7	BALL 14	04 210 013 05	2	
6	PACKING RING	17 005 016 21	2	Y
5	SEAT ADAPTER	17 005 032 00	2	
4	CONNECTOR	17 013 040 07	2	
3	OUTLET MANIFOLD	17 013 042 08	1	
2	BALL GUIDE	04 210 017 17	3	
1	OUTLET MANIFOLD	17 013 313 08	1	
S.NO.	PART NAME	PART NUMBER	QTY.	W & T

RAW MATERIAL DESCRIPTION NOTE:						ALL DIMN. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01. REMOVE SHARP CORNERS. IN CASE OF DOUBT ASK.	
SIZE							
LENGTH							
MAT.	ASSEMBLY						
VR COATINGS J-138, MIDC, BHOSARI, PUNE-411 026 INDIA		SIGN <i>VR</i> DATE <i>11/11/20</i> DRN. APPD.		PART NAME OUTLET MANIFOLD ASSEMBLY		PART NO. 17 013 312 00	
SCALE: NOT TO SCALE							





TABLE B

14	LOWER PACKING SET (REG)	PTFE(6)	17 110 062 00	Ⓒ
	LOWER PACKING SET (OPTIONAL)	GRAPHITE FILLED PTFE(6)	17 110 064 00	Ⓒ
	LOWER PACKING SET (OPTIONAL)	BRONZE FILLED PTFE(6)	17 110 066 00	ⒸⒷ
	LOWER PACKING SET (OPTIONAL)	UHMWPE (6)	17 110 070 00	Ⓓ
	LOWER PACKING SET (OPTIONAL)	S.P.E(6)	17 110 071 00	Ⓓ

TABLE C

S. NO.	PART NAME	PART NO.
BA/14A	PACKING RING (PTFE)	04 110 089 21
BB/14B	PACKING RING (GRAPHITE FILLED PTFE)	17 110 051 54
BC/14C	PACKING RING (BRONZE FILLED PTFE)	04 110 052 48 Ⓒ
BD/14D	PACKING RING (UHMWPE)	04 110 089 42 Ⓓ
BE/14E	PACKING RING (S.E)	04 110 089 40 Ⓓ

TABLE A

3	UPPER PACKING SET (REG)	PTFE(7)	04 110 106 00	ⒸⒹ
	UPPER PACKING SET (OPTIONAL)	GRAPHITE FILLED PTFE(7)	04 110 107 00	ⒸⒹ
	UPPER PACKING SET (OPTIONAL)	BRONZE FILLED PTFE(7)	04 110 108 00	ⒸⒹ
	UPPER PACKING SET (OPTIONAL)	UHMWPE (7)	04 110 112 00	Ⓓ
	UPPER PACKING SET (OPTIONAL)	S.E (7)	04 110 114 00	Ⓓ

3E/14E	SERVICE KIT-4(OPTIONAL)(UPPER-S.E)	17 110 709 00	-	Y	SET
3E/14E	SERVICE KIT-3(OPTIONAL)(UPPER-UHMWPE)	17 110 708 00	-	Y	SET
3D/14D	LOWER -UHMWPE)				
3C/14C	SERVICE KIT-2(OPTIONAL)(UPPER-BRONZE FILLED PTFE/LOWER-BRONZE FILLED PTFE)	17 110 710 00	-	Y	SET
3B/14B	SERVICE KIT-1(OPTIONAL)(UPPER-GRAPHITE FILLED PTFE/LOWER-GRAPHITE FILLED PTFE)	17 110 704 00	-	Y	SET
BA/14A	SERVICE KIT(REG)(UPPER-PTFE/LOWER-PTFE)	17 110 700 00	-	Y	SET
S. NO.	PACKING SET KIT	SERVICE KIT NO	QTY	W&T	SERVICE KIT QTY

20	WASHER	04 110 021 19	1	
19	NUT	15 210 014 07	4	
18	WASHER	19 002 014 07	4	
17	STUD	04 110 019 17	4	
16	CONNECTOR	SEE NOTE	1	
Ⓒ15	WASHER	19 002 003 19	1	
ⒸⒷ14	LOWER PACKING SET	REFER TABLE B	1	Y
Ⓒ13	PISTON SEAT	04 110 069 00	1	
12	BALL GUIDE	04 110 012 19	1	
11	BALL	04 070 013 19	1	Y
10	SUCTION SEAT	04 110 011 00	1	
9	CYLINDER	04 110 010 19	1	
8	BALL 12	04 070 016 05	1	
7	PISTON ROD	17 110 008 19	1	
6	PACKING RING	04 110 007 21	2	Y
5	SPACER	04 110 006 19	1	
Ⓒ4	MALE PACKING CAP	17 110 068 19	2	
ⒸⒷ3	UPPER PACKING SET	REFER TABLE A	1	Y
Ⓒ2	FEMALE PACKING CAP	17 110 067 19	2	
1	OIL CUP	17 110 001 17	1	
S.NO.	PART NAME	PART NUMBER	QTY.	W & T




PARTS LIST

D	UHMWPE, S.E.PACKING SET ADDED.	29/07/15	
C	PACKING SET NO. CHANGE, WASHER PART NO. CHANGE	10/06/15	
B	GRAPHITE FILLED PTFE AND BRONZE FILLED PTFE PACKING SET NEWLY ADDED	24/08/14	
B	MIDDLE PACKING CAP(04 110 014 19) REMOVED FROM LOWER PAKING SET.		
B	LOWER PACKING RING QTY 4, CHANGED TO 5	24/08/14	
A	PISTON SEAT PART NO. CHANGED AND PACKING MATERIAL CARBON FL PTFE CHANGED TO BR FL PTFE	12/06/06	

RAW MATERIAL DESCRIPTION	NOTE: CONNECTOR FOR BASE PUMP 14 003 002 19
SIZE	
LENGTH	
MAT.	ASSEMBLY
	ALL DIMN. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01.
	REMOVE SHARP CORNERS. INCASE OF DOUBT ASK.
SIGN	DRN. CKD. APD.
DATE	
	PART NAME HYDRAULIC PART 110
	PART NO. 17 110 000 00


VR COATINGS
J-138, MIDC, BHOSAPUR, PUNE-411 026
INDIA

SCALE NOT TO SCALE



23	15 211 015 07	NUT M 12	4	
22	19 002 011 19	WASHER M14	3	
21	17 350 009 17	BOLT M14X2	3	
20	61 110 008 00	SENSING VALVE	2	Y
19	17 300 003 19	PISTON ROD	2	
18	17 271 003 07	PISTON DISC	1	
17	01 270 003 25	O RING	2	Y
16	15 360 021 07	ALLEN BOLT M20X60	2	
15	15 603 025 07	GRUB SCREW M3 X 0.5	1	
14	17 300 007 07	COVER	1	
13	01 230 013 07	INTERNAL CIRCLIP B55	1	
12	01 230 011 00	AIR SEAL	1	Y
11	17 300 005 16	BUSH	1	
10	01 230 002 00	STUD	4	
9	19 002 015 07	WASHER	8	
8	17 271 001 02	TOP CASTING	1	
7	01 270 002 19	CYLINDER	1	
6	17 300 006 19	TOP PISTON ROD	1	
5	15 360 017 07	BOLT M16X60	1	
4	01 270 005 25	O RING	2	Y
3	17 271 002 02	BOTTOM CASTING	1	
2	01 110 018 00	AIR SEAL	2	Y
1	01 110 022 07	CIRCLIP	2	
SR. NO.	PART NO.	PART NAME	QTY.	W & T



RAW MATERIAL DESCRIPTION		NOTE:	
SIZE		ALL DIMN. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01. REMOVE SHARP CORNERS. IN CASE OF DOUBT ASK.	
LENGTH			
MAT.	ASSEMBLY		
VR COATINGS PVT.LTD. J-138, MIDC, BHOSARI, PUNE-411 026 INDIA		SIGN <i>DRN</i> ALBERT DATE SCALE NOT TO SCALE	PART NAME AIR MOTOR PART NO. 17 271 000 00




32	29 003 019 21	PACKING RING	2	Y
31	29 003 036 19	BALL GUIDE 28	1	
30	33 275 031 19	BALL $\phi 19$ MM	1	
29	29 003 039 00	SEAT HOLDER	1	
28	15 110 014 07	NUT M10	1	
27	29 003 028 19	SEAL WASHAR	1	
26	29 003 029 19	LOCK NUT	1	
25	29 003 009 19	CYLINDER OUTER	1	
24	29 003 020 21	PACKING RING	1	Y
23	33 275 009 00	PACKING SET	1	Y
22	29 003 050 07	WASHAR M8	6	
21	15 320 008 07	ALLEN BOLT M6X20	4	
20	29 003 049 19	CONNECTING ROD	1	
19	29 003 069 19	TIE ROD	3	
18	01 080 000 00	AIR MOTOR 080 S120	1	
17	02 081 000 01	CONTROL BLOCK	1	
16	48 031 082 00	OIL CUP COVER	1	
15	09 001 000 00	COUPLING ASSEMBLY	1	
14	29 003 008 17	CUP NUT	1	
13	29 003 067 01	FLANGE	1	
12	15 210 009 07	NUT (M8)	6	
11	29 003 041 00	OUTLET HOUSING ASSEMBLY	1	
10	29 003 010 19	CYLINDER INNER	1	
9	29 003 045 00	SHAFT	1	
8	29 003 031 21	SEAL WASHER	1	Y
7	29 003 026 21	SEAL UPPER	1	Y
6	04 070 013 19	BALL $\phi 28$ MM	1	Y
5	29 003 021 19	PISTON HOLDER	1	
4	29 003 025 21	SEAL	1	Y
3	29 003 024 19	SEAT WASHAR	1	
2	29 003 047 19	INTRENAL CIRCLIP B45	1	
1	29 003 040 00	SUCTION SEAT	1	
SR. NO.	PART NUMBER	PART NAME	QTY.	W & T



RAW MATERIAL DESCRIPTION		NOTE:	
SIZE		ALL DIM. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01. REMOVE SHARP CORNERS. IN CASE OF DOUBT ASK.	
LENGTH			
MAT.			
VR COATINGS PVT.LTD. J-138, MIDC, BHOSARI, PUNE-411 026 INDIA		DRN CKD APPD SIGN ANIL ALBERT NYD DATE SCALE NOT TO SCALE	PART NAME BARREL PUMP 4.5:1 PART NO. 29 009 000 03

16	41 006 008 00	CABLE GLAND	1	
15	15 390 008 07	ALLEN BOLT	4	
14	41 011 021 01	CAP	1	
13	41 011 016 19	PLUG 1/2"	7	
12	41 011 018 04	PACKING RING	7	
11	41 011 017 04	PACKING RING	13	
10	41 011 015 19	PLUG M22 X 1.5	13	
9	41 005 124 00	HEATER ELEMENT	1	Y
8	41 011 010 01	SCREWED PLATE	1	
7	41 011 013 00	RTD SENSOR 3/8"	1	
6	41 011 012 04	RTD SENSOR BODY	1	
5	41 011 006 01	HEATER BODY	1	
4	41 011 005 19	CONNECTOR M26 X 1.5 X 3/4"	2	
3	41 011 014 19	DISTANCE PIECE	1	
2	15 315 008 19	ALLEN BOLT M6X15	8	
1	41 011 009 01	SCREWED PLATE	1	
SR.NOS.	PART NO.	PART NAME	Qty.	W&T

A		SR.NO. 14,15 & 16 ADDED	03/08/16		RAW MATERIAL DESCRIPTION		NOTE:													
REV		DESCRIPTION	DATE	APPD.	SIZE	 <p>ALL DIMN. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01. REMOVE SHARP CORNERS. INCASE OF DOUBT ASK.</p>														
AMMENDMENTS					 VR COATINGS PVT.LTD. J-138, MIDC, BHOSARI, PUNE-411 026 INDIA		<table border="1"> <tr> <td>SIGN</td> <td>OMKAR</td> <td>ALBERT</td> <td>NVD</td> </tr> <tr> <td>DATE</td> <td></td> <td></td> <td></td> </tr> <tr> <td colspan="4">SCALE NOT TO SCALE</td> </tr> </table>		SIGN	OMKAR	ALBERT	NVD	DATE				SCALE NOT TO SCALE			
SIGN	OMKAR	ALBERT	NVD																	
DATE																				
SCALE NOT TO SCALE																				
					PART NAME		HEATER 7.6 KW WITHOUT CONTROL PANEL													
					PART NO.		41 011 000 00													





A	SR.NO. 14,15 & 16 ADDED	03/08/16	
REV	DESCRIPTION	DATE	APPD.
AMMENDMENTS			

RAW MATERIAL DESCRIPTION		NOTE:					
SIZE							
LENGTH							
MAT.							
<div> VR COATINGS PVT.LTD. J-138, MIDC, BHOSARI, PUNE-411 026 INDIA</div>			ALL DIMN. ARE IN MM UNLESS OTHERWISE STATED. FOR OPEN TOLERANCE AND SURFACE ROUGHNESS SEE STANDARD CHART DD-01/CH-01. REMOVE SHARP CORNERS. INCASE OF DOUBT ASK.				
			DRN.	CKD.	APPD.	PART NAME HEATER 7.6 KW WITHOUT CONTROL PANEL	
			SIGN	OMKAR	ALBERT		NVD
			DATE				
			SCALE	NOT TO SCALE			
		PART NO.		41 011 000 00			

WEB SITE - <http://www.vrcoatings.com>
E-MAIL - vfdsouza@vsnl.com

PLC BASED
CONTROL PANEL



QUOTATION NUMBER

NOTE:



VR COATINGS
J-138, MIDC, BHOSARI
PUNE-411026 (INDIA)
TEL : (020) 7122331
FAX : (020) 7121891



ALL DIM. ARE IN MM UNLESS OTHERWISE STATED.

SIGN	DRN.	APPD.	PROJECT NAME	POLYUREA SPRAY SYSTEM
DATE			CUSTOMER NAME	TORNADO
SCALE	NOT TO SCALE			

WARRANTY

VR Coatings warrants all equipments manufactured by us, as long as it is bearing original identification plate, to be free from defects in material and workmanship for a period of twelve months from ex-works date. VR Coatings will repair or replace any part of the equipment proven defective. The warranty applies only when the equipment is installed, operated and maintained in accordance with VR Coatings written recommendations.

Warranty claims found to be defective shall be verified and confirmed by VR Coatings.

Our warranty does not cover and VR Coatings shall not be liable for any malfunction, damages, or fair wear and tear caused by faulty installation, misuse, abrasion, corrosion, inadequate or improper maintenance, negligence, tempering, accident or incorporation of non VR Coatings parts, non observance of VR Coatings recommendations.

This warranty only consists of replacing the parts returned to our plant prepaid transportation and proven defective by us. If inspection of the equipment /part does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which may include the cost of parts, labor and transportation. VR Coatings shall not be liable for any losses resulting from a production breakdown.

Any bought out material in the equipment, which is sold but not manufactured by VR Coatings, will be subject to the manufacturer's warranty. VR Coatings will provide purchaser with reasonable assistance in making any claim for breach of these warranties.






INSTRUCTIONS MANUAL



Keep for future use!



200 LTRS. BARREL TRANSFER PUMP

Serial Number:



VR COATINGS PVT.LTD.

OFFICE: J-138, MIDC PUNE – 411 026, INDIA.

TEL : + 91 - 20 - 30781022 / 27130331.

E-MAIL: vrcoatings@eth.net

Factory: Plot No.136, Sector No.7, PCNTDA,
Bhosari, Pune – 411 026, INDIA.

TEL: + 91 – 20 - 30781034

E-MAIL: service@vrcoatings.com

Mr. Pascal D'souza (Technical Director)

+91- 9822655891





INSTRUCTIONS MANUAL

Keep for future use!



POLYUREA SPRAY SYSTEM

Serial Number:



VR COATINGS PVT.LTD.

OFFICE: J-138, MIDC PUNE – 411 026, INDIA.

TEL : + 91 - 20 - 69180136 / 27130331

E-MAIL: vrcoatings@eth.net


Factory: Plot No.136, Sector No.7, PCNTDA,
Bhosari, Pune – 411 026, INDIA.


TEL: + 91 – 20 - 69180106

E-MAIL: service@vrcoatings.com


Mr. Pascal D'souza (Technical Director)

+91- 9822655891






L.H.S. VIEW



FRONT VIEW



R.H.S. VIEW

LEGENDS:

- 1: 'R' PHASE INDICATOR RED LED

2: 'Y' PHASE INDICATOR YELLOW LED

3: 'B' PHASE INDICATOR BLUE LED

4: BASE HEATER TIC

5: ACT HEATER TIC

6: MONITORING ON/OFF SW

7: SPRAY ON/OFF SW

8: FAULT ACK PB
- 9: MIMIC HOOTER

10: BASE HEATER ON/OFF SW

11: ACT. HEATER ON/OFF SW

12: SPARE


13: EMERGENCY PB


14: SOLENOID VALVE CONNECTOR


15: PRS. MONITOR CONNECTOR

16: MAIN SWITCH
- 17: FILTER

18: FAN + FILTER







DRAWN BY : SURESH

PRINT DATE: 07.06.2014

TITLE: WRING DIAGRAM FOR 230VAC CONTROL

PROJECT: 7.5 KW HEATER SYSTEM


V.R. COATINGS PVT LTD, PUNE

DWG. NO:

11

+

 $\frac{4}{5}$



ELECTRICAL SAFETY INSTRUCTIONS



- Avoid contact with ***energized electrical circuits***
- Disconnect the power source before servicing or repairing electrical equipment.
- Use only tools and equipment with non-conducting handles when working on electrical devices
- Never use metallic pencils or rulers, or wear rings or metal watchbands when working with electrical equipment. This rule is very easy to forget, especially when you are showing some electrical part pointing with metallic pencil.
- If water or a chemical is spilled onto equipment, shut off power at the main switch or circuit breaker and unplug the equipment.
- Do not store "***highly flammable liquids***" near electrical equipment.
- Do not wear loose clothing or ties near electrical equipment.
- In case of PLC used in panel, keep the power supply ON for at least two hours in a week.
- Make sure all electric cords are tucked away, neat and tidy.
- Always use caution when working near electricity.



VR COATINGS PVT.LTD.

J-138,MIDC PUNE-411 026
INDIA. TEL:(020)27130331,27130196
FAX:(020)30781051
E-MAIL:vrcoatings@eth.net

No Contractual Document. Specification and features subject to change without notice.


DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE STATED

HEATER 7.6 KW.

PAINT WITHOUT CONTROL PANEL

Maxi. Inbound Pressure - 400 bar

PAGE - 1



PART NO.


REF.

41 011 000 00

PAGE 00

41 011 700 00

PAGE 00



TECHNICAL SPECIFICATION

Maximum Inbound Pressure : 400 bar
Capacity : 7.6 KW
Power Supply : 415 VAC,3 } ,50Hz
Inlet, Outlet Port : 3/4" BSP(M)
Temperature Range : 100°C
Wetted Parts : Aluminum, 304 Stainless Steel, PTFE.

DD-01/SD-30-1/0/010213

INPUT/OUTPUT LIST

INPUT

I1	Pressure Monitoring On/Off
I2	Fault Ack PB
I3	Supply On/Off sw
I4	Flush 1 sw
I5	Flush 2 sw
I6	Spare
I7	Base pressure input
I8	Act pressure input

OUTPUT

Q1	Supply Solenoid valve
Q2	Flush solenoid valve
Q3	Flt Lamp
Q4	Hooter

This image shows a full page of blank, lined paper. It features approximately 20 evenly spaced horizontal black lines across its entire width, typical of notebook or legal stationery. The background is a solid off-white color, and there are no margins, text, or other markings present.



This image shows a full page of blank white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page, providing a template for writing or drawing. There are no margins, text, or other markings present.

OPERATION PROCESS

Power ON the Main switch. Check that all MCB's are switched ON.

Also check that all settings of temperature indicator controllers are as per requirement.

Select the "Base Heater" switch to ON position, tank heaters for base becomes ON.

Select the "Act. Heater" switch to ON position, tank heaters for activator becomes ON.

AUTO MODE:-

Select the Auto/Manual switch to Auto mode.

Spray Operation (Paint):-

- Select the "Spray" selector switch to ON position. Spray solenoid valve becomes ON and spray cycle starts.
- Do not select the flush switch during spray operation. Fault occurs but spray cycle do not get disturbed.

Flush Operation (Solvent):-

- Select the "Base Flush" selector switch to ON position. Base flush solenoid valve becomes ON and base flush cycle starts.
- Select the "Act Flush" selector switch to ON position. Activator flush solenoid valve becomes ON and activator flush cycle starts.
- Spray selector switch must be OFF if flush cycle is ON.

Pressure Monitoring:-



- Select the "Pressure Monitoring" selector switch to ON position. Whenever pressure rises or falls down beyond set limits, pressure fault occurs. Hooter sounds and fault lamp glows.
- Press Fault Ack pushbutton to silence the hooter and acknowledge the fault.



PRESSURE SETTING ON PLC:-



- 1) On PLC display, set the values for high pressure, low pressure for both Base (paint) and Solvent.
- 2) When actual pressure deviates from these set ranges of pressure values, pressure fault occurs. (Pressure monitoring switch should be ON).

When control panel is powered up. Following screen appears.





The screen shows the actual pressure for Base and Activator. This is only readable message screen and cannot be edited.

Press "Down arrow key" to display job counter screen. Following screen appears.



The screen shows job counter display. This is optional arrangement, if there is requirement to have record of jobs sprayed in auto cycle. The counter gets incremented by 1 for each auto cycle. To reset the counter, press "Right arrow key and ESC key" simultaneously.


Now press "Down arrow key", following screen appears.




The screen shows date and time in blinking mode. Both are settable parameter.




Press "ESC" key to enter setting screen which is shown as under.



Using "Down arrow key", move the cursor to "set Param" function key. Following screen appears.




Press OK key of HMI to move to next screen shown as below.



Fault On delay timer can be set at this screen. The timer starts whenever a fault occurs. If the fault remains till the completion of this timer, fault lamp glows and hooter sounds.

Press Fault Ack pushbutton to silence the hooter and acknowledge the fault.


Press 'up' arrow key, following screen appears.



High limit for base pressure can be set at the parameter “On”.

For Ex:- Let the high limit for base pressure is set at “275” bar. When pressure goes beyond 275bar, fault occurs. Fault gets cleared only if pressure comes below “273”bar (Off parameter). The pressure limit can be changed using up/down arrow keys.


Press ‘up’ arrow key, following screen appears.



Low limit for base pressure can be set at the parameter “Off”.

For Ex:- Let the low limit for base pressure is set at “148” bar. When pressure falls below 148bar, fault occurs. Fault gets cleared only if pressure resumes above “150”bar (On parameter). The pressure limit can be changed using up/down arrow keys.

Press ‘up’ arrow key, following screen appears.



High limit for activator pressure can be set at the parameter “On”.

For Ex:- Let the high limit for act pressure is set at “275” bar. When pressure goes beyond 275bar, fault occurs. Fault gets cleared only if pressure comes below “273”bar (Off parameter). The pressure limit can be changed using up/down arrow keys.

Press ‘up’ arrow key, following screen appears.



- If activator pressure rises beyond the set pressure limit, activator pressure high message gets displayed as shown below.

			A	C	T				
		P	R	E	S	S	U	R	E
			H	I	G	H			


- If activator pressure falls below the set pressure limit, activator pressure low message gets displayed as shown below.

			A	C	T	.			
		P	R	E	S	S	U	R	E
			L	O	W				




TYPICAL INSTALLATION

Barrel Transfer Pump 4.5:1
(For Moisture Sensitive Material)



Barrel Length Pump 5.230
(For General Liquid)



INSTALLATION

1. Screw the bung adapter tightly into the bunghole of the drum.
 2. Install an air line filter on air line to remove harmful dirt and moisture from the compressed air supply.
 3. Connect air supply to the pump.
 4. Always connect a ground wire to the air motor.
- The pump installation is complete.

OPERATION

Daily startup procedures

1. Connect air supply to the Transfer pump.
 2. Turn on the main air supply.
 3. Slowly increase the air pressure by air regulator until the transfer pump run slowly.
- Use the Air regulator to control the pump speed.

Daily shutdown procedures

1. Slowly decrease the air pressure until zero.
2. Disconnect the air line.

For extended period shutdown

Flush, disassemble and thoroughly clean the Transfer pump before storing in a dry place.

MAINTANANCE

WARNING: TO AVOID PERSONAL INJURY, ALWAYS DISCONNECT THE AIR COUPLER AND RELIVE ALL THE AIR AND HYDRAULIC PRESSURES BEFORE SERVICING THE PUMP.

Disassembly

1. Place the transfer pump in a vice.
2. Remove the suction seat.


If the unit requires more than installation of a repair kit, it is usually quicker and least expensive to send the unit in for repair.

TROUBLE SHOOTING


MALFUNCTION	Pump does not start/stops during operation	Pump does not suck or only insufficiently	Spray pressure too low	Pump operates irregularly	Pump operates although spray gun is closed	Pump transports material into the rinsing agent	Regulator frozen
AIRMOTOR	Press sensing valve provided on control block Clean regulator, replace defective parts if necessary			Clean regulator, replace defective parts if necessary			Compressed air too moist, stroke frequency too high, ambient temperature too low.
HYDRAULIC PART		Not sufficiently ventilated, loose suction connection		Not sufficiently ventilated, loose suction connection	Not sufficiently ventilated, loose suction connection		
SUCTION AND TRANSFER VALVE		Worn or blocked, replace defective parts		Worn or blocked, replace defective parts	Replace worn or defective parts		
PACKINGS		Leaking piston and packing		Leaking piston and packing		Leaking packing	
FILTER	Filter mesh blocked, check where and clean out	Filter mesh blocked, check where and clean out	Filter mesh blocked, check where and clean out		Drain valve open.		
COMPRESSED AIR LINE	Volume flow too low, air pressure too low.		Volume flow too low, air pressure too low.				
MATERIAL HOSE	Blocked, check where and clean out	Blocked, check where and clean out	Blocked, check where and clean out				

TYPICAL INSTALLATION

**Barrel Transfer Pump 4.5:1
(For Moisture Sensitive Material)**



**Barrel Length Pump 5.230
(For General Liquid)**



INSTALLATION

1. Screw the bung adapter tightly into the bunghole of the drum.
 2. Install an air line filter on air line to remove harmful dirt and moisture from the compressed air supply.
 3. Connect air supply to the pump.
 4. Always connect a ground wire to the air motor.
- The pump installation is complete.

OPERATION

Daily startup procedures

1. Connect air supply to the Transfer pump.
 2. Turn on the main air supply.
 3. Slowly increase the air pressure by air regulator until the transfer pump run slowly.
- Use the Air regulator to control the pump speed.

Daily shutdown procedures

1. Slowly decrease the air pressure until zero.
2. Disconnect the air line.

For extended period shutdown

Flush, disassemble and thoroughly clean the Transfer pump before storing in a dry place.

MAINTANANCE

WARNING: TO AVOID PERSONAL INJURY, ALWAYS DISCONNECT THE AIR COUPLER AND RELIVE ALL THE AIR AND HYDRAULIC PRESSURES BEFORE SERVICING THE PUMP.

Disassembly

1. Place the transfer pump in a vice.
2. Remove the suction seat.

If the unit requires more than installation of a repair kit, it is usually quicker and least expensive to send the unit in for repair.

TROUBLE SHOOTING

MALFUNCTION	Pump does not start/stops during operation	Pump does not suck or only insufficiently	Spray pressure too low	Pump operates irregularly	Pump operates although spray gun is closed	Pump transports material into the rinsing agent	Regulator frozen
AIRMOTOR	Press sensing valve provided on control block Clean regulator, replace defective parts if necessary			Clean regulator, replace defective parts if necessary			Compressed air too moist, stroke frequency too high, ambient temperature too low.
HYDRAULIC PART		Not sufficiently ventilated, loose suction connection		Not sufficiently ventilated, loose suction connection	Not sufficiently ventilated, loose suction connection		
SUCTION AND TRANSFER VALVE		Worn or blocked, replace defective parts		Worn or blocked, replace defective parts	Replace worn or defective parts		
PACKINGS		Leaking piston and packing		Leaking piston and packing		Leaking packing	
FILTER	Filter mesh blocked, check where and clean out	Filter mesh blocked, check where and clean out	Filter mesh blocked, check where and clean out		Drain valve open.		
COMPRESSED AIR LINE	Volume flow too low, air pressure too low.		Volume flow too low, air pressure too low.				
MATERIAL HOSE	Blocked, check where and clean out	Blocked, check where and clean out	Blocked, check where and clean out				

OPERATION

- 1) I3 "ON" == Q1 ON
- 2) I4 "ON" == Q2A ON
- 3) I5 "ON" == Q2B ON
- 4) I1 "ON" == PRS MONITORING ON
FOR LP[OR HP " Q3 AND Q4"ON
FLT ACK === Q4 OFF
I1 "OFF" === Q3 ALSO OFF
- 5) I3 AND I4 "ON" == Q4 ON (HOOTER)
- 6) I3 AND I5 "ON" == Q4 ON

PREVENTIVE MAINTENANCE (ELECTRICAL)

- ❖ Keep the electrical control panel and junction boxes free from any debris and dust.
- ❖ Electrical connections should not be loosened. It may lead to spark.
- ❖ Identify components running hot or not according to specifications: Transformers, motors, bearings and wires almost always run hot before they fail. Predictive maintenance can avoid asset failure.
- ❖ Make sure that mounting fasteners and locking is secure.
- ❖ Check for wear of wiring insulation.
- ❖ Repair or replace the terminal blocks that are damaged or corroded.
- ❖ Make sure that all lamps are functioning well.
- ❖ Check the physical condition, operation and functionality of the Breakers, switches and component parts.
- ❖ Pitted contacts shall be replaced.
- ❖ Visually inspect for physical damage, moisture, overheating and cleanliness.
- ❖ Inspect and remove dust from busses, connectors, supports and Enclosure surfaces. A vacuum cleaner or dry compressed air may be used.
- ❖ Identify loose connections: Loose connections can cause power fluctuations to devices, devices to operate erratically and uneven load distribution between wires.



selec

TC513A / TC513AX / TC221A /
TC203AX / TC303A / TC303AX
Operating Instructions



SPECIFICATIONS

Display

3 digit, 7 segment digital display

LED Indications

R: Control output ON

Keys

3 keys for digital setting

INPUT SPECIFICATIONS

Input Signal

Thermocouple (J,K,T,R,S) / RTD (Pt100)

Sampling time

250 ms

Input Filter (FTC)

0.2 to 10.0 sec

Resolution

Fixed 1° resolution

Temperature Unit

°C / °F selectable

Indication Accuracy

For TC inputs: 0.25% of FS $\pm 1^\circ$
For R & S inputs: 0.5% of F.S $\pm 2^\circ$
(20 min of warm up time for TC input)
For RTD inputs: 0.1% of FS $\pm 1^\circ$

FUNCTIONAL SPECIFICATIONS

Control Method

- 1) PID control with auto tuning
- 2) ON-OFF control

Proportional Band (P)

1 to 400°

Integral Time (I)

0.0 to 99.9 min

Derivative Time (D)

0 to 999 sec

Cycle Time

0.1 to 99.9 sec

Hysteresis Width

0.1 to 99.9°

Manual Reset Value

-19.9 to 19.9°

CONTROL OUTPUT (Relay or SSR user selectable)*

Relay contact (SPST) (For TC513A, TC221A, TC303A)

10 A @ 250V AC / 30V DC, resistive

Relay contact (SPDT) (For TC513AX, TC203AX, TC303AX)

10 A @ 250V AC / 30V DC, resistive

SSR Drive Output (Voltage Pulse)

12V DC, 50 mA

POWER SUPPLY

Supply Voltage

85 to 270V AC/DC (AC: 50 or 60 Hz)

OPTIONAL - 24V AC/DC

Power Consumption

5 VA max @ 230V AC

Temperature

Operating: 0 to 50°C ; Storage: -20 to 75°C

Humidity (non-condensing)

95% RH

Weight

TC513A/TC513AX : 129 gms

TC221A/TC203AX : 180 gms

TC303A/TC303AX : 240 gms

SAFETY PRECAUTIONS

All safety related codifications, symbols and instructions that appear in this operating manual or on the equipment must be strictly followed to ensure the safety of the operating personnel as well as the instrument.

If the equipment is not handled in a manner specified by the manufacturer it might impair the protection provided by the equipment.

Read complete instructions prior to installation and operation of the unit.

WARNING: Risk of electric shock.

WIRING GUIDELINES

WARNING:

1. To prevent the risk of electric shock power supply to the equipment must be kept OFF while doing the wiring arrangement. Do not touch the terminals while power is being supplied.
2. To eliminate electromagnetic interference use short wire with adequate ratings; twists of the same in equal size shall be made. For the input and output signal lines, be sure to use shielded wires and keep them away from each other.
3. Cable used for connection to power source, must have a cross section of 1mm² or greater. These wires shall have insulation capacity made of at least 1.5kV.
4. When extending the thermocouple lead wires, always use thermocouple compensation wires for wiring. For the RTD type, use a wiring material with a small lead resistance (5Ω max per line) and no resistance differentials among three wires.
5. A better anti-noise effect can be expected by using standard power supply cable for the instrument.

MAINTENANCE

- 1 The equipment should be cleaned regularly to avoid blockage of ventilating parts.
2. Clean the equipment with a clean soft cloth . Do not use Isopropyl alcohol or any other cleaning agent.

INSTALLATION GUIDELINES


1. This equipment, being built-in-type, normally becomes a part of main control panel and in such case the terminals do not remain accessible to the end user after installation and internal wiring.
- 2 Do not allow pieces of metal, wire clippings, or fine metallic fillings from installation to enter the product or else it may lead to a safety hazard that may in turn endanger life or cause electrical shock to the operator.

3. Circuit breaker or mains switch must be installed between power source and supply terminals to facilitate power 'ON' or 'OFF' function. However this switch or breaker must be installed in a convenient position normally accessible to the operator.
4. Use and store the temperature controller within the specified ambient temperature and humidity ranges as mentioned in this manual.

CAUTION

1. When powering up for the first time, disconnect the output connections.
2. Fuse Protection: The unit is normally supplied without a power switch and fuses. Make wiring so that the fuse is placed between the mains power supply switch and the controller. (2 pole breaker fuse- rating: 275V AC, 1A for electrical circuitry is highly recommended)
3. Since this is a built-in-type equipment (finds place in main control panel), its output terminals get connected to host equipment. Such equipment shall also comply with basic EMI/EMC and other safety requirements like BSEN61326-1 and BSEN61010 respectively.
4. Thermal dissipation of equipment is met through ventilation holes provided on chassis of equipment. Such ventilation holes shall not be obstructed else it can lead to a safety hazard.
5. The output terminals shall be strictly loaded to the manufacturer specified values/range.

MECHANICAL INSTALLATION



MODELS	DIM	A	B	C	D	E	F	G
TC513A/TC513AX		52	52	94	45	4	46	46
TC221A/TC203AX		72	72	83.7	67	4.5	69	69
TC303A/TC303AX		96	96	73	90.5	5	92	92


1. Prepare the panel cutout with proper dimensions as shown above.
2. Remove the clamp from the controller and push the controller into the panel cutout. Insert the clamp from the rear side until the main unit is securely fit into the panel.
3. The equipment in its installed state must not come in close proximity to any heating sources, caustic vapors, oils, steam, or other unwanted process by-products.
4. Use the specified size of crimp terminals (M3.5 screws) to wire the terminal block. Tighten the screws on the terminal block using the tightening torque within the range of 1.2 N.m.
5. Do not connect anything to unused terminals.

EMC Guidelines:

1. Use proper input power cables with shortest connections and twisted type.
2. Layout of connecting cables shall be away from any internal EMI source.

LOAD CONNECTIONS

1. The service life of the output relays depends on the switching capacity and switching conditions. Consider the actual application conditions and use the product within the rated load and electrical service life.
2. Although the relay output is rated at 10 amps it is always necessary to use an interposing relay or contactor that will switch the load. This avoids damage to the controller in the event of a fault short developing on the power output circuit.
3. Always use a separate fused supply for the "power load circuit" and do not take this from the live and neutral terminals supplying power to the controller.




ELECTRICAL PRECAUTIONS DURING USE

Electrical noise generated by switching of inductive loads can create momentary disruption, erratic display, latch up, data loss or permanent damage to the instrument.

To reduce noise:


- a) Use of snubber circuits across loads as shown above, is recommended.
- b) Use separate shielded wires for inputs.

TERMINAL CONNECTIONS



Operating /1103/ TC513A / TC513AX / TC221A / TC203AX / TC303A / TC303AX / OP292-V04


TERMINAL CONNECTIONS




*NC contact valid only for TC203AX

Control Output

Relay Output




SSR Drive Output




Measured Value Input

Thermocouple (J, K, T, R, S)




Connect thermocouple sensor according to polarity shown.

RTD (Pt100)




For 2-wire RTD input short terminals 9 and 10.




*NC contact valid only for TC303AX

Control Output

Relay Output




SSR Drive Output




Measured Value Input

Thermocouple (J, K, T, R, S)



Connect thermocouple sensor according to polarity shown.

RTD (Pt100)




For 2-wire RTD input short terminals 11 and 12

WARNING: Please check the power supply voltage and controllers output type ordered (with reference to the order code) before installation.

Use only the correct thermocouple wire or compensating cable from the probe to instrument terminals avoiding joints in the cable if possible.
Failure to use the correct wire type will lead to inaccurate readings.

Ensure that the input sensor connected at the terminals and the input type set in the temperature controller configuration are the same.

FRONT PANEL DESCRIPTION



1	Process-value (PV) / Parameter name display	1) Displays a process value (PV). 2) Displays the parameter symbols at parameter setting mode for 1 sec and then parameter values. 3) Displays PV error conditions. (refer Table 2)
	Set-value (SV)	4) Displays a set value (SV) when key pressed.
2	Control output indication	The LED is lite when the control output is ON
3	Tune	Auto tune: Decimal point blinks with faster speed.

FRONT KEYS DESCRIPTION

Functions	Key press
Online	
To view Level 1	Press key for 3 seconds.
To view Level 2	Press key for 3 seconds.
To view Protection Level	Press + keys for 3 seconds.
To view and change setpoint value	Press to view the setpoint. Press + / key to change the setpoint.
Programming Mode	
To view parameters on the same level.	Or key once to view the next or previous function in operational menu.
To increase or decrease the value of a particular parameter.	+ to increase and + to decrease the function value. Note: Parameter value will not alter when respective level is locked.

NOTE: The unit will auto exit programming mode after 30 seconds of inactivity.

OR

By pressing the or or + keys for 3 sec.

USER GUIDE

1. Display Bias:

This function is used to adjust the PV value in cases where it is necessary for PV value to agree with another recorder or indicator, or when the sensor cannot be mounted in correct location.


2. Filter Time Constant

The input filter is used to filter out quick changes that occur to the process variable in a dynamic or quick responding application which causes erratic control. The digital filter also aids in controlling processes where the electrical noise affects the input signal. Larger the value of FTC entered, greater the filter added and the slower the controller reacts to the process and vice versa.

3. Auto tuning:

The Auto-tuning function automatically computes and sets the proportional band (P), integral time (I), Derivative time (D), ARW% and cycle time (CY.T) as per process characteristics.

- Decimal point of LSD flashes at faster speed while auto-tuning is being performed.
- At the completion of Auto-tuning, the decimal point stops blinking.




- If the power goes OFF before auto-tuning is completed, auto-tuning will be restarted at next power ON.
- If auto-tuning is not completed after 3-4 cycles, the auto-tuning is suspected to fail. In this case, check the wiring & parameters such as the control action, input type, etc.
- Carry out the auto-tuning again, if there is a change in set point or process parameters.

4. ON/OFF control action (For Reverse Mode):

The relay is 'ON' up to the set temperature and cuts 'OFF' above the set temperature. As the temperature of the system drops, the relay is switched 'ON' at a temperature slightly lower than the set point.


HYSTERESIS:

The difference between the temperature at which relay switches 'ON' and at which the relay switches 'OFF' is the hysteresis or dead band.



5. Manual Reset (for PID control & I=0):

After some time the process temperature settles at some point and there is a difference between the set temperature & the controlled temperature. This difference can be removed by setting the manual reset value equal & opposite to the offset.



CALIBRATION ACCURACY DECLARATION


Product is tested & calibrated by automatic technique. The calibration of this instrument is done as per following accuracy :

For TC inputs: 0.25% of FS $\pm 1^\circ$
For R & S inputs: 0.5% of F.S $\pm 2^\circ$
(20 min of warm up time for TC input)
For RTD inputs: 0.1% of FS $\pm 1^\circ$

Sources calibrated against:
Kusam-meco, model 405, Sr.No.:104446


Initial calibration is valid for 18 months after the Month/Year of manufacturing which is mentioned on order code label.

CONFIGURATION INSTRUCTIONS



OPERATIONAL MENU

POWER ON



REQUIRED PARAMETER SETTING IS SHOWN IN LEVEL 1
DISPLAY CONDITION COLUMN

Press key for 3 sec.

Press key for 3 sec.

Press + keys for 3 sec.

Level 1				
Display (For 1sec)	Description	Default Value	Range	Display Condition
Input	Input type (Refer Table 1)	J	J/K/T/R/S/RTD	RTD —
Unit	Temperature unit	°C	°C/°F	C —
SP.L	Set point low limit	-19.9	Min range of sensor selected to SP.H	00 —
SP.H	Set point high limit	150	SP.L to Max range of sensor selected	100 —
Filter	Filter time constant (Refer user guide)	1.0	0.2 to 10.0 sec	1.0 —
Action	Control action	RE	RE/FD	RE —
Logic	Control logic	PID	PID/ONF	ONF —
Anti reset	Anti reset windup%	25	1 to 100 %	For CNT=PID
Factory	Factory default (Reset all)	NO	NO/YES	NO —

Level 2				
Display (For 1sec)	Description	Default Value	Range	Display Condition
Tune	Tune (Refer user guide)	0.0	OFF/ON	For CNT=PID
P	Proportional band	1.0	1 to 400°	For CNT=PID
I	Integral time	2.0	0.0 to 99.9 min	For CNT=PID
d	Derivative time	3.0	0 to 999 sec	For CNT=PID
Cycle mode	Cycle time mode	AUT	AUT/US.F	For CNT=PID
Cycle time	Cycle time	15.0	0.1 to 99.9 sec	For CNT=PID
Hysteresis	Hysteresis	1.0	0.1 to 99.9°	For CNT=ONF
Manual reset	Manual reset (Refer user guide)	0.0	-19.9 to 19.9°	For CNT=PID & I=0
Display bias	Display bias (Refer user guide)	0.0	-19.9 to 19.9°	—

Protection Level				
Display (For 1sec)	Description	Default Value	Range	Display Condition
SP	Lock setpoint	UNL	UNK/LCK	—
LV1	Lock Level 1	UNL	UNK/LCK	—
LV2	Lock Level 2	UNL	UNK/LCK	—

Note

1. Locking parameters (LV1 or LV2 or SP) will not permit change in the value of respective level parameters.
2. Continuous operation of + keys for SP or other parameters makes Update speed faster in 3 stages after 3 seconds.

Programming Setpoint (Online):

Default: 50

To view setpoint: Press the key.

To increase/decrease setpoint: Press + keys.

Range: SP.L to SP.H

INPUT RANGES (Table 1)

FOR RTD

Input	°C	°F
Pt100	-150 to 850	-199 to 999

FOR THERMOCOUPLE

Input	°C	°F
J	-199 to 750	-199 to 999
K	-199 to 999	-199 to 999
T	-199 to 400	-199 to 750
R & S	0 to 999	32 to 999

ERROR DISPLAY (Table 2)

When an error has occurred, the display indicates error codes as given below.

Error	Meaning	Control Output Status
5.b7	Sensor break / Over range condition	OFF
5.nE	Sensor reverse / Under range condition	OFF

Selec Controls Pvt. Ltd.

(Specifications are subject to change, since development is a continuous process)

Telephone: +91-22-40394200 / 40394202

Fax: +91-22-28471733

Toll free: 1800 227 353

Website: www.selec.com

Email: sales@selec.com

Operating / 1103/ TC513A / TC513AX / TC221A / TC203AX / TC303A / TC303AX / OP292-V04

TECHNICAL SPECIFICATIONS**Barrel Transfer Pump**

Part No.	29 009 000 03
Output (Continuous duty)	21 Ltrs/Min
Output (Intermediate duty)	42 Ltrs/Min
Cycles per ltrs.	5
Cycle per Gal.	19
Pressure ratio	4.5:1
Stroke Length	120 mm
Air motor Piston ϕ	80mm
Air inlet pressure max	6 Bar



TECHNICAL SPECIFICATIONS**Barrel Transfer Pump**

Part No.	29 009 000 03
Output (Continuous duty)	21 Ltrs/Min
Output (Intermediate duty)	42 Ltrs/Min
Cycles per ltrs.	5
Cycle per Gal.	19
Pressure ratio	4.5:1
Stroke Length	120 mm
Air motor Piston ϕ	80mm
Air inlet pressure max	6 Bar



TECHNICAL SPECIFICATION

POLYUREA SPRAY SYSTEM - 2K/270/110X2

Type	2K/270/110x2
Mixing Ratio	1 :1
Transfer Ratio	55:1
Output Per Cycle	220 cc
Air motor Piston Ø	270 mm
Spray Volume @ 40 cycles/min	8.8 ltr/min
Air In Max	6 bar
Max. Pressure	330 bar
Air consumption N ltr @ 40 cycles/min	3850
Inline Heaters	7kw x 2nos.
Temperature Range	Up to 100° C
Power Supply	415 VAC-3 phase 50 Hz 5 wire R-Y-B-N-E copper flexible 6sq.mm x 5 core cable for incoming feeder



WARNING AND SAFETY INSTRUCTIONS

EQUIPMENT IS FOR PROFESSIONAL USE ONLY

⚠ WARNING**HIGH PRESSURE DEVICE FOR PROFESSIONAL USE ONLY**

Read and understand instruction manual before use and maintenance. Observe on warnings.



Do not use spray materials containing reactive solvents with equipment containing aluminum, galvanized or zinc coated wetted parts. e.g. Dichloromethane and ethylene chloride can chemically react with aluminum and galvanized or zinc coated parts and cause explosion hazard.

⚠ WARNING**Do not process flammable, explosive, toxic or otherwise hazardous materials without first performing an appropriate hazard analysis.**

VR Coatings cannot be an expert in the chemical and biological properties of the infinite number of materials that could be processed in this machine. As sold by VR Coatings, this machine is not designed to safely process hazardous materials unless additional precautions are not taken.

Before processing any material that are (or can react to become) flammable, explosive, toxic or otherwise hazardous, the user must perform a thorough hazard analysis and risk assessment of the entire process and determine the best way to deal with the hazard(s) identified, including contingency plans for dealing with processing errors and object conditions.



It is compulsory to

- know the product and possible hazards.
- store the product to be used in the appropriate areas.
- keep the product used during dispensing in a suitable container.
- Dispose the product according to the regulation of hazardous products in force in the country where the product is used.
- Wear protective equipment designed for that use.
- wear glasses, gloves, shoes clothes and mask for breath.

⚠ WARNING



SKIN INJECTION HAZARD. Protect hands and body from high-pressure fluids. Relieve pressure before disconnecting hydraulic or other lines and tighten all connections before applying pressure. In case of accidental skin injection, seek immediate "Surgical Treatment". Failure to follow this warning can result in amputation or serious injury.



- NEVER attempt to force the flow of fluid backward through the gun with your finger, hand or hand-held object against the gun nozzle.



- Before flushing system, always remove spray tip and adjust fluid pressure to lowest possible setting.



WARNING: The paint hose can develop leaks from wear, kinking, abuse etc. A leak is capable of injecting fluid into the skin; therefore the paint hose should be inspected before use. NEVER attempt to plug a hose with any part of your body, adhesive tape or any other makeshift device. Do not attempt to repair a spray hose. Instead, replace it with a new-grounded hose. You must see to it that the following points are followed for hoses, accessories or any other hardware:

- ☐ Comply with manufacturer's recommendations.
- ☐ Withstand the pressure ranges with correct safety factor.
- ☐ must not show any leaks, kinks, and sign of wear and should be factory fitted and pressure tested.

An air pressure safety valve forms an integral part of the air motor or air regulator and must not be altered or tampered with.

▲ WARNING



COMPONENT RUPTURE The system is capable of producing high pressure all components in the system must have a maximum working pressure capacity, not less than the pressure rating of the pump.

SERVICING Before servicing, cleaning or removing any part, always shut off power source, carefully release pressure in fluid portions of the system and set safety locks on guns and equipment

▲ WARNING



High velocity flow of material through equipment may create static electricity. All equipment being sprayed must be properly grounded to prevent sparking, which may cause fire or explosion.



Due to static electricity potential generated by the high velocity of fluid through the pump, hose and tip, sparking may occur and the system may be hazardous. This can result in an explosion and/or fire, if every part of the spray equipment is not properly grounded. Be sure that both the object being sprayed and the airless equipment are grounded.

This can be done by attaching a static wire to water piping or building structural members known to be earthen. If the hose does not contain a static electricity conductor, a static wire must be attached from the spray gun to the earth.

⚠ CAUTION



Before any adjustment, inspection, maintenance, cleaning, removing work always shut off the power source, carefully release pressure in fluid of the system and set safety locks on guns.

⚠ CAUTION



FLUSHING/CLEANING

Always flush the unit into a separate metal container with the spray tip removed and the gun held firmly against the side of container to assure proper grounding and prevent static discharge, which could cause serious bodily injury.

⚠ CAUTION



FINGURE OR HANDS PINCH HAZARD. KEEP HANDS CLEAR OF MOVING PARTS COUPLING AND PISTONS

Before servicing/removing any part always shut off power source and release pressure in fluid portions of the system.

WARNING AND SAFETY INSTRUCTIONS

EQUIPMENT IS FOR PROFESSIONAL USE ONLY

⚠ WARNING



HIGH PRESSURE DEVICE FOR PROFESSIONAL USE ONLY

Read and understand instruction manual before use and maintenance. Observe on warnings.



Do not use spray materials containing reactive solvents with equipment containing aluminum, galvanized or zinc coated wetted parts. e.g. Dichloromethane and ethylene chloride can chemically react with aluminum and galvanized or zinc coated parts and cause explosion hazard.

⚠ WARNING



Do not process flammable, explosive, toxic or otherwise hazardous materials without first performing an appropriate hazard analysis.

VR Coatings cannot be an expert in the chemical and biological properties of the infinite number of materials that could be processed in this machine. As sold by VR Coatings, this machine is not designed to safely process hazardous materials unless additional precautions are not taken.

Before processing any material that are (or can react to become) flammable, explosive, toxic or otherwise hazardous, the user must perform a thorough hazard analysis and risk assessment of the entire process and determine the best way to deal with the hazard(s) identified, including contingency plans for dealing with processing errors and object conditions.



It is compulsory to

- know the product and possible hazards.
- store the product to be used in the appropriate areas.
- keep the product used during dispensing in a suitable container.
- Dispose the product according to the regulation of hazardous products in force in the country where the product is used.
- Wear protective equipment designed for that use.
- wear glasses, gloves, shoes clothes and mask for breath.

⚠ WARNING



SKIN INJECTION HAZARD. Protect hands and body from high-pressure fluids. Relieve pressure before disconnecting hydraulic or other lines and tighten all connections before applying pressure. In case of accidental skin injection, seek immediate" Surgical Treatment". Failure to follow this warning can result in amputation or serious injury.



- NEVER attempt to force the flow of fluid backward through the gun with your finger, hand or hand-held object against the gun nozzle.



- Before flushing system, always remove spray tip and adjust fluid pressure to lowest possible setting.



WARNING: The paint hose can develop leaks from wear, kinking, abuse etc. A leak is capable of injecting fluid into the skin; therefore the paint hose should be inspected before use. NEVER attempt to plug a hose with any part of your body, adhesive tape or any other makeshift device. Do not attempt to repair a spray hose. Instead, replace it with a new-grounded hose. You must see to it that the following points are followed for hoses, accessories or any other hardware:

- ☐ Comply with manufacturer's recommendations.
- ☐ Withstand the pressure ranges with correct safety factor.
- ☐ must not show any leaks, kinks, and sign of wear and should be factory fitted and pressure tested.

An air pressure safety valve forms an integral part of the air motor or air regulator and must not be altered or tampered with.

▲ WARNING



COMPONENT RUPTURE The system is capable of producing high pressure all components in the system must have a maximum working pressure capacity, not less than the pressure rating of the pump.

SERVICING Before servicing, cleaning or removing any part, always shut off power source, carefully release pressure in fluid portions of the system and set safety locks on guns and equipment

▲ WARNING



High velocity flow of material through equipment may create static electricity. All equipment being sprayed must be properly grounded to prevent sparking, which may cause fire or explosion.



Due to static electricity potential generated by the high velocity of fluid through the pump, hose and tip, sparking may occur and the system may be hazardous. This can result in an explosion and/or fire, if every part of the spray equipment is not properly grounded. Be sure that both the object being sprayed and the airless equipment are grounded.

This can be done by attaching a static wire to water piping or building structural members known to be earthen. If the hose does not contain a static electricity conductor, a static wire must be attached from the spray gun to the earth.

⚠ CAUTION



Before any adjustment, inspection, maintenance, cleaning, removing work always shut off the power source, carefully release pressure in fluid of the system and set safety locks on guns.

⚠ CAUTION



FLUSHING/CLEANING

Always flush the unit into a separate metal container with the spray tip removed and the gun held firmly against the side of container to assure proper grounding and prevent static discharge, which could cause serious bodily injury.

⚠ CAUTION



FINGURE OR HANDS PINCH HAZARD. KEEP HANDS CLEAR OF MOVING PARTS COUPLING AND PISTONS

Before servicing/removing any part always shut off power source and release pressure in fluid portions of the system.

WARNING AND SAFETY INSTRUCTIONS

EQUIPMENT IS FOR PROFESSIONAL USE ONLY

⚠ WARNING



HIGH PRESSURE DEVICE FOR PROFESSIONAL USE ONLY

Read and understand instruction manual before use and maintenance. Observe on warnings.



Do not use spray materials containing reactive solvents with equipment containing aluminum, galvanized or zinc coated wetted parts. e.g. Dichloromethane and ethylene chloride can chemically react with aluminum and galvanized or zinc coated parts and cause explosion hazard.

⚠ WARNING



Do not process flammable, explosive, toxic or otherwise hazardous materials without first performing an appropriate hazard analysis.

VR Coatings cannot be an expert in the chemical and biological properties of the infinite number of materials that could be processed in this machine. As sold by VR Coatings, this machine is not designed to safely process hazardous materials unless additional precautions are not taken.

Before processing any material that are(or can react to become) flammable, explosive, toxic or otherwise hazardous, the user must perform a thorough hazard analysis and risk assessment of the entire process and determine the best way to deal with the hazard(s) identified, including contingency plans for dealing with processing errors and object conditions.



It is compulsory to

- know the product and possible hazards.
- store the product to be used in the appropriate areas.
- keep the product used during dispensing in a suitable container.
- Dispose the product according to the regulation of hazardous products in force in the country where the product is used.
- Wore protective equipment designed for that use.
- wore glasses, gloves, shoes clothes and mask for breath.

⚠ WARNING



SKIN INJECTION HAZARD. Protect hands and body from high pressure fluids. Relieve pressure before disconnecting hydraulic or other lines and tighten all connections before applying pressure. In case of accidental skin injection, seek immediate” Surgical Treatment”. Failure to follow this warning can result in amputation or serious injury.




An airless spray gun requires that fluid be introduced to it at very high pressure. Fluids under high pressure, from spray or leaks, can penetrate the skin and inject substantial quantities of toxic fluid into the body. If not promptly and properly treated, the injury can cause tissue death or gangrene and may result in serious, permanent disability or amputation of the wounded part. Therefore extreme caution must be exercised when using any airless spray equipment.

IF YOU ARE INJECTED, SEE A PHYSICIAN IMMEDIATELY. DO NOT TREAT AS A SIMPLE CUT!

NOTE TO PHYSICIAN:

Injection into the skin is a serious, traumatic injury. It is important to treat the injury surgically as soon as possible. Do not delay treatment to research toxicity. Toxicity is concerned with some exotic coatings injected directly in to the bloodstream. Consultation with a plastic surgeon or a reconstructive hand surgeon may be advised





- NEVER attempt to force the flow of fluid backward through the gun with your finger, hand or hand-held object against the gun nozzle.



- Before flushing system, always remove spray tip and adjust fluid pressure to lowest possible setting.



WARNING: The paint hose can develop leaks from wear, kinking, abuse etc. A leak is capable of injecting fluid into the skin; therefore the paint hose should be inspected before use. NEVER attempt to plug a hose with any part of your body, adhesive tape or any other makeshift device. Do not attempt to repair a spray hose. Instead, replace it with a new grounded hose. You must see to it that the following points are followed for hoses, accessories or any other hardware :

- ☐ Comply with manufacturer's recommendations.
 - ☐ Withstand the pressure ranges with correct safety factor.
 - ☐ Must not show any leaks, kinks, sign of wear and should be factory fitted and pressure tested.
- An air pressure safety valve forms an integral part of the air motor or air regulator and must not be altered or tampered with.



⚠ WARNING

COMPONENT RUPTURE The system is capable of producing high pressure all components in the system must have a maximum working pressure capacity, not less than the pressure rating of the pump.

SERVICING Before servicing, cleaning or removing any part, always shut off power source, carefully release pressure in fluid portions of the system and set safety locks on guns and equipment

**PRESSURE RELEASE PROCEDURE**

A Set trigger safely in a locked position.

B Shut off pump(Close main air supply valve and back-off air regulator).

C Release fluid pressure from entire system (Open drain valve) and trigger gun.

D Reset trigger safely in a locked position.

⚠ WARNING

High velocity flow of material through equipment may create static electricity. All equipment being sprayed must be properly grounded to prevent sparking, which may cause fire or explosion.



Due to static electricity potential generated by the high velocity of fluid through the pump, hose and tip, sparking may occur and the system may be hazardous. This can result in an explosion and/or fire, if every part of the spray equipment is not properly grounded. Be sure that both the object being sprayed and the airless equipment are grounded.

This can be done by attaching a static wire to water piping or building structural members known to be earthen. If the hose does not contain a static electricity conductor, a static wire must be attached from the spray gun to the earth.

⚠ CAUTION

Before any adjustment, inspection, maintenance, cleaning, removing work always shut off the power source, carefully release pressure in fluid of the system and set safety locks on guns.



ALWAYS follow the coating or solvent manufacturer's safety precautions and warnings. Never spray flammable material near open flames, pilot lights or any other source of ignition.



If you experience any static sparking or slight shock while using the equipment, stop spraying immediately. Check the entire system for proper grounding. Do not use the system again until the problem has been corrected.

Follow material supplier's instructions carefully and ensure adequate ventilation of working area to prevent health hazards.

⚠ CAUTION**FLUSHING/CLEANING**

Always flush the unit into a separate metal container with the spray tip removed and the gun held firmly against the side of container to assure proper grounding and prevent static discharge, which could cause serious bodily injury.

⚠ CAUTION

FINGURE OR HANDS PINCH HAZARD. KEEP HANDS CLEAR OF MOVING PARTS COUPLING AND PISTONS

Before servicing/removing any part always shut off power source and release pressure in fluid portions of the system.

⚠ CAUTION

DO NOT START PUMP IF GUARD IS NOT AT “UP” POSITION.


TO SET “UP” POSITION-hold by hands push upward till it locks in ball catch.

TO SET “DOWN” POSITION-Push downward.

FINGURE OR HANDS PINCH HAZARD.KEEP HANDS CLEAR. Before servicing/removing any part always shut off power source and release pressure in fluid portions of the system.

OPERATING INSTRUCTIONS

GENERAL DESCRIPTION:



Pneumatic piston Pumps are made for spraying, Dispensing, and transferring of various types of liquid/semi solid. These pumps are mainly used for airless/air assisted spraying of coating materials and dispensing /transferring of paints, oil, ink, sealants adhesives, wax, grease, solvents etc. and incorporate the following essential parts:

Airless Pump : Pneumatic motor with Control Unit, Hydraulic parts, Suction device, mounting plate ,etc.

Accessories: HP (High Pressure) hose, HP Filter, Trolley, Spray gun, Spray nozzle, etc.

Optional : Circulating unit, special accessories depending on applications.

The various pump versions are identified as follows:

e.g.: TIGER 30.150

Double stroke Volume in CC (150)

The above is intended to obtain the following data: s

Material Pressure : Pressure Input x Transmission Ratio

Displaced Volume : Double Stroke Volume x No. Of double stroke/ min. E.g. 50 double strokes/min.)

The pump works double acting and self-priming and serves to transfer the spray material to the spray gun by making it pass through a filter and a high pressure hose. Its differential piston, which is located in the hydraulic portion of the pump, moves upwards and downwards in the working cylinder (1 cycle = 1 double stroke = 1 upward and 1 downward stroke). The displacement piston features a layer of hard chrome of about 200 microns to protect against wear. The suction and delivery ball valve feature tungsten carbide seat.

The pump is equipped with an oil cup containing a solvent, which is intended to lubricate the piston and to prevent paint residues from incrustation. The packing need to be readjusted manually by tightening the upper packing take up nut which is designed as oil cup.

The actual spray performance depends on both spray nozzle size and selected spray pressure; increased material flow results in both spray nozzle size and air consumption.



Make sure that pump does not work too fast and / or too long when idling in order to prevent damage to sealing and valves.

All airless spraying units are equipped with capacity sieving filters. There are different mesh sizes to match according to the airless nozzle. Please see **Nozzle Chart** for appropriate type of nozzle.

In case of high delivery transfer pumps separate filters cartridge type or bag type can be used. Filter size depends upon the fluid, which is handled, and application requirements.

TWO COMPONENT HOT AIRLESS SPRAY EQUIPMENT -

Two Component Spray Equipment are used where curing time is very fast ranging from few seconds to several minutes and spraying through standard airless pump is not possible.

For High Performance Protective Coatings which are solvent free and fast curing Two Components Epoxy or PU Coating tar modified or tar free, Two Component Hot Airless Spraying Equipment is a must.

TWO COMPONENT HOT AIRLESS EQUIPMENT CONSIST OF -

1. Plural Component High Pressure Pump
2. Mixing Block
3. Mixers – Static / Dynamic
4. Flush Pump
5. Heating System
6. Feed pump and supply system
7. Monitoring and control system
8. Spray Guns

1. PLURAL COMPONENT HIGH PRESSURE PUMP

This is the core part of Two Component System. It is like a standard Airless Spray Equipment except two or three hydraulic cylinders driven by single common Air Motor.

2. MIXING BLOCK / MANIFOLD

Both the components that are individually metered and delivered by Two Component Pump are mixed in this Mixing Block incorporated with numbers of Non Return Valves. Return Line from the Mixing Block goes back to the tank in case of circulated system.

3. MIXERS

When fluids are pumped through mixer they are progressively divided and recombined to get mixed. Diameter and length of the mixer depends upon material specifications.

4. FLUSH PUMP

This is the standard Airless High Pressure Pump with pressure ratio ranging from 40:1 to 60:1 and output per cycle from 70 to 110cc used in Two Component Systems to rinse the whole system. Selection of flush pump depends on material to be flushed and hose lengths.

5. HEATED SYSTEM

This may consist of inline fluid heaters, heated supply containers, heated hoses. VR Coatings offers high pressure inline fluid heaters to heat each individual component to the required temperature. Oil heated Jacketed Containers up to 200 ltr. capacity is also offered by VR Coatings to preheat the component individually as per material specification. It has power up to 12KW and temperature range up to 100°C. This is controlled and monitored by PID based Control Panel.

For long hose lengths materials which have to be sprayed at high temperature, the spray hoses must be heated / insulated. VR Coatings offers hot water system to heat the hose and also provide electrical heated hose. In some cases insulated hose can

be used instead of heated hose again depending on application, material specification and ambient temperature.

6. FEED PUMP AND SUPPLY SYSTEM

Feeding pumps are used to feed the component from supply tank to Two Component pump. VR Coatings offers various feed pumps from its standard transfer pump range depending on the material specifications.

Separate feed pumps can be used to transfer material from supplier's drum to supply containers of Two Component System. Drumpress with Hoisting Unit can be used for transferring high viscous materials.

Agitators may also be used depending upon the application and type of the material. VR Coatings offers electrical driven high torque agitator for viscous material. Pneumatic agitators are also available where torque requirement is less.

7. MONITORING AND CONTROL SYSTEM

The monitoring system is required for safeguarding against incorrect mixing ratio for Two Component System. When pressure exceeds or drops surpassing the tolerance setting that are set by operator, while spraying the system automatically shut downs. When there is malfunctioning in the system and is manifested by surpassing set limits the system automatically switches off. These malfunctions may be because of internal / external leakage's, material deficiency, damaged seal etc. Automatic 'switching off' of the system prevents incorrect mixing ratio and reworks.

8. SPRAY GUNS

Trigger operated and insulated handle spray guns are used to apply coatings manually. For automatic spraying pneumatically operated automatic guns are used.

OTHER ACCESSORIES

A flexible HP hose serves as connection between pump and spray gun. Its inside wall consists of either Nylon or Teflon; it also contains an electrical conductor in order to permit electrostatic charges to discharge through the grounded pump.

WARNING



COMPONENT RUPTURE The system is capable of producing high pressure, all components in the system must have a maximum working pressure capacity not less than the pressure rating of the pump.

A large number of different nozzles are available. See **Nozzle Chart**.

MOUNTING OF ANY AIRLESS PUMP

Any pumping unit should be installed in a way to make it easily accessible for cleaning and maintenance purposes.



In the case of wall mounting, assure that pump is vertically installed and fastened by using the holes on the mounting plate.

All pumps are equipped with a grounding point. It is compulsory that the ground lead be connected to this point.

WARNING



High velocity flow of material through equipment may create static electricity. All equipment being sprayed must be properly grounded to prevent sparking, which may cause a fire or explosion.

Make sure that sufficient compressed air is available when connecting the pump to the air supply net.

Insure inside diameter of the connection tube between compressed air delivery point and airless unit is sufficient for required capacity.

COMMISSIONING AND OPERATING

1. General Information

Present pump is suitable for any kind of coatings/ material such as primers, basic coats, lacquers, dispersion paints, caustics, bituminous mastics etc.,

Depending on their physical and chemical characteristics, other types of spray media can be used e.g. cements, fillers, deadening agents and so forth.

Two component paints, PU material, PES material, acid hardening material or other media containing filler such as asbestos, ground cork and silicates require special attention prior to use.

We do not recommend the application of coarse bodied or abrasive fluids using the airless method. These would include sand filled wall coatings, coatings with coarse fibrous, various types of adhesives.

⚠ WARNING



Do not process flammable, explosive, toxic or otherwise hazardous materials without first performing an appropriate hazard analysis.


It is compulsory to

- know the product and possible hazards.**
- store the product to be used in the appropriate areas.**
- keep the product used during dispensing in a suitable container.**
- Dispose the product according to the regulation of hazardous products in force in the country where the product is used.**
- Wear protective equipment designed for that use.**
- wear glasses, gloves, shoes clothes and mask for breath.**

2. In case of doubt, please contact for correct equipment recommendations.

Setting up

- Hold oil cup/coupling guard by hand and push downwards in versions provided with this type of guard.
- Check for top lubricant to maximum level in pump lubrication chamber or oil-cup or packing take-up nut.
- Lift oilcup guard in upward direction till it locks in ball catch.

⚠ CAUTION	
	<p>FINGURE OR HANDS PINCH HAZARD. KEEP HANDS CLEAR. Before servicing/removing any part always shut off power source and release pressure in fluid portions of the system.</p> <p>Ensure coupling guard is always at UP position while pump is working.</p>

- Check high-pressure filter screen element. Mesh opening should be smaller than bore tip size used.
- The Table below should be used as a guideline only. We suggest that you do not use any filter element when spraying materials containing fibrous.

Mesh size an element marking (opening)	Tip size	Coating material to be sprayed
M 200 (0.084 mm/ 0.0033")	< 0.3 mm 0.011"	Clear lacquer, varnishes, and hammer tone.
M 150 (0.6 mm/0.0039")	>0.3 mm 0.011"	Primer, filler, red oxide.
M 100 (0.75 mm/0.0057")	>0.3 mm 0.011"	Primer, filler, red oxide.
M 70 (0.250 mm/0.0098")	>0.5 mm 0.016"	Iron mica, red oxide.
M 50 (0.320 mm/0.0125")	>0.6 mm 0.023"	Latex paint, bodied coatings.

- Connect high-pressure fluid hose and gun and connect air supply to air regulator.

⚠ CAUTION



Have Trigger Lock engaged at all times when not spraying/in use.

Grounding

Connect the other end of the grounding wire provided on machine to the earth ground. Always use electrically conductive hoses.

Flushing Of Complete Two Component System.

The unit has been factory tested using an oil emulsion. To avoid contamination of the coating material to be sprayed, be sure the emulsion is flushed from the system before spray operation begins by using a compatible solvent.

Do as follows:

- Close main air supply valve and back-off all air regulators.
- Close drain valve located at high-pressure filter at outlet manifold..
- Insert suction hose and tube or fluid end into compatible solvent.
- Place drain hoses from drain valves into container, open both drain Valves, if system having return lines open return line valves instead of drain valves and put line ends in container

Note: If system is already loaded with both components then take two separate containers to collect drain.

- Open main air supply valve and slowly open-air regulators to max. 2 bar (30 psi) of feed pumps. open air regulator of main plural component pump to max 2 bar.

Note: Pump cycles slowly and circulates fluid via drain hose or return line back into the container.

- Close Drain valves/return line valves. Point gun into container ensuring contact between gun and metal container-then trigger the gun.

Note: The pump will cycle slowly and circulate fluid via gun back into the container.

- Close gun and increase air regulator setting of two component pump to maximum pressure allowed. Check all connections for leaks.

Note: Maximum fluid pressure will vary according to the model of pump selected.

- Close main air supply valve and back-off air regulator.



- Open drain valves / return line valves relieve system pressure completely. Finally trigger the gun again shortly to ensure that there is no pressure retained in the fluid hose

⚠ CAUTION



CAUTION : drain valves, return valves, supply valves shall be always closed or opened simultaneously of both components: otherwise system will unbalance and raise high pressure In one line.

- Remove suction hose and tube or fluid end from solvent container, wipe clean . Point gun into the container, ensuring good contact with the container Trigger the Gun .Slowly open air regulators to max. 2 bar (30 psi) of feed pumps. open air regulator of main plural component pump to max 2 bar .Remove complete solvent via gun and return lines

⚠ CAUTION



FLUSHING/CLEANING

Always flush the unit into a separate metal container with the spray tip removed and the gun held firmly against the side of container to assure proper grounding and prevent static discharge which could cause serious bodily injury.

MATERIAL LOADING AND OPERATING.

- Take individual components to be mixed and sprayed in respective feed containers, manually or by separate transfer pumps or (if material is highly viscous) may be by drum press unit.
- Close Drain valves on filters at outlet manifold.
- Open return line valves. Increase feed pumps air pressure gradually till material flows properly. Collect return material in separate containers instead of main feed tank till its solvent free.
- Start flushing pump loaded with compatible solvent and keeps pressurized for immediate flushing of mixed material whenever required.
- Before opening supply valves, open flush valve and flush for few seconds. Close flushing Valve. Close return line valves and

- open supply line valves and Trigger the spray gun. Take mixed material in a separate container and increase pressure till you get proper mixing and atomization. Insure the pressures on the pressure gauges are stable before applying on substrate.

NOTE :

- There is pressure difference in upward and downward stroke due to use of feed pumps. As well as difference in both component pressures because of typical and efficient mixing block design.
- Set upper and lower pressure limits on either the gauges or pressure controllers provided for monitoring.
- Upper pressure limit shall be about 20 bar more than the stall pressure and lower limit shall be below about 20 bar than lowest working/spraying pressure. These parameters can be varied depending upon material specifications and application.



NOTE: Do not stop while spraying when pot life is very short. If you Stop, immediately close supply lines open return lines and flush the mixed material.

- Start monitoring system by switching on the monitoring switch on the control panel.
- Automatic switching off closes supply valves, opens return lines and flush valve and fault indication lamp will glow. Operator has to immediately flush the mixed material. Switch off monitoring. Identify and rectify the problem and start the system again as mentioned above.

OPERATING REMOTE PNEUMATIC CONTROLS.


- Refer circuit diagram of pneumatic control panel.
- To switch on supply valves and to switch off return line valves or vice versa. Operated hand lever of 3/2 way DC valve as shown in figure on Pneumatic Panel.
- To switch on flushing operate hand lever of 3/2 way DC valve as shown in figure. Flushing valve will only operate when supply line valves are closed and return line valves are open.



NOTE : Immediately flush the mixed material when you STOP Spraying

TROUBLE SHOOTING CHART RELATED TO MIXING.

PROBLEM	CAUSE	SOLUTION
Mixing ratio incorrect	Return line valve leaking	Check and clean valve seats, if worn out replace.
		Insure sufficient air pressure to valves.
		Check pneumatic circuit.
	External leakages through joints	Tighten the joints. Replace worn out sealings
	Hydraulic Part valve seat leakages	Remove and clean valve seats.
	Feeding Container empty	Refill the container
Solvent is mixing in sprayed material.	Flushing valve leaking	Check and clean valve seats. Replace if there are worn out parts. Check & clean non return valves in mixing block.
Spray pressure is low at high air inlet pressure	Choking in fluid line filters	Check filters. Clean the filter and replace element if necessary.
	Choking in hoses	Replace choked hoses.
	Choking in mixing block	Clean the mixing block and service it.
	Choking in Static Mixer	Clean or replace.
	Required material temperature not achieved	Circulate the heated material till required temperature reaches .
		Check whether any heating element is failed. Correct it or replace.
Mixed Material is not flushing out	Hardened material in the mixing block or in the static mixer or in the hose and gun	Clean the mixing block with compatible solvent; service it as necessary. Clean static mixer, gun and hose. Replace hose if cleaning not possible.
	Solvent pump pressure is low	Increase pump air pressure
	Flushing valve not opening fully	Insure sufficient air pressure to valve.
	Solvent container empty	Refill the solvent supply.
	The solvent is not compatible with the material	Change to a compatible solvent



PRESSURE RELEASE PROCEDURE

- A Set trigger safely in a locked position.
- B Shut off pump(Close main air supply valve and back-off air regulator).
- C Release fluid pressure from entire system
Open drain valve and trigger gun.
- D Reset trigger safely in a locked position.

Spray Pattern Control

CAUTION



Have Gun **Trigger Lock** engaged at all times when not actually spraying.

When installing **spray tip** be sure that **Gasket** is correctly used between gun tip and spray tip. With Gun in the “**Open**”(triggered) position, increase the air regulator setting until the correct spray pattern is achieved.



Note: Use the lowest air pressure possible that will give proper fluid atomization and spray pattern. Excessive or higher pressures show no improved result, but will cause reduced system component life, and will waste material.

POST-OPERATIONAL HANDLING:

Actuate gun in order to evacuate pressure from pump. Remove nozzle and clean it.

Lacquer may remain in the pump up to 48 hours. This should however be avoided when using two component materials or any other material liable to self-cure quickly.

Incase of protracted downtimes, evacuate pump, refill with solvent and leave as such. Clean HP filter if necessary.

- **Shut Down Procedure**

Flush the mixed material, shut-off flush valve. Actuate gun in order to evacuate pressure from pump. Follow Procedure as listed under “**Flushing**”, however use regular **Recommended lubricating oil** without additives instead of solvent, if the pump is to be put into storage.

Back-off (relief) air regulator completely.

Close main airs supply valve.

MAINTENANCE:

- Daily - if compressed air is wet - drain oil and water separator with pressure on and blow out water at least twice daily.
- Check fog oiler for correct adjustment (droplet metering) and oil s level. Refill if required.

Note: Severe operating conditions may cause frosting of Air motor. To prevent, fill fog oiler with mixture of 50:50 regular Recommended lubricating oil and Glycol.

- Check or top-up level of lubricant in pump packing take-up nut.
Note: Change lubricant every 50 hours of operation, earlier in oil cup pumps. Discoloration of lubricant indicates packing wear or failure. This will affect pump performance. If necessary, renew upper packing set.
- Clean and inspect filter elements in filter screen housing and high-pressure filter at least daily, based on quality of product to be sprayed.
- Do not kink or bend high-pressure fluid hose to less than four-inch radius.
- Loosen threaded connections or hose couplings of the unit or system only when essential. This will help prevent hardened materials getting into the system, which could malfunction.



- Displacement piston in lowest (DOWN) position at all times to prevent material from hardening on the fluid piston or rod.

TECHNICAL SPECIFICATIONS

Name	Type	Ratio	Output/cycle(cc)	Air motor piston ϕ mm	Stroke length mm	Approximate Weight (kg)	Recommended spray volume/minute (lt.)	Air inlet pressure Max (bar)	Output Pressure Max. (bar)	Air consumption N lt./ min. Max.
<u>TIGER</u>	30.70	30:1	70	110	120	19	3.5	8	240	900
	40.110	40:1	110	160	120	24	5.5	8	320	1900
	12.150	12:1	150	110	120	22	7.5	6	72	900
	28.20	28:1	20	80	70	15	2	6	168	450
	30.150	30:1	150	160	120	23	6	8	240	1900
	28.40	28:1	40	80/110	120/70	17	2	6	168	450
	60.70	60:1	70	160	120	21	3.5	6	360	1400
	16.70	16:1	70	80	120	17	3.5	8	128	450
	12.150	12:1	150	110	120	24	7.5	6	720	900
<u>RHINO</u>	45.210	45:1	210	230	120	62	5.5	6	270	3000
	60.150	60:1	150	230	120		6	6	360	3000
	30.275	30:1	275	230	120	62	10	6	280	3000
	45.275	45:1	275	270	120	70	7.5	6	270	4000
	60.210	60:1	210	210	120	70	5.5	6	360	3000
	55.275	55:1	275	300	120	67	7.5	6	330	5000
	75.210	75:1	210	300	120	67	5.5	6	450	5000
<u>HIPPO</u>	4.90	4:1	90	60	70	8	1.8	6	24	100
	2.900	2:1	900	110	120	28	30	6	12	480
	5.900	5:1	900	160	120	30	30	6	30	4000
	3.400	3:1	400	080	120	22	15	6	18	300
<u>ELEPHANT</u>	04.2000	4:1	2000	230	120	78	40	6	24	1200
	04.3400	4:1	3400	230	200		70	6	24	2000
	02.4000	2:1	4000	230	120	105	80	6	12	1200
	02.6500	2:1	6500	230	200	110	130	6	12	2000

CHEETAH

Type	2k -350 / 79X79X150	2k -350 / 110x110x110	2k -350 / 110x110x79	2k -350 / 110x110x58	2k -350 / 150x150x32
Mixing Ratio *	1:1	2:1	3:1	4:1	10:1
Transfer Ratio *	70:1	65:1	70:1	75:1	60:1
Output per Cycle	300 cc	340 cc	300 cc	280 cc	332 cc
Air Motor Piston	350 mm	350 mm	350 mm	350 mm	350 mm
Stroke Length	120 mm	120 mm	120 mm	120 mm	120 mm
Recommended Spray Vol/Min	7.5 ltr.	8.5 ltr.	7.5 ltr.	7 ltr.	8 ltr.
Air Inlet Pressure Max.	6 bar	6 bar	6 bar	6 bar	6 bar
Output Pressure Max.	420 bar	390 bar	420 bar	450 bar	360 bar
Air Consumption N ltr./min Max.	6800	6800	6800	6800	6800

*Other ratios on request



TROUBLE SHOOTING

MALFUNCTION	Pump does not start/stops during operation	Pump does not suck or only insufficiently	Spray pressure too low	Pump operates irregularly	Pump operates although spray gun is closed	Pump transports material into the rinsing agent	Regulator frozen
AIMOTOR	Press sensing valve provided on control block Clean regulator, replace defective parts if necessary			Clean regulator, replace defective parts if necessary			Compressed air too moist, stroke frequency too high, ambient temperature too low.
HYDRAULIC PART		Not sufficiently ventilated, loose suction connection		Not sufficiently ventilated, loose suction connection	Not sufficiently ventilated, loose suction connection		
SUCTION AND TRANSFER VALVE		Worn or blocked, replace defective parts		Worn or blocked, replace defective parts	Replace worn or defective parts		
PACKINGS		Leaking piston and packing		Leaking piston and packing		Leaking packing	
FILTER	Filter mesh blocked, check where and clean out	Filter mesh blocked, check where and clean out	Filter mesh blocked, check where and clean out		Drain valve open.		
COMPRESSED AIR LINE	Volume flow too low, air pressure too low.		Volume flow too low, air pressure too low.				
PRESSURE REGULATOR VALVE (AIR)	Air pressure too low		Air pressure too low				
SUCTION SET		Filter mesh blocked		Filter mesh blocked	Filter mesh blocked		
MATERIAL HOSE	Blocked, check where and clean out	Blocked, check where and clean out	Blocked, check where and clean out				
ATOMIZER	Orifice of spray cap blocked		Orifice spray too large				
MATERIAL BEING USED	Viscosity too high						

INDEX

DECLARATION OF CONFIRMITY	1
SAFETY LABELS	2
WARNING AND SAFETY INSTRUCTIONS	3
OPERATING INSTRUCTIONS	9
TROUBLESHOOTING	22
TECHNICAL SPECIFICATIONS	21
DRAWINGS AND PARTLISTS	
NOTES	24
WARRANTY	25



WARRANTY

VR Coatings warrants all equipments manufactured by us, as long as it is bearing original identification plate, to be free from defects in material and workmanship for a period of one year from ex-works date. VR Coatings will repair or replace any part of the equipment proven defective. The warranty applies only when the equipment is installed, operated and maintained in accordance with VR Coatings written recommendations.

Warranty claims found to be defective shall be verified and confirmed by VR Coatings.

Our warranty does not cover and VR Coatings shall not be liable for any malfunction, damages, or fair wear and tear caused by faulty installation, misuse, abrasion, corrosion, inadequate or improper maintenance, negligence, tempering, accident or incorporation of non VR Coatings parts, non observance of VR Coatings recommendations.

This warranty only consists of replacing the parts returned to our plant prepaid transportation and proven defective by us. If inspection of the equipment /part does not discloses any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may includes the cost of parts, labor and transportation. VR Coatings shall not be liable for any losses resulting from a production breakdown.

Material bought in equipment, which is sold but not manufactured by VR Coatings, will be subject to the manufacturer's warranty. VR Coatings will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

Date of sales

This image shows a full page of blank, lined paper. It features approximately 20 evenly spaced horizontal black lines across its entire width, providing a guide for handwriting or typing. The paper itself is a clean, off-white color.



SAFETY LABELS AND NAMEPLATE



Label on pump

label no.W.01



Label on pump provided with coupling guard


Label no.W.02



Label on pump provided without coupling guard

Label no.W.03

Safety labels free of charge on request



Name Plate



WARNING AND SAFETY INSTRUCTIONS

EQUIPMENT IS FOR PROFESSIONAL USE ONLY

⚠ WARNING



HIGH PRESSURE DEVICE FOR PROFESSIONAL USE ONLY

Read and understand instruction manual before use and maintenance. Observe on warnings.



Do not use spray materials containing reactive solvents with equipment containing aluminum, galvanized or zinc coated wetted parts. e.g. Dichloromethane and ethylene chloride can chemically react with aluminum and galvanized or zinc coated parts and cause explosion hazard.

⚠ WARNING



Do not process flammable, explosive, toxic or otherwise hazardous materials without first performing an appropriate hazard analysis.

VR Coatings cannot be an expert in the chemical and biological properties of the infinite number of materials that could be processed in this machine. As sold by VR Coatings, this machine is not designed to safely process hazardous materials unless additional precautions are not taken.

Before processing any material that are(or can react to become) flammable, explosive, toxic or otherwise hazardous, the user must perform a thorough hazard analysis and risk assessment of the entire process and determine the best way to deal with the hazard(s) identified, including contingency plans for dealing with processing errors and object conditions.



It is compulsory to

- Know the product and possible hazards.**
- Store the product to be used in the appropriate areas.**
- Keep the product used during dispensing in a suitable container.**
- Dispose the product according to the regulation of hazardous products in force in the country where the product is used.**
- Wore protective equipment designed for that use.**
- Wore glasses, gloves, shoes clothes and mask for breath.**

⚠ WARNING



SKIN INJECTION HAZARD. Protect hands and body from high pressure fluids. Relieve pressure before disconnecting hydraulic or other lines and tighten all connections before applying pressure. In case of accidental skin injection, seek immediate” Surgical Treatment”. Failure to follow this warning can result in amputation or serious injury.




An airless spray gun requires that fluid be introduced to it at very high pressure. Fluids under high pressure, from spray or leaks, can penetrate the skin and inject substantial quantities of toxic fluid into the body. If not promptly and properly treated, the injury can cause tissue death or gangrene and may result in serious, permanent disability or amputation of the wounded part. Therefore extreme caution must be exercised when using any airless spray equipment.

IF YOU ARE INJECTED, SEE A PHYSICIAN IMMEDIATELY. DO NOT TREAT AS A SIMPLE CUT!

NOTE TO PHYSICIAN:

Injection into the skin is a serious, traumatic injury. It is important to treat the injury surgically as soon as possible. Do not delay treatment to research toxicity. Toxicity is concerned with some exotic coatings injected directly in to the bloodstream. Consultation with a plastic surgeon or a reconstructive hand surgeon may be advised





- NEVER attempt to force the flow of fluid backward through the gun with your finger, hand or hand-held object against the gun nozzle.



- Before flushing system, always remove spray tip and adjust fluid pressure to lowest possible setting.



WARNING: The paint hose can develop leaks from wear, kinking, abuse etc. A leak is capable of injecting fluid into the skin; therefore the paint hose should be inspected before use. NEVER attempt to plug a hose with any part of your body, adhesive tape or any other makeshift device. Do not attempt to repair a spray hose. Instead, replace it with a new grounded hose. You must see to it that the following points are followed for hoses, accessories or any other hardware:

- ☐ Comply with manufacturer's recommendations.
 - ☐ Withstand the pressure ranges with correct safety factor.
 - ☐ Must not show any leaks, kinks, sign of wear and should be factory fitted and pressure tested.
- An air pressure safety valve forms an integral part of the air motor or air regulator and must not be altered or tampered with.



⚠ WARNING



COMPONENT RUPTURE The system is capable of producing high pressure all components in the system must have a maximum working pressure capacity, not less than the pressure rating of the pump.

SERVICING Before servicing, cleaning or removing any part, always shut off power source, carefully release pressure in fluid portions of the system and set safety locks on guns and equipment



PRESSURE RELEASE PROCEDURE

A Set trigger safely in a locked position.

B Shut off pump (Close main air supply valve and back-off air regulator).

C Release fluid pressure from entire system (Open drain valve) and trigger gun.

D Reset trigger safely in a locked position.

⚠ WARNING



High velocity flow of material through equipment may create static electricity. All equipment being sprayed must be properly grounded to prevent sparking, which may cause fire or explosion.



Due to static electricity potential generated by the high velocity of fluid through the pump, hose and tip, sparking may occur and the system may be hazardous. This can result in an explosion and/or fire, if every part of the spray equipment is not properly grounded. Be sure that both the object being sprayed and the airless equipment are grounded. This can be done by attaching a static wire to water piping or building structural members known to be earthen. If the hose does not contain a static electricity conductor, a static wire must be attached from the spray gun to the earth.

⚠ CAUTION

Before any adjustment, inspection, maintenance, cleaning, removing work always shut off the power source, carefully release pressure in fluid of the system and set safety locks on guns.



ALWAYS follow the coating or solvent manufacturer's safety precautions and warnings. Never spray flammable material near open flames, pilot lights or any other source of ignition.



If you experience any static sparking or slight shock while using the equipment, stop spraying immediately. Check the entire system for proper grounding. Do not use the system again until the problem has been corrected.

Follow material supplier's instructions carefully and ensure adequate ventilation of working area to prevent health hazards.

⚠ CAUTION**FLUSHING/CLEANING**

Always flush the unit into a separate metal container with the spray tip removed and the gun held firmly against the side of container to assure proper grounding and prevent static discharge, which could cause serious bodily injury.

⚠ CAUTION

FINGER OR HANDS PINCH HAZARD. KEEP HANDS CLEAR OF MOVING PARTS COUPLING AND PISTONS

Before servicing/removing any part always shut off power source and release pressure in fluid portions of the system.

⚠ CAUTION

DO NOT START PUMP IF GUARD IS NOT AT “UP” POSITION.

TO SET “UP” POSITION-hold by hands push upward till it locks in ball catch.

TO SET “DOWN” POSITION-Push downward.

FINGER OR HANDS PINCH HAZARD. KEEP HANDS CLEAR. Before servicing/removing any part always shut off power source and release pressure in fluid portions of the system.

⚠ CAUTION


Ensure that temperature of hot fluid used in the equipment shall not exceed 80% of the self-ignition temperature of the gases/solvent vapour in explosive atmosphere, in which equipment is used.

⚠ CAUTION

Check the compatibility of the solvent used in the equipment with the materials of wetted parts.

OPERATING INSTRUCTIONS

GENERAL DESCRIPTION:



Pneumatic piston Pumps are made for spraying, Dispensing, and transferring of various types of liquid/semi solid. These pumps are mainly used for airless/air assisted spraying of coating materials and dispensing /transferring of paints, oil, ink, sealants adhesives, wax, grease, solvents etc. and incorporate the following essential parts:

Airless Pump : Pneumatic motor with Control Unit, Hydraulic parts, Suction device, mounting plate ,etc.

Accessories: HP (High Pressure) hose, HP Filter, Trolley, Spray gun, Spray nozzle, etc.

Optional : Circulating unit, special accessories depending on applications.

The various pump versions are identified as follows:

e.g.: TIGER 30.150

Double stroke Volume in CC (150)

The above is intended to obtain the following data: s

Material Pressure : Pressure Input x Transmission Ratio

Displaced Volume : Double Stroke Volume x No. Of double stroke/ min. E.g. 50 double strokes/min.)

The pump works double acting and self-priming and serves to transfer the spray material to the spray gun by making it pass through a filter and a high pressure hose. Its differential piston, which is located in the hydraulic portion of the pump, moves upwards and downwards in the working cylinder (1 cycle = 1 double stroke = 1 upward and 1 downward stroke). The displacement piston features a layer of hard chrome of about 200 microns to protect against wear. The suction and delivery ball valve feature tungsten carbide seat.

The pump is equipped with an oil cup containing a solvent, which is intended to lubricate the piston and to prevent paint residues from incrustation. The packing need to be readjusted manually by tightening the upper packing take up nut which is designed as oil cup.

The actual spray performance depends on both spray nozzle size and selected spray pressure; increased material flow results in both spray nozzle size and air consumption.



Make sure that pump does not work too fast and / or too long when idling in order to prevent damage to sealing and valves.

All airless spraying units are equipped with capacity sieving filters. There are different mesh sizes to match according to the airless nozzle. Please see **Nozzle Chart** for appropriate type of nozzle.

In case of high delivery transfer pumps separate filters cartridge type or bag type can be used. Filter size depends upon the fluid, which is handled, and application requirements.

TWO COMPONENT HOT AIRLESS SPRAY EQUIPMENT-

Two Component Spray Equipment are used where curing time is very fast ranging from few seconds to several minutes and spraying through standard airless pump is not possible.

For high performance protective coatings which are solvent free and fast curing two components Epoxy or PU coating tar modified or tar free, two component hot airless spraying equipment is a must.

TWO COMPONENT HOT AIRLESS EQUIPMENT CONSIST OF-

1. Plural component high pressure pump
2. Mixing block
3. Mixers-Static/Dynamic
4. Flush pump
5. Heating system
6. Feed pump and supply system
7. Monitoring and control system
8. Spray guns



1. PLURAL COMPONENT HIGH PRESSURE PUMP

This is the core part of two component system. It is like standard airless spray equipment except two or three hydraulic cylinders driven by single common air motor.

2. MIXING BLOCK / MANIFOLD

Both the components that are individually metered and delivered by two component pump are mixed in this mixing block incorporated with numbers of non return valves. Return line from the mixing block goes back to the tank in case of circulated system.

3. MIXERS

When fluids are pumped through mixer they are progressively divided and recombined to get mixed. Diameter and length of the mixer depends upon material specifications.

4. FLUSH PUMP

This is the standard airless high pressure pump with pressure ratio ranging from 40:1 to 60:1 and output per cycle from 70 to 110cc used in two component system to rinse the whole system. Selection of flush pump depends on material to be flushed and hose lengths.

5. HEATED SYSTEM

This may consist of inline fluid heaters, heated supply containers, heated hoses. VR Coatings offers high pressure Inline fluid heaters to heat each individual component to the required temperature. Oil heated jacketed containers up to 200 ltr. capacity is also offered by VR Coatings to preheat the component individually as per material specification. It has power up to 12KW and temperature range up to 100°C. This is controlled and monitored by PID based control panel.

For long hose lengths materials which have to be sprayed at high temperature, the spray hoses must be heated/ insulated. VR Coatings offers hot water system to heated/ insulated. VR Coatings offers hot water system to

heat the hose and also provide electrical heated hose. In some cases insulated hose can be used instead of heated hose again depending on application, material specification and ambient temperature.

6. FEED PUMP AND SUPPLY SYSTEM

Feeding pump are used to feed the component from supply tank to two component pump. VR Coatings offers various feed pumps from its standard transfer pump range depending on the material specifications.

Separate feed pumps can be used to transfer material from Suppliers drum to supply containers of Two Component System. Drumpress with Hoisting unit can be used for transferring high viscous materials.

Agitators may also be used depending upon the application and type of the material. VR Coatings offers electrical driven high torque agitator for viscous material. Pneumatic agitators are also available where torque requirement is less.

7. MONITORING AND CONTROL SYSTEM

The monitoring system is required for safeguarding against incorrect mixing ratio for Two Component System. When pressure exceeds or drops surpassing the tolerance setting that are set by operator, while spraying the system automatically shut downs. When there is malfunctioning in the system and is manifested by surpassing set limits the system automatically switches off. These malfunctions may be because of internal/ external leakages, material deficiency, damaged seal etc. Automatic 'switching off' of the system prevents incorrect mixing ratio and reworks.

8. SPRAY GUNS

Trigger operated and insulated handle spray guns are used to apply coatings manually. For automatic spraying pneumatically operated automatic guns are used.

OTHER ACCESSORIES

A flexible HP hose serves as connection between pump and spray gun. Its inside wall consists of either Nylon or Teflon; it also contains an electrical conductor in order to permit electrostatic charges to discharge through the grounded pump.

WARNING



COMPONENT RUPTURE The system is capable of producing high pressure; all components in the system must have a maximum working pressure capacity not less than the pressure rating of the pump.

A large number of different nozzles are available. See **Nozzle Chart**.

MOUNTING OF ANY AIRLESS PUMP

Any pumping unit should be installed in a way to make it easily accessible for cleaning and maintenance purposes.



In the case of wall mounting, assure that pump is vertically installed and fastened by using the holes on the mounting plate.

All pumps are equipped with a grounding point. It is compulsory that the ground lead be connected to this point.

WARNING



High velocity flow of material through equipment may create static electricity. All equipment being sprayed must be properly grounded to prevent sparking, which may cause a fire or explosion.

Make sure that sufficient compressed air is available when connecting the pump to the air supply net.

Insure inside diameter of connection tube between compressed air delivery point and airless unit is sufficient for required capacity.

COMMISSIONING AND OPERATING

1. General Information

Present pump is suitable for any kind of coatings/ material such as primers, basic coats, lacquers, dispersion paints, caustics, bituminous mastics etc.,

Depending on their physical and chemical characteristics, other types of spray media can be used e.g. cements, fillers, deadening agents and so forth.

Two component paints, PU material, PES material, acid hardening material or other media containing filler such as asbestos, ground cork and silicates require special attention prior to use.

We do not recommend the application of coarse bodied or aggressive fluids using the airless method. These would include sand filled wall coatings, coatings with coarse fibrous, various types of adhesives.



⚠ WARNING



Do not process flammable, explosive, toxic or otherwise hazardous materials without first performing an appropriate hazard analysis.

It is compulsory to

- know the product and possible hazards.**
- store the product to be used in the appropriate areas.**
- keep the product used during dispensing in a suitable container.**
- Dispose the product according to the regulation of hazardous products in force in the country where the product is used.**
- Wear protective equipment designed for that use.**
- wear glasses, gloves, shoes clothes and mask for breath.**

2. In case of doubt, please contact for correct equipment recommendations.

Setting up

- Hold oil cup/coupling guard by hand and push downwards in versions provided with this type of guard.
- Check for top lubricant to maximum level in pump lubrication chamber or oil-cup or packing take-up nut.
- Lift oil cup guard in upward direction till it locks in ball catch.

⚠ CAUTION




FINGURE OR HANDS PINCH HAZARD. KEEP HANDS CLEAR. Before servicing/removing any part always shut off power source and release pressure in fluid portions of the system.

Ensure coupling guard is always at UP position while pump is working.

- Check high-pressure filter screen element. Mesh opening should be smaller than bore tip size used.
- The Table below should be used as a guideline only. We suggest that you do not use any filter element when spraying materials containing fibrous.

Mesh size an element marking (opening)	Tip size	Coating material to be sprayed
M 200 (0.084 mm/ 0.0033’')	< 0.3 mm 0.011’"	Clear lacquers, varnishes, and hammer tone.
M 150 (0.099mm/0.0039’)	>0.3 mm 0.011’"	Primer, filler, red oxide.
M 100 (0.145mm/0.0057)	>0.3 mm 0.011’"	Primer, filler, red oxide.
M 70 (0.250 mm/0.0098’)	>0.5 mm 0.016’"	Iron mica, red oxide.
M 50 (0.320 mm/0.0125’)	>0.6 mm 0.023’"	Latex paint, bodied coatings.

- Connect high-pressure fluid hose and gun and connect air supply to air regulator.

⚠ CAUTION	
	Have Trigger Lock engaged at all times when not spraying/in use.

Grounding

Connect the other end of the grounding wire provided on machine to the earth ground. Always use electrically conductive hoses.

Flushing of Complete Two Component System


The unit has been factory tested using an oil emulsion. To avoid contamination of the coating material to be sprayed, be sure the emulsion is flushed from the system before spray operation begins by using a compatible solvent.

Do as follows:

- Close main air supply valve and back-off air regulator.
- Close drain valve located at high-pressure filter manifold.
- Insert suction hose and tube or fluid end into compatible solvent.



- Place drain hoses from drain valves into container, open both drain Valves, if system having return lines open return line valves instead of drain valves and put line ends in container
Note: If system is already loaded with both components then take two separate containers to collect drain.
- Open main air supply valve and slowly open-air regulators to max. 2 bar (30 psi) of feed pumps. Open air regulator of main plural component pump to max 2 bar.
Note: Pump cycles slowly and circulates fluid via drain hose or return line back into the container.
- Close Drain valves/ return line valve. Point gun into container ensuring contact between gun and metal container then trigger the gun.
Note: The pump will cycle slowly and circulate fluid via gun back into the container.
- Close gun and increase air regulator setting of two component pump to maximum pressure allowed. Check all connections for leaks.
Note: Maximum fluid pressure will vary according to the model of pump selected.
- Close main air supply valve and back-off air regulator.
- Open drain valves/ return line valve relieve system pressure completely. Finally trigger the gun again shortly to ensure that there is no pressure retained in the fluid hose.

⚠ CAUTION	
	<p>CAUTION : drain valves, return valves, supply valves shall be always closed or opened simultaneously of both components: otherwise system will unbalance and raise high pressure In one line.</p>

- Remove suction hose and tube or fluid end from solvent container, wipe clean. Point gun into the container, ensuring good contact with the container Trigger the gun. Slowly open air regulators to max. 2 bar (30 psi) of feed pumps. Open air regulators to main plural component pump to max 2 bar. Remove complete solvent via gun and return lines+

CAUTION



FLUSHING/CLEANING

Always flush the unit into a separate metal container with the spray tip removed and the gun held firmly against the side of container to assure proper grounding and prevent static discharge which could cause serious bodily injury.

MATERIAL LOADING AND OPERATING

- Take individual components to be mixed and sprayed in respective feed containers, manually or separate transfer pump or (if material is highly viscous) may be by drumpress unit.
- Close drain valves on filters at outlet manifold.
- Open the return valves. Increase feed pumps air pressure gradually till material flows properly. Collect return material in separate containers instead of main feed tank till its solvent free.
- Start flushing pump loaded with compatible solvent and keeps pressurized for immediate flushing of mixed material whenever required.
- Before opening supply valves, open flush valve and flush for few seconds. Close flushing valve. Close return line valves and open supply line valves and Trigger the spray gun. Take mixed material in a separate container and increase till you get proper mixing and atomization. Insure the pressures on the pressure gauges are stable before applying on substrate.

NOTE:

- There is pressure difference in upward and downward stroke due to use of feed pumps. As well as difference in both component pressures because of typical and efficient mixing block design.
- Set upper and lower pressure limits on the gauges or pressure controllers provided for monitoring.
- Upper pressure limit shall be about 20 bar more than the stall pressure and lower limit shall be below about 20 bar than lowest working/spraying pressure. These parameters can be varied depending upon material specifications and application.





Note: Do not stop while spraying when pot life is very short. If you stop, immediately close supply lines open return lines and flush the mixed material.

Note: Do not stop while spraying when pot life is very short. If you stop, immediately close supply lines open return lines and flush the mixed material.

- Start monitoring system by switching on the monitoring switch on the control panel.
- Automatic switching off closes supply valves, open return lines and flush valve and indication lamp will glow. Operator has to immediately flush the mixed material. Switch off monitoring. Identify and rectify the problem and start the system again as mentioned above.

OPERATING REMOTE PNEUMATIC CONTROLS

- Refer circuit diagram of pneumatic control panel.
- To switch on supply valves and to switch off return line valves or vice versa. Operated hand lever of 3/2 way DC valve as shown in figure on pneumatic panel.
- To switch on flushing operate hand lever of 3/2 way DC valve as shown in figure. Flushing valve will only operate when supply line valves are closed and return line valves are open.




Note: Immediately flush the mixed material when you STOP spraying

TROUBLE SHOOTING CHART RELATED TO MIXING

PROBLEM	CAUSE	SOLUTION
Mixing ratio incorrect	Return line valve leaking	Check and clean valve seats, if worn out replace.
		Insure sufficient air pressure to valves.
		Check pneumatic circuit.
	External leakages through joints	Tighten the joints. Replace worn out sealing's
	Hydraulic part valve seat leakages	Remove and clean valve seats
	Feeding container empty	Refill the container
Solvent is mixing in sprayed material	Flushing valve leaking	Check and clean valve seats. Replace if there are worn out parts. Check & clean non return valves in mixing block.
Spray pressure is low at high air inlet pressure	Choking in fluid line filters	Check filters. Clean the filter and replace element if necessary.
	Choking in hoses	Replace choked hoses.
	Choking in static mixer	Clean or replace
	Required material temperature not achieved	Circulate the heated material till required temperature reaches
		Check whether any heating element is failed. Correct it or replace.
Mixed material is not flushing out	Hardened material in the mixing block or in the static mixer or in the hose and gun	Clean the mixing block with compatible solvent, Service it as necessary. Clean static mixer, gun and hose. Replace hose if cleaning not possible.
	Solvent pump pressure is low	Increase pump air pressure
	Flushing valve not opening fully	Insure sufficient air pressure to valve
	Solvent container empty	Refill the solvent supply
	The solvent is compatible with the material	Change to a compatible solvent





PRESSURE RELEASE PROCEDURE

- A Set trigger safely in a locked position.
- B Shut off pump(Close main air supply valve and back-off air regulator).
- C Release fluid pressure from entire system
Open drain valve and trigger gun.
- D Reset trigger safely in a locked position.

Spray Pattern Control

CAUTION



Have Gun **Trigger Lock** engaged at all times when not actually spraying.

When installing **spray tip** be sure that **Gasket** is correctly used between gun tip and spray tip. With Gun in the “**Open**” (triggered) position, increase the air regulator setting until the correct spray pattern is achieved.



Note: Use the lowest air pressure possible that will give proper fluid atomization and spray pattern. Excessive or higher pressures show no improved result, but will cause reduced system component life, and will waste material.

POST-OPERATIONAL HANDLING:

Actuate gun in order to evacuate pressure from pump. Remove nozzle and clean it.

Lacquer may remain in the pump unto 48 hours. This should however be avoided when using two component materials or any other material liable to self-cure quickly.

Incase of protracted downtimes, evacuate pump, refill with solvent and leave as such. Clean HP filter if necessary.



• SHUT DOWN PROCEDURE

Flush the mixed material, shut-off flush valve. Actuate gun in order to evacuate pressure from pump. Follow procedure as listed under “Flushing”, however use regular Recommended lubricating oil without additives instead of solvent, if the pump is to be put into storage.

Back-off (relief) air regulator completely.

Close main air supply valve.

MAINTENANCE:

- Daily - if compressed air is wet - drain oil and water separator with pressure on and blow out water at least twice daily.
- Check fog oiler for correct adjustment (droplet metering) and oil level. Refill if required.

Note: Severe operating conditions may cause frosting of Air motor. To prevent, fill fog oiler with mixture of 50:50 regular recommended lubricating oil and Glycol.

Check or top-up level of lubricant in pump packing take-up nut & tighten oil cup if required.

Note: Change lubricant every 50 hours of operation, earlier in oil cup pumps. Discoloration of lubricant indicates packing wear or failure. This will affect pump performance. If necessary, renew upper packing set.

- Clean and inspect filter elements in filter screen housing and high-pressure filter at least daily, based on quality of product to be sprayed.
- Do not kink or bend high-pressure fluid hose to less than four-inch radius.
- Loosen threaded connections or hose couplings of the unit or system only when essential. This will help prevent hardened materials getting into the system, which could malfunction.



- Displacement piston in lowest (DOWN) position at all times to prevent material from hardening on the fluid piston or rod.

TECHNICAL SPECIFICATIONS

Name	Type	Ratio	Output/cycle(cc)	Air motor piston ϕ mm	Stroke length mm	Approximate Weight (kg)	Recommended spray volume/minute (lt.)	Air inlet pressure Max. (bar)	Output Pressure Max. (bar)	Air consumption N lt./ min. Max.
<u>TIGER</u>	30.70	30:1	70	110	120	19	3.5	8	240	900
	40.110	40:1	110	160	120	24	5.5	8	320	1900
	12.150	12:1	150	110	120	22	7.5	6	72	900
	28.20	28:1	20	80	70	15	2	6	168	450
	30.150	30:1	150	160	120	23	6	8	240	1900
	28.40	28:1	40	80/110	120/70	17	2	6	168	450
	60.70	60:1	70	160	120	21	3.5	6	360	1400
	16.70	16:1	70	80	120	17	3.5	8	128	450
	12.150	12:1	150	110	120	24	7.5	6	720	900
	14.20	14:1	20	60	70	13	1.2	6	84	250
	14.40	14:1	40	60	120	15	1.2	6	84	250
<u>RHINO</u>	45.210	45:1	210	230	120	62	5.5	6	270	3000
	60.150	60:1	150	230	120	60	6	6	360	3000
	30.275	30:1	275	230	120	62	10	6	280	3000
	45.275	45:1	275	270	120	70	7.5	6	270	4000
	60.210	60:1	210	210	120	70	5.5	6	360	3000
	55.275	55:1	275	300	120	67	7.5	6	330	5000
	75.210	75:1	210	300	120	67	5.5	6	450	5000
	75.275	75:1	275	350	120	67	7.5	6	450	5000
<u>HIPPO</u>	4.90	4:1	90	60	70	8	1.8	6	24	100
	2.900	2:1	900	110	120	28	30	6	12	480
	5.900	5:1	900	160	120	30	30	6	30	4000
	3.400	3:1	400	080	120	22	15	6	18	300
<u>ELEPHANT</u>	4.2000	4:1	2000	230	120	78	40	6	24	1200
	4.3400	4:1	3400	230	200		70	6	24	2000
	2.4000	2:1	4000	230	120	105	80	6	12	1200
	2.6500	2:1	6500	230	200	110	130	6	12	2000

CHEETAH

Type	2k-350/ 79x79x150	2k-350/ 110x110x110	2k-350 / 110x110x79	2k-350/ 110x110x58	2k-350/ 150x150x32
Mixing Ratio*	1:1	2:1	3:1	4:1	10:1
Transfer Ratio*	70:1	65:1	70:1	75:1	60:1
Output per cycle	300 cc	340 cc	300 cc	280 cc	332 cc
Air Motor Piston	350 mm	350 mm	350 mm	350 mm	350 mm
Stroke Length	120 mm	120 mm	120 mm	120 mm	120 mm
Recommended spray Vol/min	7.5ltr.	8.5ltr.	7.5 ltr.	7 ltr.	8 ltr.
Air Inlet Pressure Max.	6 bar	6 bar	6 bar	6 bar	6 bar
Output Pressure Max.	420 bar	390 bar	420 bar	450 bar	360 bar
Air consumption N ltr./min Max.	6800	6800	6800	6800	6800



TROUBLE SHOOTING

MALFUNCTION	Pump does not start/stops during operation	Pump does not suck or only insufficiently	Spray pressure too low	Pump operates irregularly	Pump operates although spray gun is closed	Pump transports material into the rinsing agent	Regulator frozen
AIMOTOR	Clean regulator, replace defective parts if necessary			Clean regulator, replace defective parts if necessary			Compressed air too moist, stroke frequency too high, ambient temperature too low.
HYDRAULIC PART		Not sufficiently ventilated, loose suction connection		Not sufficiently ventilated, loose suction connection	Not sufficiently ventilated, loose suction connection		
SUCTION AND TRANSFER VALVE		Worn or blocked, replace defective parts		Worn or blocked, replace defective parts	Replace worn or defective parts		
PACKINGS		Leaking piston and packing		Leaking piston and packing		Leaking packing	
FILTER	Filter mesh blocked, check where and clean out	Filter mesh blocked, check where and clean out	Filter mesh blocked, check where and clean out		Drain valve open.		
COMPRESSED AIR LINE	Volume flow too low, air pressure too low.		Volume flow too low, air pressure too low.				
PRESSURE REGULATOR VALVE (AIR)	Air pressure too low		Air pressure too low				
SUCTION SET		Filter mesh blocked		Filter mesh blocked	Filter mesh blocked		
MATERIAL HOSE	Blocked, check where and clean out	Blocked, check where and clean out	Blocked, check where and clean out				
ATOMIZER	Orifice of spray cap blocked		Orifice spray too large				
MATERIAL BEING USED	Viscosity too high						

WARRANTY

VR Coatings warrants all equipments manufactured by us, as long as it is bearing original identification plate, to be free from defects in material and workmanship for a period of one year from ex-works date. VR Coatings will repair or replace any part of the equipment proven defective. The warranty applies only when the equipment is installed, operated and maintained in accordance with VR Coatings written recommendations.

Warranty claims found to be defective shall be verified and confirmed by VR Coatings.

Our warranty does not cover and VR Coatings shall not be liable for any malfunction, damages, or fair wear and tear caused by faulty installation, misuse, abrasion, corrosion, inadequate or improper maintenance, negligence, tempering, accident or incorporation of non VR Coatings parts, non observance of VR Coatings recommendations.

This warranty only consists of replacing the parts returned to our plant prepaid transportation and proven defective by us. If inspection of the equipment /part does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the cost of parts, labor and transportation. VR Coatings shall not be liable for any losses resulting from a production breakdown.

Material bought in equipment, which is sold but not manufactured by VR Coatings, will be subject to the manufacturer's warranty. VR Coatings will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

NOTES

[illegible]

INDEX

DECLARATION OF CONFIRMITY	1
SAFETY LABELS	2
WARNING AND SAFETY INSTRUCTIONS	3
OPERATING INSTRUCTIONS	9
TROUBLESHOOTING	17
TECHNICAL SPECIFICATIONS	18
WARRANTY	19
NOTES	20



SAFETY LABELS AND NAMEPLATE



Label on pump

label no.W.01




Label on pump provided without coupling guard Label no.W.02



Label on pump provided with coupling guard Label no.W.03

Safety labels free of charge on request



selec

TC513A / TC513AX / TC221A /
TC203AX / TC303A / TC303AX
Operating Instructions



SPECIFICATIONS

Display

3 digit, 7 segment digital display

LED Indications

R: Control output ON

Keys

3 keys for digital setting

INPUT SPECIFICATIONS

Input Signal

Thermocouple (J,K,T,R,S) / RTD (Pt100)

Sampling time

250 ms

Input Filter (FTC)

0.2 to 10.0 sec

Resolution

Fixed 1° resolution

Temperature Unit

°C / °F selectable

Indication Accuracy

For TC inputs: 0.25% of FS ±1°
For R & S inputs: 0.5% of F.S ± 2°
(20 min of warm up time for TC input)
For RTD inputs: 0.1% of FS ±1°

FUNCTIONAL SPECIFICATIONS

Control Method

- 1) PID control with auto tuning
- 2) ON-OFF control

Proportional Band (P)

1 to 400°

Integral Time (I)

0.0 to 99.9 min

Derivative Time (D)

0 to 999 sec

Cycle Time

0.1 to 99.9 sec

Hysteresis Width

0.1 to 99.9°

Manual Reset Value

-19.9 to 19.9°

CONTROL OUTPUT (Relay or SSR user selectable)*

Relay contact (SPST) (For TC513A, TC221A, TC303A)

10 A @ 250V AC / 30V DC, resistive

Relay contact (SPDT) (For TC513AX, TC203AX, TC303AX)

10 A @ 250V AC / 30V DC, resistive

SSR Drive Output (Voltage Pulse)

12V DC, 50 mA

POWER SUPPLY

Supply Voltage

85 to 270V AC/DC (AC: 50 or 60 Hz)

OPTIONAL - 24V AC/DC

Power Consumption

5 VA max @230V AC

Temperature

Operating: 0 to 50°C ; Storage: -20 to 75°C

Humidity (non-condensing)

95% RH

Weight

TC513A/TC513AX : 129 gms

TC221A/TC203AX : 180 gms

TC303A/TC303AX : 240 gms

SAFETY PRECAUTIONS

All safety related codifications, symbols and instructions that appear in this operating manual or on the equipment must be strictly followed to ensure the safety of the operating personnel as well as the instrument.

If the equipment is not handled in a manner specified by the manufacturer it might impair the protection provided by the equipment.

Read complete instructions prior to installation and operation of the unit.

WARNING: Risk of electric shock.

WIRING GUIDELINES

WARNING:

1. To prevent the risk of electric shock power supply to the equipment must be kept OFF while doing the wiring arrangement. Do not touch the terminals while power is being supplied.
2. To eliminate electromagnetic interference use short wire with adequate ratings; twists of the same in equal size shall be made. For the input and output signal lines, be sure to use shielded wires and keep them away from each other.
3. Cable used for connection to power source, must have a cross section of 1mm² or greater. These wires shall have insulation capacity made of at least 1.5kV.
4. When extending the thermocouple lead wires, always use thermocouple compensation wires for wiring. For the RTD type, use a wiring material with a small lead resistance (5Ω max per line) and no resistance differentials among three wires.
5. A better anti-noise effect can be expected by using standard power supply cable for the instrument.

MAINTENANCE

- 1 The equipment should be cleaned regularly to avoid blockage of ventilating parts.
2. Clean the equipment with a clean soft cloth . Do not use Isopropyl alcohol or any other cleaning agent.

INSTALLATION GUIDELINES


1. This equipment, being built-in-type, normally becomes a part of main control panel and in such case the terminals do not remain accessible to the end user after installation and internal wiring.
- 2 Do not allow pieces of metal, wire clippings, or fine metallic fillings from installation to enter the product or else it may lead to a safety hazard that may in turn endanger life or cause electrical shock to the operator.

3. Circuit breaker or mains switch must be installed between power source and supply terminals to facilitate power 'ON' or 'OFF' function. However this switch or breaker must be installed in a convenient position normally accessible to the operator.
4. Use and store the temperature controller within the specified ambient temperature and humidity ranges as mentioned in this manual.

CAUTION

1. When powering up for the first time, disconnect the output connections.
2. Fuse Protection: The unit is normally supplied without a power switch and fuses. Make wiring so that the fuse is placed between the mains power supply switch and the controller. (2 pole breaker fuse- rating: 275V AC,1A for electrical circuitry is highly recommended)
3. Since this is a built-in-type equipment (finds place in main control panel), its output terminals get connected to host equipment. Such equipment shall also comply with basic EMI/EMC and other safety requirements like BSEN61326-1 and BSEN61010 respectively.
4. Thermal dissipation of equipment is met through ventilation holes provided on chassis of equipment. Such ventilation holes shall not be obstructed else it can lead to a safety hazard.
5. The output terminals shall be strictly loaded to the manufacturer specified values/range.

MECHANICAL INSTALLATION



MODELS	DIM	A	B	C	D	E	F	G
TC513A/TC513AX		52	52	94	45	4	46	46
TC221A/TC203AX		72	72	83.7	67	4.5	69	69
TC303A/TC303AX		96	96	73	90.5	5	92	92


1. Prepare the panel cutout with proper dimensions as shown above.
2. Remove the clamp from the controller and push the controller into the panel cutout. Insert the clamp from the rear side until the main unit is securely fit into the panel.
3. The equipment in its installed state must not come in close proximity to any heating sources, caustic vapors, oils, steam, or other unwanted process by-products.
4. Use the specified size of crimp terminals (M3.5 screws) to wire the terminal block. Tighten the screws on the terminal block using the tightening torque within the range of 1.2 N.m.
5. Do not connect anything to unused terminals.

EMC Guidelines:

1. Use proper input power cables with shortest connections and twisted type.
2. Layout of connecting cables shall be away from any internal EMI source.

LOAD CONNECTIONS

1. The service life of the output relays depends on the switching capacity and switching conditions. Consider the actual application conditions and use the product within the rated load and electrical service life.
2. Although the relay output is rated at 10 amps it is always necessary to use an interposing relay or contactor that will switch the load. This avoids damage to the controller in the event of a fault short developing on the power output circuit.
3. Always use a separate fused supply for the "power load circuit" and do not take this from the live and neutral terminals supplying power to the controller.




ELECTRICAL PRECAUTIONS DURING USE

Electrical noise generated by switching of inductive loads can create momentary disruption, erratic display, latch up, data loss or permanent damage to the instrument.

To reduce noise:


- a) Use of snubber circuits across loads as shown above, is recommended.
- b) Use separate shielded wires for inputs.

TERMINAL CONNECTIONS



Operating /1103/ TC513A / TC513AX / TC221A / TC203AX / TC303A / TC303AX / OP292-V04


TERMINAL CONNECTIONS




*NC contact valid only for TC203AX

Control Output

Relay Output




SSR Drive Output




Measured Value Input

Thermocouple (J, K, T, R, S)




Connect thermocouple sensor according to polarity shown.

RTD (Pt100)




For 2-wire RTD input short terminals 9 and 10.




*NC contact valid only for TC303AX

Control Output

Relay Output




SSR Drive Output




Measured Value Input

Thermocouple (J, K, T, R, S)



Connect thermocouple sensor according to polarity shown.

RTD (Pt100)




For 2-wire RTD input short terminals 11 and 12

WARNING: Please check the power supply voltage and controllers output type ordered (with reference to the order code) before installation.

Use only the correct thermocouple wire or compensating cable from the probe to instrument terminals avoiding joints in the cable if possible.
Failure to use the correct wire type will lead to inaccurate readings.

Ensure that the input sensor connected at the terminals and the input type set in the temperature controller configuration are the same.

FRONT PANEL DESCRIPTION



1	Process-value (PV) / Parameter name display	1) Displays a process value (PV). 2) Displays the parameter symbols at parameter setting mode for 1 sec and then parameter values. 3) Displays PV error conditions. (refer Table 2)
	Set-value (SV)	4) Displays a set value (SV) when key pressed.
2	Control output indication	The LED is lite when the control output is ON
3	Tune	Auto tune: Decimal point blinks with faster speed.

FRONT KEYS DESCRIPTION

Functions	Key press
Online	
To view Level 1	Press key for 3 seconds.
To view Level 2	Press key for 3 seconds.
To view Protection Level	Press + keys for 3 seconds.
To view and change setpoint value	Press to view the setpoint. Press + / key to change the setpoint.
Programming Mode	
To view parameters on the same level.	Or key once to view the next or previous function in operational menu.
To increase or decrease the value of a particular parameter.	+ to increase and + to decrease the function value. Note: Parameter value will not alter when respective level is locked.

NOTE: The unit will auto exit programming mode after 30 seconds of inactivity.

OR

By pressing the or or + keys for 3 sec.

USER GUIDE

1. Display Bias:

This function is used to adjust the PV value in cases where it is necessary for PV value to agree with another recorder or indicator, or when the sensor cannot be mounted in correct location.


2. Filter Time Constant

The input filter is used to filter out quick changes that occur to the process variable in a dynamic or quick responding application which causes erratic control. The digital filter also aids in controlling processes where the electrical noise affects the input signal. Larger the value of FTC entered, greater the filter added and the slower the controller reacts to the process and vice versa.

3. Auto tuning:

The Auto-tuning function automatically computes and sets the proportional band (P), integral time (I), Derivative time (D), ARW% and cycle time (CY.T) as per process characteristics.

- Decimal point of LSD flashes at faster speed while auto-tuning is being performed.
- At the completion of Auto-tuning, the decimal point stops blinking.




- If the power goes OFF before auto-tuning is completed, auto-tuning will be restarted at next power ON.
- If auto-tuning is not completed after 3-4 cycles, the auto-tuning is suspected to fail. In this case, check the wiring & parameters such as the control action, input type, etc.
- Carry out the auto-tuning again, if there is a change in set point or process parameters.

4. ON/OFF control action (For Reverse Mode):

The relay is 'ON' up to the set temperature and cuts 'OFF' above the set temperature. As the temperature of the system drops, the relay is switched 'ON' at a temperature slightly lower than the set point.


HYSTERESIS:

The difference between the temperature at which relay switches 'ON' and at which the relay switches 'OFF' is the hysteresis or dead band.



5. Manual Reset (for PID control & I=0):

After some time the process temperature settles at some point and there is a difference between the set temperature & the controlled temperature. This difference can be removed by setting the manual reset value equal & opposite to the offset.



CALIBRATION ACCURACY DECLARATION

Product is tested & calibrated by automatic technique. The calibration of this instrument is done as per following accuracy :


For TC inputs: 0.25% of FS $\pm 1^\circ$
For R & S inputs: 0.5% of F.S $\pm 2^\circ$
(20 min of warm up time for TC input)
For RTD inputs: 0.1% of FS $\pm 1^\circ$

Sources calibrated against:

Kusam-meco, model 405, Sr.No.:104446


Initial calibration is valid for 18 months after the Month/Year of manufacturing which is mentioned on order code label.

CONFIGURATION INSTRUCTIONS



OPERATIONAL MENU

POWER ON



REQUIRED PARAMETER SETTING IS SHOWN IN LEVEL 1
DISPLAY CONDITION COLUMN

Press key for 3 sec.

Press key for 3 sec.

Press + keys for 3 sec.

Level 1				
Display (For 1sec)	Description	Default Value	Range	Display Condition
Input	Input type (Refer Table 1)	J	J/K/T/R/S/RTD	RTD —
Unit	Temperature unit	°C	°C/°F	C —
SP.L	Set point low limit	-19.9	Min range of sensor selected to SP.H	00 —
SP.H	Set point high limit	150	SP.L to Max range of sensor selected	100 —
Filter	Filter time constant (Refer user guide)	1.0	0.2 to 10.0 sec	1.0 —
Action	Control action	RE	RE/FD	RE —
Logic	Control logic	PID	PID/ONF	ONF —
Anti reset	Anti reset windup%	25	1 to 100 %	For CNT=PID
Factory	Factory default (Reset all)	NO	NO/YES	NO —

Level 2				
Display (For 1sec)	Description	Default Value	Range	Display Condition
Tune	Tune (Refer user guide)	OFF	OFF/ON	For CNT=PID
P	Proportional band	1.0	1 to 400°	For CNT=PID
I	Integral time	2.0	0.0 to 99.9 min	For CNT=PID
d	Derivative time	3.0	0 to 999 sec	For CNT=PID
Cycle mode	Cycle time mode	AUT	AUT/US.F	For CNT=PID
Cycle time	Cycle time	15.0	0.1 to 99.9 sec	For CNT=PID
Hysteresis	Hysteresis	1.0	0.1 to 99.9°	For CNT=ONF
Manual reset	Manual reset (Refer user guide)	0.0	-19.9 to 19.9°	For CNT=PID & I=0
Display bias	Display bias (Refer user guide)	0.0	-19.9 to 19.9°	—

Protection Level				
Display (For 1sec)	Description	Default Value	Range	Display Condition
SP	Lock setpoint	UNL	UNK/LCK	—
LV1	Lock Level 1	UNL	UNK/LCK	—
LV2	Lock Level 2	UNL	UNK/LCK	—

Note

1. Locking parameters (LV1 or LV2 or SP) will not permit change in the value of respective level parameters.
2. Continuous operation of + keys for SP or other parameters makes Update speed faster in 3 stages after 3 seconds.

Programming Setpoint (Online):

Default: 50

To view setpoint: Press the key.

To increase/decrease setpoint: Press + keys.

INPUT RANGES (Table 1)

FOR RTD		
Input	°C	°F
Pt100	-150 to 850	-199 to 999

FOR THERMOCOUPLE

Input	°C	°F
J	-199 to 750	-199 to 999
K	-199 to 999	-199 to 999
T	-199 to 400	-199 to 750
R & S	0 to 999	32 to 999

ERROR DISPLAY (Table 2)

When an error has occurred, the display indicates error codes as given below.		
Error	Meaning	Control Output Status
5.b 7	Sensor break / Over range condition	OFF
5.n E	Sensor reverse / Under range condition	OFF

Selec Controls Pvt. Ltd.

(Specifications are subject to change, since development is a continuous process)

Telephone: +91-22-40394200 / 40394202

Fax: +91-22-28471733

Toll free: 1800 227 353

Website: www.selec.com

Email: sales@selec.com